

System Multimeter PM2535

Operation Manual/Gebrachsanleitung/Notice d'emploi

4822 872 30387

900810



PHILIPS

IMPORTANT

In correspondence concerning this instrument, please quote the type number and serial number as given on the type plate.

NOTE: *The design of this instrument is subject to continuous development and improvement. Consequently, this instrument may incorporate minor changes in detail from the information contained in this manual.*

WICHTIG

Bei Schriftwechsel über dieses Gerät wird gebeten, die genaue Typenbezeichnung und die Gerätenummer anzugeben. Diese befinden sich auf dem Leistungsschild.

BEMERKUNG: *Die Konstruktion und Schaltung dieses Geräts wird ständig weiterentwickelt und verbessert. Deswegen kann dieses Gerät von den in dieser Anleitung stehenden Angaben abweichen.*

IMPORTANT

RECHANGE DES PIECES DETACHEES (Réparation)

Dans votre correspondance et dans vos réclamations se rapportant à cet appareil, veuillez TOUJOURS indiquer le numéro de type et le numéro de série qui sont marqués sur la plaquette de caractéristiques.

REMARQUE: *Cet appareil est l'objet de développements et améliorations continuels. En conséquence, certains détails mineurs peuvent différer des informations données dans la présente notice d'emploi et d'entretien.*

CONTENTS

Page

1. OPERATOR SAFETY	1-1E
1.1 General information	1-1E
1.2 Safety precautions	1-1E
1.3 Caution and warning statements	1-1E
1.4 Symbols	1-1E
1.5 Impaired safety protection	1-1E
 2. GENERAL INFORMATION	 2-1E
2.1 Introduction	2-1E
2.2 Characteristics	2-2E
2.2.1 Safety characteristics	2-2E
2.2.2 Performance characteristics	2-2E
2.2.3 Vdc	2-3E
2.2.4 Vac	2-5E
2.2.5 Resistance	2-6E
2.2.6 Idc	2-8E
2.2.7 Iac	2-9E
2.2.8 Temperature	2-11E
2.2.9 Converter characteristics	2-11E
2.2.10 Time function	2-12E
2.2.11 Input terminal arrangement	2-12E
2.3 Operational data	2-13E
2.3.1 Display	2-13E
2.3.2 IEC/IEEE interface	2-14E
2.3.3 System 21 interface	2-14E
2.3.4 External control	2-14E
2.4 Environmental conditions	2-14E
2.4.1 Climatic conditions	2-14E
2.4.2 Mechanical conditions	2-15E
2.4.3 Line supply conditions	2-15E
2.4.4 Power consumption	2-15E
2.4.5 Accessories	2-15E
 3. INSTALLATION INSTRUCTIONS	 3-1E
3.1 Initial inspection	3-1E
3.2 Safety instructions	3-1E
3.2.1 Earthing (grounding)	3-1E
3.2.2 Mains voltage setting and fuses	3-1E
3.3 Operating position of the instrument	3-2E
3.4 19-Inch rack-mounting	3-2E

	Page
4. OPERATING INSTRUCTIONS	4-1E
4.1 General information	4-1E
4.2 Switching-on	4-1E
4.3 Display indications	4-3E
4.4 Keyboard	4-5E
4.4.1 Multimeter functions, direct action	4-5E
4.4.2 Help functions	4-6E
4.4.2.1 Function programming	4-6E
4.4.2.2 General	4-6E
4.4.2.3 Mathematic functions	4-6E
4.4.2.4 Aquisition/presentation of measuring data	4-6E
4.4.2.5 Input of figures	4-7E
4.4.3 Inputs	4-7E
4.4.4 Guard Usage	4-7E
4.5 Rear panel Controls	4-8E
4.6 Detailed multimeter functions explanation	4-9E
4.6.1 Function Selection	4-9E
4.6.2 Ranging	4-9E
4.6.3 Trigger	4-10E
4.6.4 Speed	4-11E
4.6.5 Filter	4-12E
4.6.6 Null	4-12E
4.6.7 Selfdiagnostics	4-13E
4.6.8 Reset	4-13E
4.6.9 Calibration	4-13E
4.7 Measuring functions explanation	4-14E
4.7.1 Direct voltage measurements	4-14E
4.7.2 Alternating voltage measurements	4-15E
4.7.3 Resistance two-wire measurements	4-16E
4.7.4 Resistance four-wire measurements	4-17E
4.7.5 Direct current measurements	4-18E
4.7.6 Alternating current measurements	4-19E
4.7.7 Temperature measurements	4-20E
4.7.8 Clipping-Crest-factor indication	4-20E
4.8 Help functions Explanation	4-21E
4.8.1 Mathematical functions explanations	4-21E
4.8.1.1 AX + B scaled measurements	4-21E
4.8.1.2 dBm	4-23E
4.8.1.3 $\Delta\% \frac{X-C}{C} \times 100\%$	4-24E
4.8.1.4 Zero	4-25E
4.8.2 Aquisition/presentation of measuring data	4-26E
4.8.2.1 Delay	4-26E
4.8.2.2 Limits	4-27E
4.8.2.3 Burst	4-29E
4.8.2.4 RD.BUF. (read buffer)	4-31E
4.8.2.5 MIN/MAX	4-35E
4.8.2.6 Digits	4-36E
4.8.3 Function programming	4-37E
4.8.3.1 PROG function	4-37E
4.8.3.2 Sequence	4-38E

4.9	General	4-42E
4.9.1	Beeper ■	4-42E
4.9.2	<u>CLR</u> (Clear)	4-43E
4.9.3	Check	4-44E
4.9.4	SHIFT and <u>ENTER</u>	4-44E
4.9.5	Input of figures	4-44E

5. OPERATING INSTRUCTIONS FOR REMOTE OPERATION VIA IEC-625/IEEE-488 INTERFACE 5-1E

5.1	General	5-1E
5.2	Specifications	5-1E
5.2.1	Functional specification	5-1E
5.2.2	Code specification	5-1E
5.2.3	Connector pinning	5-1E
5.2.4	Timing specification	5-2E
5.3	Programming the PM2535	5-3E
5.3.1	General information	5-3E
5.4	Interface programming	5-3E
5.4.1	Explanation	5-3E
5.4.2	Remote/local selection	5-4E
5.4.3	Talk only selection	5-4E
5.4.4	Address selection	5-5E
5.4.5	Interface program data	5-5E
5.4.6	Sending program data	5-5E
5.4.7	Separators	5-7E
5.4.8	Identity	5-7E
5.4.9	Interface test	5-7E
5.5	Device programming	5-7E
5.5.1	Function selection	5-8E
5.5.2	Range selection	5-8E
5.5.3	Measuring Speed/Resolution	5-9E
5.5.4	Filter	5-9E
5.5.5	Trigger modes	5-10E
5.5.6	Internal settling time	5-10E
5.5.7	Start command	5-10E
5.5.8	Display mode	5-10E
5.5.9	Output mode	5-11E
5.5.10	Null	5-11E

VIE

	Page
5.6	Help functions (Device programming) 5-12E
5.6.1	Mathematic functions 5-12E
5.6.1.1	AX + B 5-12E
5.6.1.2	dBm 5-13E
5.6.1.3	Δ% 5-13E
5.6.1.4	Zero 5-14E
5.6.2	Aquisition/presentation of measuring data 5-14E
5.6.2.1	Delay 5-14E
5.6.2.2	Limits 5-15E
5.6.2.3	BURST 5-15E
5.6.2.4	RD.BUF (Read Buffer) 5-16E
5.6.2.5	MIN/MAX 5-17E
5.6.2.6	DIGITS 5-18E
5.6.3	Function programming 5-18E
5.6.3.1	PROG function 5-18E
5.6.3.2	Sequence 5-18E
5.6.3.3	Bleeper 5-19E
5.7	System 21 mode 5-19E
5.8	Survey of commands 5-20E
5.9	Calibration via the controller 5-23E
5.10	Selfdiagnostics via the controller 5-23E
5.11	Output data 5-23E
5.11.1	Measuring data 5-23E
5.11.2	Dump 5-25E
5.11.3	Output of settings 5-26E
5.11.4	Device status data 5-28E
5.11.5	Identity 5-29E
5.11.6	Interface test 5-29E
5.12	Reasons for service request 5-29E
5.13	SYSTEM 21 master function 5-31E
5.13.1	General 5-31E
5.13.2	Contact assignment of System 21 connector 5-32E
5.13.3	Addressing a message 5-32E
5.13.4	Commands 5-32E
6. GLOSSARIES	6-1E
6.1	Glossary of terms 6-1E
6.2	Short survey of program commands 6-3E
APPENDIX A 1S0-7 BIT CODING TABLE	A-1
APPENDIX B PROGRAM EXAMPLES	B-1

1. OPERATOR SAFETY

Read this page carefully before installation and use of the instrument.

1.1 GENERAL INFORMATION

The instrument described in this manual is designed to be used by properly-trained personnel only. Adjustment, maintenance and repair of the exposed equipment shall be carried out only by qualified personnel, who are aware of the hazards involved.

1.2 SAFETY PRECAUTIONS

For the correct and safe use of this instrument it is essential that both operating and service personnel follow generally-accepted safety procedures in addition to the safety precautions specified in this manual. Specific warning and caution statements, where they apply, will be found throughout the manual. Where necessary, the warning and caution statements and/or symbols are marked on the apparatus.

1.3 CAUTION AND WARNING STATEMENTS

CAUTION: is used to indicate correct operating or maintenance procedures in order to prevent damage to or destruction of the equipment or other property.

WARNING: calls attention to a potential danger that requires correct procedures or practices in order to prevent personnel injury.

1.4 SYMBOLS



Read the operating instructions.

Explanation of symbol

To preserve the instrument from damage the operator must refer to an explanation in the instruction manual.

1.5 IMPAIRED SAFETY PROTECTION

Whenever it is likely that safe operation is impaired, the instrument **must** be made inoperative and secured against any unintended operation. The appropriate servicing authority must then be informed.

2. GENERAL INFORMATION

2.1 INTRODUCTION

The PM2535 is a digital, automatic multimeter controlled by a microcomputer.

The instrument has the following capabilities:

- Standard multimeter functions
- Help functions
- Input of figures
- Extended capabilities via the IEC-625/IEEE-488 interface

The standard multimeter functions (white text) are:

- Direct voltages (V_{DC})
- Alternating voltages (V_{AC}) true RMS, ac coupled.
- Direct currents (A_{DC})
- Alternating currents (A_{AC}) true RMS, ac coupled.
- Resistance, in two-wire ($\Omega-2 W$) and four-wire ($\Omega-4 W$) configuration
- Temperature °C

Ranges can be selected manually, automatically or remote.

Beside the standard functions the user can alter the speed to increase the number of measurements per second, or to obtain a higher resolution.

The filter function switches in a frequency filter in the function V_{AC} and A_{AC} ; in all other functions (except °C) it acts as a digital filter.

Offset in the lowest dc range can be compensated by using the NULL function.

Measurements can be started with an internal, manual or external facility. External starting is possible via the trigger input, or via the IEC/IEEE-bus interface.

The help functions (green text) are:

- Mathematical functions, processing the measuring data such as:

$AX + B$
 $\Delta\%$
 dBm
 ZERO

- Acquisition/presentation of the measuring data such as:

DELAY, LIMITS, BURST.
 RD.BUF, MIN/MAX, LIMITS, DIGITS

- Function programming such as:

To store and call combinations of instrument settings. PROG, SEQU (SYSTEM 21)

- General

Beeper  on/off, CHECK, ENTER, CLR (CLEAR)

The input of figures (blue text)

0...9, polarity and decimal point

Extended capabilities via the IEC-625/IEEE-488 interface

All the manual controls are also possible via the interface.

The PM2535 is equipped with an internal guard, which is externally accessible. Therefore, very low levels with noise voltages can be measured with high accuracy.

2-2E

2.2 CHARACTERISTICS

2.2.1 Safety Characteristics

This apparatus has been designed and tested in accordance with Safety Class I requirements of IEC Publication 348, Safety Requirements for Electronic Measuring Apparatus and CSA 556B, and has been supplied in a safe condition.

This manual contains information and warnings which must be followed to ensure safe operation and to retain the instrument in a safe condition.

This instrument:

- satisfies the requirements of EEC Council Directive NO. 73/23 EEC in that it conforms with IEC Publication 348.
- is listed by the Canadian Standards Association as certified.
- is certified by the Independent German Testing and Approvals Institute VDE (and has been tested according to VDE 0411, Part 1).

2.2.2 Performance Characteristics

- Properties expressed in numerical values with stated tolerance are guaranteed by PHILIPS. Specified non-tolerance numerical values indicate those that could be **nominally** expected from the mean of a range of identical instruments.
- This specification is valid after the instrument has warmed up for 30 minutes (reference temperature 23 °C \pm 2 °C) to reach the 90 days accuracy. The warm-up time to reach the 24 hours specification is 2 hours.

2.2.3 Vdc

Ranges

300 mV, 3 V, 30 V, 300 V

Measuring modes:

Speed mode	Measuring speed (depending on measured value)	Nominal scale length	Resolution on 300 mV range
Speed 1	0.2 up to 0.3 meas/s	3 000 000	100 nV
Speed 2	2 up to 3 meas/s	300 000	1 μ V
Speed 3	20 up to 30 meas/s	30 000	10 μ V
Speed 4	>100 meas/s	3 000	100 μ V

Notes: - Stated measuring speed is excluding IEC/IEEE controller.

- At speed 1 display value will be updated within 0.5 s after a step-change of input signal.

Accuracy is given in:

\pm (% of reading + % of range) relative to calibration values

Speed mode	Range	Accuracy 24 h, tcal \pm 1 $^{\circ}$ C	Accuracy 90 days, tcal \pm 5 $^{\circ}$ C	Accuracy 1 year, tcal \pm 5 $^{\circ}$ C
Speed 1 and 2	300 mV	0.0025 + 0.0013*	0.007 + 0.0017*	0.012 + 0.0017*
	3 V	0.0020 + 0.0010	0.005 + 0.0013	0.010 + 0.0013
	30 V	0.0025 + 0.0013	0.006 + 0.0017	0.015 + 0.0017
	300 V	0.0025 + 0.0010	0.006 + 0.0013	0.010 + 0.0013
Speed 3	300 mV - 300 V	0.0033 + 0.0033	0.008 + 0.005	0.010 + 0.005
Speed 4	300 mV - 300 V	0.033 + 0.033	0.04 + 0.05	0.05 + 0.05

* valid when using "NULL".

Temperature coefficient in range outside tcal \pm 5 $^{\circ}$ C

\pm (0.002 % of reading + 0.0005 % of range)/K

Input impedance:

10 M Ω // 30 pF
at overload on 300 mV and 3 V ranges:
100 k Ω // 30 pF

Offset current in input:

<30 pA

2-4E

Series Mode Rejection:

	Mains frequency	
	50 or 60 Hz $\pm 0.1\%$ *	50 or 60 Hz $\pm 1\%$ *
Speed 1	>80 dB	>60 dB
Speed 2	>70 dB	>50 dB
Speed 3	>60 dB	>40 dB
Speed 4	0	0

* valid for 50 Hz or 60 Hz version respectively

Max. SM signal

Peak value 140 % of range

Common Mode Rejection

(measured with 1 k Ω unbalance, guard connected to CM voltage)

	DC signal	50 or 60 Hz $\pm 0.1\%$ *	50 or 60 Hz $\pm 1\%$ *
Speed 1	>140 dB	>160 dB	>140 dB
Speed 2	>140 dB	>150 dB	>130 dB
Speed 3	>140 dB	>140 dB	>120 dB
Speed 4	>140 dB	> 80 dB	> 80 dB

* valid for 50 Hz or 60 Hz version respectively

Max. CM voltage

250 Vac or dc, 350 Vpeak between "0" and guard
250 Vac or dc, 350 Vpeak between guard and ground

Response time (Filter off): (at single trigger first reading is within specified distance from final value when step-input and trigger command are given simultaneously).

	excl. ranging		incl.ranging *		digits from final value
	internal trigger	single trigger	internal trigger	single trigger	
Speed 1	<5.0 s	<4.4 s	<5.1 s	<5.1 s	50
Speed 2	<950 ms	<540 ms	<750 ms	<800 ms	10
Speed 3	<100 ms	< 50 ms	<210 ms	<220 ms	10
Speed 4	< 30 ms	< 15 ms	< 80 ms	< 80 ms	5

* Ranging over max. number of ranges.

Maximum input voltage

Ranges 300 mV and 3 V: 400 V for <30 s
300 V continuously
600 Vpeak
Ranges 30 V and 300 V: 400 V continuously
600 Vpeak
Max. allowable V.Hz product 10⁶

Zeroing

Offset voltage and thermal voltages on 300 mV range can be compensated via "NULL" pushbutton. Nulling range $\pm 100 \mu\text{V}$.

Filter

Digital filter can be switched on/off via "FILTER" pushbutton. Filter characteristic exponential with automatic reset after step change.

Clip indication

Signals clipping in input circuit during measuring cycle. Measuring cycle is normally finished and displayed including a warning symbol "↑".

2.2.4 Vac

Converter type AC-coupled RMS
 Ranges 300 mV, 3 V, 30 V, 300 V
 Frequency range Filter on 40 Hz - 100 kHz (default)
 Filter off 400 Hz - 100 kHz

Measuring modes:

Speed mode	Measuring speed (int trig) (depending on measured value)	Nominal scale length	Resolution on 300 mV range
Speed 2	2.2 up to 3 meas/s	30 000	10 μ V
Speed 3	20 up to 30 meas/s	3 000	100 μ V

Note: Stated measuring is excluding IEC/IEEE controller.

Accuracy is: Valid over 1-100 % of range;
 \pm (% of reading + % of range) relative to calibrated values

Speed 2 and 3	Frequency range	Accuracy 24 h, $t_{cal} \pm 1$ °C	Accuracy 90 days, $t_{cal} \pm 5$ °C	Accuracy 1 year, $t_{cal} \pm 5$ °C
Filter on	40 Hz - 5 kHz	0.1 + 0.1	0.2 + 0.1	0.3 + 0.1
Filter off	400 Hz - 5 kHz	0.1 + 0.1	0.2 + 0.1	0.3 + 0.1
Filter on and off	5 kHz - 100 kHz	(0.02 + 0.02)/kHz	(0.04 + 0.02)/kHz	(0.06 + 0.02)/kHz

Temperature coefficient in range outside $t_{cal} \pm 5$ °C ± 0.03 % of reading/K

Input impedance Ranges 300 mV and 3 V: 1.2 M Ω // 30 pF
 Ranges 30 V and 300 V: 0.93 M Ω // 30 pF

Common Mode Rejection (guard connected to "0" 1 k Ω unbalance) 120 dB for dc signals
 80 dB for ac signals of 50 Hz, decreasing with 20 dB/dec

Maximum CM voltage 250 Vac or dc, 350 Vpeak between "0" and guard
 250 Vac or dc, 350 Vpeak between guard and ground

Response time: (at single trigger first reading is within specified distance from final value when step-input and trigger command are given simultaneously).

	Excl. ranging				Incl. ranging				Digits from final value
	Filter on		Filter off		Filter on		Filter off		
	Trigger		Trigger		Trigger		Trigger		
	internal	single	internal	single	internal	single	internal	single	
Speed 2	<1.8 s	<1.5 s	<1.1 s	<650 ms	<2.1 s	<3.1 s	<1.3 s	<1.5 s	10
Speed 3	<0.9 s	<1.0 s	<200 ms	<200 ms	<1.7 s	<2.7 s	<800 ms	<900 ms	10

2-6E

Crest factor	>3.3 at full scale, increasing down scale by $3.3 \times \frac{\text{full scale}}{\text{reading}}$ with a maximum of 33. Warning on display when clipping occurs, by symbol "↑".
Maximum input voltage	All ranges 400 Vac or dc, 600 Vpeak.
Maximum V.Hz product	10 ⁷
Maximum dc voltage on input	400 V

2.2.5 Resistance (2-wire, 4-wire)

Input configuration	2-wire via "0" and "V-Ohm" 4-wire via PROBE
Ranges 2-wire	3 kΩ, 30 kΩ, 300 kΩ, 3 MΩ, 30 MΩ, 300 MΩ.
4-wire	3 kΩ, 30 kΩ, 300 kΩ, 3 MΩ.

Measuring modes:

Speed mode	Ranges	Measuring speed (depending on measured value)	Nominal scale length	Resolution
Speed 1	3 kΩ-3 MΩ 30 MΩ 300 MΩ	.2 up to .3 meas/s .2 up to .3 meas/s .2 up to .3 meas/s	3 000 000 300 000 30 000	1 mΩ - 1 Ω 100 Ω 10 kΩ
Speed 2	3 kΩ-3 MΩ 30 MΩ 300 MΩ	2 up to 3 meas/s 2 up to 3 meas/s 2 up to 3 meas/s	300 000 30 000 3 000	10 mΩ - 10 Ω 1 kΩ 100 kΩ
Speed 3	3 kΩ-3 MΩ 30 MΩ 300 MΩ	20 up to 30 meas/s 20 up to 30 meas/s 20 up to 30 meas/s	30 000 3 000 300	100 mΩ - 100 Ω 10 kΩ 1 MΩ
Speed 4	3 kΩ-300 kΩ	>65 meas/s	3 000	1 Ω - 100 Ω

Notes: - Stated measuring speed is excluding IEC/IEEE controller.
- At Speed 1 display value will be updated within 0.5 s after a step-change of input signal.

Accuracy is given in: ± (% of reading + % of range) relative to calibration values

Speed mode	Range	Accuracy 24 h, tcal ±1 °C	Accuracy 90 days, tcal ±5 °C	Accuracy 1 year, tcal ±5 °C
Speed 1, 2 and 3	3 kΩ - 300 kΩ	0.01 + 0.0033	0.02 + 0.0033	0.03 + 0.0033
	3 MΩ	0.02 + 0.0033	0.04 + 0.0033	0.05 + 0.0033
	30 MΩ	0.06 + 0.0033	0.10 + 0.0033	0.15 + 0.0033
Speed 4	300 MΩ	0.8 + 0.033	1.6 + 0.033	2.0 + 0.033
	3 kΩ-300 kΩ	0.033 + 0.033	0.05 + 0.033	0.06 + 0.033

Temperature coefficient in range outside:

$t_{cal} \pm 5 \text{ }^\circ\text{C}$

Ranges 3 k Ω - 3 M Ω
 30 M Ω
 300 M Ω

$\pm 0.005 \text{ \% of reading/K}$
 $\pm 0.02 \text{ \% of reading/K}$
 $\pm 0.05 \text{ \% of reading/K}$

Measuring current

1 mA at 3 k Ω down to 10 nA at 300 M Ω (non-linear)

Maximum lead resistance in 4-wire configuration

100 Ω

Maximum voltage at open input

<10 V

Polarity input sockets

"V- Ω " negative, "0" positive

Testing semiconductor junctions

Possible in forward (up to $V_f = 3 \text{ V}$) and reverse direction

Protection

2-wire terminals: up to 250 Vac or dc, 350 Vpeak
 4-wire terminals: up to 30 Vac or dc, 42 Vpeak

Common Mode voltage influence

(measured with "guard" and "0" connected to CM voltage)

Speed	DC signal	50 or 60 Hz $\pm 0.1 \text{ \%}$	50 or 60 Hz $\pm 1 \text{ \%}$
1, 2, 3	0.00002	0.00002	0.0002
4	0.002	0.01	0.01

Maximum CM voltage:

- 2-wire configuration

250 Vac or dc, 350 Vpeak between "0" and guard
 250 Vac or dc, 350 Vpeak between guard and ground

- 4-wire configuration

30 Vac or dc, 42 Vpeak between "0" and ground; guard must be connected to "0"

Response time: (filter off)

(at single trigger first reading is within specified distance from final value when step-input and trigger command are given simultaneously)

Speed Mode	Ranges	Excl. ranging		Incl. ranging		Digits from final value
		internal trigger	single trigger	internal trigger	single trigger	
Speed 1	3 k Ω - 3 M Ω	<5.0 s	<4.4 s	<5.2 s	<5.2 s	50
	30 M Ω	<5.2 s	<4.6 s	<5.6 s	<5.8 s	50
	300 M Ω	<5.5 s	<4.9 s	<5.8 s	<6.0 s	50
Speed 2	3 k Ω - 3 M Ω	<950 ms	<540 ms	<750 ms	<800 ms	10
	30 M Ω	<1.3 s	<700 ms	<1.1 s	<1.2 s	10
	300 M Ω	<2.0 s	<1.0 s	<1.3 s	<1.4 s	10
Speed 3	3 k Ω - 300 k Ω	<110 ms	< 60 ms	<220 ms	<230 ms	10
	3 M Ω	<140 ms	< 90 ms	<500 ms	<500 ms	10
	30 M Ω	<300 ms	<300 ms	<1.0 s	<1.0 s	10
	300 M Ω	<500 ms	<500 ms	<1.5 s	<1.5 s	10
Speed 4	3 k Ω - 300 k Ω	<40 ms	<25 ms	<90 ms	<90 ms	5

2-8E

Filter Digital filter can be switched on/off via "FILTER" pushbutton.
Filter characteristic: exponential with automatic reset after step change

Clip indication Signals clipping in input circuit during measuring cycle.
Measuring cycle is normally finished and displayed including a warning symbol "↑".

2.2.6 Idc

Ranges 30 mA, 3 A

Measuring modes:

Speed mode	Measuring speed (depending on measured value)	Nominal scale length	Resolution on 30 mA range
Speed 2	2 up to 3 meas/s	300 000	100 nA
Speed 3	20 up to 30 meas/s	30 000	1 μA
Speed 4	>100 meas/s	3 000	10 μA

Note: - stated measuring speed is excluding IEC/IEEE controller.

Accuracy is given in: ± (% of reading + % of range) relative to calibration values

Speed mode	Range	Accuracy 24 h, tcal ±1 °C	Accuracy 90 days, tcal ±5 °C	Accuracy 1 year, tcal ±5 °C
Speed 2 and 3	30 mA and 3 A			
	<1 A	0.01 + 0.005	0.03 + 0.005	0.05 + 0.005
	>1 A	0.1 + 0.01	0.15 + 0.01	0.2 + 0.01
Speed 4	30 mA and 3 A			
	<1 A	0.01 + 0.03	0.03 + 0.03	0.05 + 0.03
	>1 A	0.1 + 0.05	0.15 + 0.05	0.2 + 0.05

Temperature coefficient outside range tcal ±5 °C ± (0.005 % of reading + 0.001 % of range)/K

Voltage drop Range 30 mA <250 mV
Range 3 A <600 mV

Protection By fuse 3.15 AF
Up to 250 Vac or dc, 350 Vpeak.

Series Mode Rejection

	Mains frequency	
	50 or 60 Hz ±0.1 % *	50 or 60 Hz ±1 % *
Speed 2	>70 dB	>50 dB
Speed 3	>60 dB	>40 dB
Speed 4	0	0

* valid for 50 Hz or 60 Hz version respectively

Max. SM signal

Peak value 150 % of range

Common Mode voltage influence

± (% of range/V)

	DC signals	50 or 60 Hz ±0.1 % *	50 or 60 Hz ±1 % *
Speed 2, 3 Speed 4	0.00002 0.002	0.00002 0.01	0.0002 0.01

* valid for 50 Hz or 60 Hz respectively

Max. CM voltage

250 Vac or dc, 350 Vpeak between "0" and guard
250 Vac or dc, 350 Vpeak between guard and ground

Response time: (at single trigger first reading is within specified distance from final value when step-input and trigger command are given simultaneously)

	excl. ranging		incl.ranging		Digits
	internal trigger	single trigger	internal trigger	single trigger	from final value
Speed 2	<950 ms	<540 ms	<750 ms	<800 ms	10
Speed 3	<100 ms	<50 ms	<210 ms	<220 ms	10
Speed 4	<30 ms	<15 ms	<80 ms	<80 ms	5

Filter

Digital filter can be switched on/off via "FILTER" pushbutton.
Filter characteristic exponential with automatic reset at step change

Clip indication

Signals clipping in input circuit during measuring cycle.
Measuring cycle is normally finished and displayed including a warning symbol "↑".

2.2.7 Iac

Converter type

AC-coupled RMS, no DC component allowed.

Ranges

30 mA, 3 A

Frequency range

Filter on: 40 Hz - 1 kHz (default)
Filter off: 400 Hz - 1 kHz

Measuring modes:

Speed mode	Measuring speed (int trig) (depending on measured value)	Nominal scale length	Resolution on 30 mA range
Speed 2 Speed 3	2.2 up to 3 meas/s 20 up to 30 meas/s	30 000 3 000	1 µA 10 µA

Note: Stated measuring speed is excluding IEC/IEEE controller.

2-10E

Accuracy is:

Valid over 1-100 % of range;
 \pm (% of reading + % of range) relative to calibrated values

Speed 2 and 3	Frequency range	Accuracy 24 h, tcal ± 1 °C	Accuracy 90 days, tcal ± 5 °C	Accuracy 1 year, tcal ± 5 °C
Filter on	40 Hz - 1 kHz	0.1 + 0.1	0.2 + 0.1	0.3 + 0.1
Filter off	400 Hz - 1 kHz	0.1 + 0.1	0.2 + 0.1	0.3 + 0.1

Temperature coefficient in range outside
 tcal ± 5 °C

± 0.03 % of reading/K

Voltage drop

Range 30 mA <250 mV
 Range 3 A <600 mV

Protection

By fuse 3.15 AF
 Up to 250 Vac or dc, 350 Vpeak

Common Mode voltage
 influence

± 0.0001 % of range/V for DC signals
 ± 0.0001 % of range/V for AC signals up to 100 Hz

Maximum CM voltage

250 Vac or dc, 350 Vpeak between "0" and guard
 250 Vac or dc, 350 Vpeak between guard and ground

Response time: (filter off)

(at single trigger first reading is within specified distance from final value when step-input and trigger command are given simultaneously)

	Excl. ranging				Incl. ranging				Digits from final value
	Filter on		Filter off		Filter on		Filter off		
	Trigger		Trigger		Trigger		Trigger		
	internal	single	internal	single	internal	single	internal	single	
Speed 2	<1.8 s	<1.5 s	<1.1 s	<650 ms	<2.1 s	<3.1 s	<1.3 s	<1.5 s	10
Speed 3	<0.9 s	<1.0 s	<200 ms	<200 ms	<1.7 s	<2.7 s	<800 ms	<900 ms	10

Crest-factor

>3.3 at full scale, increasing down scale by
 $3.3 \times \frac{\text{full scale}}{\text{reading}}$ with maximum of 33.

Warning on display when clipping occurs, by symbol "↑".

2.2.8 Temperature (°C)

Measuring principle	Pt-100 probe, according to DIN 43760, in 4-wire configuration via PROBE input
Recommended probe	Philips PM 9249 (– 60 °C up to + 200 °C)
Range	– 100 °C up to 850 °C
Resolution	Speed 2: 0.1 °C Speed 3: 1 °C
Measuring current	1 mA
Linearisation	Probe characteristics according to DIN 43760 is linearised within stated accuracy limits
Accuracy	Excl. probe ± (0.3 % of reading + 0.2 °C)
Temperature coefficient	± (0.01 % of reading + 0.003 % of range)/K
Response time (excl. probe)	

	internal trig.	single trig.
Speed 2	< 750 ms	< 550 ms
Speed 3	< 75 ms	< 65 ms

Note: Stated measuring speed is excluding IEC/IEEE controller.

Max. voltage between "0" and guard	30 Vac or dc, 42 Vpeak
Max. voltage at probe tip	Depending on probe

2.2.9 Converter characteristics (of analog-to-digital converter)

Type of conversion	Linear
Operating principle	Integrating ADC
Commutation point	At the end of each representation unit
Basic mode of operation: - manually triggered - externally triggered	Via "SINGLE" pushbutton on front. In "SINGLE TRIGGER" mode via rear input "EXT TRIG" (BNC). Starting a measurement via the interface is possible in SINGLE TRIGGER mode.
- repetitive triggered	In "INT TRIGGER" mode a new measurement is started automatically after completing the previous one.
Range setting	Selectable between AUTO and MANUAL ranging - Manual with UP and DOWN switches - Automatic: • upranging at about 100 % of scale, 3 000/30 000/300 000/3 000 000 • downranging at about 9 % of scale, 270/2700/27 000/270 000
Polarity setting	Automatic setting on Vdc, Adc, °C, blanked in other functions

2-12E

Resolution
 1 : 3 000
 1 : 30 000
 1 : 300 000
 1 : 3 000 000
 depending on selected function, range and speed mode

Initial settings after power on or reset
 As stored in program 0. (PROG 0)

2.2.10 Time function

Input settling time
 Automatically adapted to obtain a correct measuring result when input signal and trigger signal are given simultaneously in Single Trigger mode

Sampling time

Speed \ Version	50 Hz	60 Hz
1, 2, 3 4	20 ms 2 ms	16 $\frac{2}{3}$ ms 2 ms

2.2.11 Input terminal arrangement

Number of sockets
 - 5x safe 4 mm terminals on removable input unit mounted in front; can also be mounted on rear (guard, 0 V- Ω , 0A, V- Ω , A).
 - 2x 8 pin DIN connectors for PROBE, one on front and one on rear. Only one socket accessible at a time.

Input configuration
 Asymmetrical, floating, guarded

Impedance between sockets

guard - ground	>10 G Ω // <1000 pF
guard - "0"	>10 G Ω // <1000 pF
"0" - ground	>20 G Ω // < 500 pF
"0" - V- Ω	} depending on function and range, see relevant spec. points.
"0" - A	
"0V- Ω " - "0A"	directly connected

Maximum voltage between input sockets

guard - ground	250 Vac or dc, 350 Vpeak
guard - "0"	250 Vac or dc, 350 Vpeak
"0" - ground	250 Vac or dc, 350 Vpeak
V- Ω - ground	450 Vac or dc, 600 Vpeak
A - "0"	250 Vac or dc, 350 Vpeak fuse protected (Imax. 3 A)
V- Ω - "0"	depending on function and range; see relevant specification

2.3 OPERATIONAL DATA

Warm-up time	30 minutes to reach specified 90 days accuracy 2 hours before calibration and for 24 h specification
Safety	According to IEC-348/VDE 0411 Safety Class I CSA 556-B
Mechanical characteristics	Dimensions: 280 x 210 x 86 mm Mass: 2.85 kg. Cabinet material: Aluminium case plastic front
Recalibration interval	1 year
Back-up battery life-time	5 years

2.3.1 Display

Visual representation

Number of digits	6.5, 5.5, 4.5, 3.5, depending on function, range and speed mode
Number of representation units	3 000 30 000 300 000 3 000 000 depending on function, range and speed mode
Means of representation of output value	7-segment, reflective LCD display, 9 mm
Polarity representation	Automatic indication of + or -, or blanked according to measured quantity
Decimal point representation	Indicated in LCD display
Means of function representation	Selected function is indicated in LCD via units indication and annunciators
Means of units representation	Via 16-segment characters in LCD; mV, V, Ω, kΩ, MΩ, μA, mA, °C
Overload representation	Display indicates "OL"
Indication of exceeding crest-factor or clipping input circuit	"↑" in LCD, measured value remains on display
Data hold	Possible in SINGLE TRIGGER mode via "SINGLE" pushbutton or EXT TRIG input on rear, or by using Data Hold Probe PM9267
Range hold	Possible via RANGING "AUT/MAN" switch
Acoustic representation	Signal is given: - at Vdc and Vac when overload occurs on 300 V range (cannot be switched off) - at Adc and Aac when overload occurs on 3 A range (cannot be switched off) - in the help-funtions (selectable)

2-14E

2.3.2 IEC/IEEE interface

IEC/IEEE interface

According to IEC-625, IEEE-488

See section 5.2. for specification

2.3.3 System 21 interface

Interface function

Master function System 21 bus

Connector type

9-pin female D-connector

Available supply

current 200 mA

2.3.4 External control

Remote programmable

Via IEC/IEEE-bus

External triggering

Via BNC on rear

- Trigger pulse negative-going, width >15 μ s
 H = +2.4 ... +20 V
 L = -20 ... +1 V

- By short-circuiting EXT TRIG input one measurement is performed.
 Recovery time >10 ms

- EXT TRIG input is protected up to 60 Vac or dc, 85 Vpeak

2.4 ENVIRONMENTAL CONDITIONS

General

The environmental data mentioned in this manual are based on the results of the manufacturer's checking procedures.

Details on these procedures and failure criteria are supplied on request by the PHILIPS organisation in your country, or by PHILIPS, INDUSTRIAL & ELECTRO-ACOUSTICAL EQUIPMENT DIVISION, EINDHOVEN, THE NETHERLANDS.

Operating conditions are specified according to IEC 359.

2.4.1 Climatic conditions

Group I with extension of the temperature limits

Temperature

Reference temperature

23 °C \pm 1 °C

Rated range of use

0 °C ... 50 °C

Limit range of operation

0 °C ... 55 °C

Limit range of storage and transport

-25 °C ... +70 °C

Humidity

Reference rel. hum.

45 - 75 % RH

Rated range of use

20 - 80 % RH (no condensation)

Limit range of operation

20 - 80 % RH

Limit range of storage and transport

5 - 95 % RH

Max. dew-point

25 °C

Barometric pressure

Rated range of use

70 kPa to 106 kPa (up to 2200 m)

Limit range for storage and transport

53.3 kPa to 106 kPa (up to 4300 m)

2.4.2 Mechanical conditions

Group 2

2.4.3 Line supply conditions

Group S2

Voltage

Reference value 230 V ± 1 %

Rated range of use 230 V ± 10 %

Note: Instrument can be altered internally for a nominal mains voltage of 115 V.

Frequency

Reference value 50 Hz ± 1 %

Rated range of use 50 Hz ± 1 %

Note: Instrument can be altered internally for a nominal mains frequency of 60 Hz

Interruptions

Interruption <10 ms: no influence
 >10 <500 ms: instrument may either restart or continue
 >500 ms: instrument will restart, condition equals situation as stored in program 0 (PROG 0).

2.4.4 Power consumption

Power consumption <20 VA

Electromagnetic compatibility

Conducted interference CISPR publ 11 and 14
 VDE 871-B and 875-K

Radiated interference VFG 1046/84

2.4.5 Accessories

Supplied with instrument: Measuring leads PM9266 (incl. probes)
 Mains supply cable
 Spare fuses
 Operating manual
 8-pin DIN connector

Optionally available

Specific accessories for PM2535 4-wire Ω cable PM9264/01
 Shielded measuring cable PM9265/01

Universal accessories

High frequency probe PM9210
 High frequency probe PM9213
 Current shunt PM9244
 Current transformer PM9245
 Current probe PM9101
 EHT probe PM9246
 Temp. probe (Pt-100) PM9249
 Data hold probe PM9267
 Rack mounting set PM9280/02

3. INSTALLATION INSTRUCTIONS

3.1 INITIAL INSPECTION

Check the contents of the shipment for completeness and note whether any damage has occurred during transport. If the contents are incomplete, or there is damage, a claim should be filed with the carrier immediately, and the Philips Sales or Service organisation should be notified in order to facilitate the repair or replacement of the instrument.

3.2 SAFETY INSTRUCTIONS

3.2.1 Earthing (Grounding)

Before any other connection is made, the instrument shall be connected to a protective earth conductor via the three-core mains cable.

The mains plug shall be inserted only into a socket outlet provided with a protective earth contact. The protective action shall not be negated by use of an extension cord without protective conductor.

WARNING: Any interruption of the protective conductor inside or outside the instrument, or disconnection of the protective earth terminal, is likely to make the instrument dangerous. Intentional interruption is prohibited.

3.2.2 Mains voltage setting and fuses

WARNING: The instrument shall be disconnected from all voltage sources when a fuse is to be renewed, or when the instrument is to be adapted to a different mains voltage.

- Before inserting the mains plug into the mains socket, make sure that the instrument is set to the local mains voltage.

Note: If the mains plug has to be adapted to the local situation it should only be done by a qualified person.



Figure 3.1 Mains fuse location

3-2E

- The instrument shall be set to the local mains voltage only by a qualified person who is aware of the hazards involved.
- Make sure that only fuses of the required current rating, and specified type are used for renewal. The use of repaired fuses, and/or the short-circuiting of fuse holders, is prohibited.
- Fuses shall only be renewed by a qualified person who is aware of the hazard involved.

Mains voltage

When despatched from the factory, the PM2535 is set to the local mains voltage of 230 V/50 Hz. For modification to 115 V, or for modification to 60 Hz refer to the service manual of this instrument.

Mains fuse

The mains fuse is located in a holder on the rear panel, adjacent to the mains socket. To replace it, first remove the mains cable and prise out the lift-out lug with a screwdriver.


3.3 OPERATING POSITION OF THE INSTRUMENT

- The instrument may not only be used in horizontal position, but can also be used in a sloping position by folding down the handle. The characteristics mentioned in section 2.2 are guaranteed for the normal (horizontal) position as well as for the sloping position or when the handle is folded down.
- Do not position the instrument on any surface which produces or radiates heat, or in direct sunlight.

3.4 19-INCH RACK-MOUNTING

The PM9280/02 is a rack-mounting set for mounting two instruments (e.g. 2x PM2535) into a 19-inch rack. If a PM2535 has to be built-in, the feet of the PM2535 must be removed. The instrument can be mounted in the rack and fastened with the screws, delivered with the rack-mounting set. (The holes of the PM2535, without the feet correspond to the holes (A) in the rack).

Remark: Donot use longer screws (M3X5) than supplied with the PM9280/02 to avoid short circuit between mains earth (screening) and guard.



4. OPERATING INSTRUCTIONS

4.1 GENERAL INFORMATION

This section outlines the procedures and precautions necessary for operation.

It is subdivided into three main parts viz:

- Manual operation (local) of the PM2535

This part identifies and briefly describes the functions of the front and rear panel controls and indicators. It also explains the practical aspects of operation to enable an operator to evaluate quickly the instrument's main functions.

- Operation via a IEEE controller (Remote)


This section describes how to operate the instrument in a IEEE-488/IEC-625 configuration via a controller. It gives a detailed description of the functions, input and output data.

- Operation in combination with System 21

This section describes the practical use of the PM2535, in which the master function of System 21 is already included.

4.2 SWITCHING-ON

The instrument may be switched "ON" after making sure that the installation instructions, described in Section 3 have been followed.



Having switched on, the PM2535 is immediately ready for use. After a warm-up time of 30 minutes the instrument meets the specifications listed in Section 2 (90 days specification).

Note: To meet the specifications use a shielded low thermal voltage cable. Recommended cable: PM9265/01

4-2E




ST4741

The initial states after Power On are as stored in program 0 (PROG 0).
At delivery the following settings are stored:

Front	Via IEC-625/IEEE-488 interface
Function : V ₋₋₋	FNC_VDC
Range : AUTO	RNG_AUTO
Measuring speed : 2	MSP_2
Resolution : 6	RSL_6
Filter : Off	FIL_OFF
Internal settling time : On	IST_ON
Trigger : Internal	TRG_I
Delay : Off, 0	DLY_OFF,0
Display : On	DSP_ON
Null : Off	OUT_S
Calibration : Off	NUL_OFF
dBm : Off, 600Ω	CAL_OFF
Δ% : Off, +1	DBM_OFF, +600
AX + B : Off, +1,0	PRC_OFF, 1
Limits : Off, 0,0	SCL_OFF, +1,0
Relative Reference : Off, 0	LIM_OFF, 0,0
Burst : Off, 999	ZER_OFF, 0
Digits : 7	BUR_OFF, 999
Beeper : On	DIG_7
Sequence : Off	BLP_ON
	SEQ_OFF
In the sequence program	
AID 20M0	-----
DSP 1.0S	-----
ST00 P.E	-----
	} Not possible via the bus

Remark: It is possible to enter all delivery settings from the internal ROM into program 0 (PROG 0) by pressing the test-switch inside the instrument and meanwhile resetting the instrument.
(Refer to the Service Manual)

4.3 DISPLAY INDICATIONS



ST4902
860324

IEC-625/IEEE-488 messages

REM	Remote
LSTN	Listener
TLK	Talker
TLK ONLY	Talk only
SRQ	Service request, instrument asks service

} IEC-625/IEEE-488 interface messages

Bleeper function on on > limit, Buffer full in BURST mode

- SHIFT** Keyboard shift function indication. Functions indicated by the arrows (blue, green) are valid.
- LIM** Limits mode indication. The limit function is active.
- Δ%** Deviation in % indication. In this function the display indicates the Δ% from a preprogrammed value.
- CAL** Calibration mode on
- AX + B** Scaled measurements indication. In this function the measured value (X) is scaled via AX + B and displayed.
- MIN**
MAX Minimum/Maximum indication. This function displays the minimum and maximum value.
- READ** Read buffer indication
In this function a stored block of measuring data in the result buffer can be read out.
- BURST** Burst function indication.
A preprogrammed number of measurements is stored in the buffer.
- SEQU** Sequence function indication. In this function a preprogrammed sequence of measurements is carried out on a preprogrammed address and channel number. The sequence function can be used in combination with system 21.
- DELAY** Delay function indication. This function introduces a programmable delay between a trigger and the actual start of measurement.
- ZERO** Relative Reference mode.
- SET** Indication that figures must be entered.

4-4E


- ▼ (gn) Helpfunction indication, green text is valid
- ▼ (bl) Input of figures indication, blue text is valid
- ⊠ ⊠ Messages/Unit indication mV, V, Ω, A etc.
- 2W 4W** Configuration indication for OHM
 2W = 2 wire via banana sockets
 4W = 4 wire via probe input
- ^ High limit exceed
- v Lo limit exceed
- ~ ac/dc indication; ~ in functions V~, A~
 --- in function V---, A---
- PROBE** Message: This function needs a probe
- HOLD** Data hold indication, in combination with a DATA HOLD probe.
- NULL** Zero point correction indication (V---, 300 mV)
- FILT** Filter on indication; 40 Hz in functions V~, A~.
 Digital filter in functions V---, A---, Ω-2W, Ω-4W.
- SPEED** Measuring speed indication
 1234
- S TRG** Single trigger indication
- M RNG** Manual ranging indication
- ÷ Polarity indication e.g. in functions: V---, A---, ZERO SET, °C
- ↑ Clip (V---, A---) or Crestfactor V~, A~) overflow



ST4903
860307

- Result indication in the multimeter function
- Message indication in the help functions.

4.4 KEYBOARD



HOW TO OPERATE THE KEYBOARD

The functions can be subdivided into three categories

1. Multimeter functions (white) - The indication is situated **above** the keys.
 - Direct operation, press once and the function is chosen.
2. Help functions (green) - The indication is situated in the first line **under** the keys.
 - ▼ Arrow on display
 - points to green square. - Operation after pressing the SHIFT key.
3. Input of figures (blue) - The indication is situated **under** the key in the **second** line
 - ▼ Arrow on display
 - points to blue square - The input of figures is automatically requested in the relevant help functions
 - The input of figures can be cleared (CLR key)
 - The input must be terminated with the ENTER key

The selected functions from categories 1 and 2 are indicated in the display.

The arrows in the display point to the actual category (colour). Some key functions are active in categories 2 and 3. This is indicated with a blue line under the green text.

4.4.1 Multimeter functions, direct action (white).

FUNCTION	Selects the measurement functions (V ₋₋₋ , V _~ , etc)
RANGING	A selection can be made between manual (M RNG on display) or automatic ranging. The UP and DOWN buttons are used to range.
TRIGGER	A selection can be made between internal and single trigger (external trigger via BNC connector on the rear). The single trigger mode is indicated with S TRG on the display.
SPEED	Measuring speed 1,2,3, or 4 can be selected. (The default speed setting is always speed 2).
FILTER	On/off for ac filter in alternating current/voltage measuring functions or digital filter for all (except °C) other functions.
NULL	On/off for offset correction in V ₋₋₋ , 300 mV. (NULL on display)
SHIFT	SHIFT key to enable selection of the help functions (green)
CAL	The calibration mode (pencil-point operation) can be enabled. (Refer to the service manual of this instrument)
RESET	Pushbutton (pencil-point operation) to reset to initial state. The initial state is the state stored under program 0. (PROG 0)


4-6E

4.4.2 Help functions (green)

4.4.2.1 Function programming

- PROG In the PROG (program) function all relevant instrument settings can be stored under a certain number. At recall of that number the PM2535 will assume these settings.
- SEQU In the SEQU (sequence) function a number of sequential steps is carried out. Each step is a preprogrammed instrument setting with the possibility of outputting information for system 21 (scanning function).

4.4.2.2 General

- CLR CLEAR selectively switches - off a help function (green), or clears mistaken entry at input of figures (blue).
-  Switches on/off the bleeper.
- CHECK Selection of the IEEE 488/IEC-625 parameters, the selfdiagnostic mode or the calibration mode is possible.
- ENTER Enter function for all data and figures to be input

4.4.2.3 Mathematical functions (measuring data will be processed)

Remark: A measuring function selection will switch-off the mathematical help function selected to avoid mistakes. The stored variables will be saved. The mathematical functions switch off each other except dBm and ZERO.

AX + B Scaled measurement function. The instrument will ask the values A and B for calculating. The measured value is adapted according to the formula AX + B.

dBm dBm (0dB 1mW) function. The instrument will ask the reference resistor value. The dB value is calculated according $20 \log \frac{X}{U_{ref}}$

Δ% Deviation in % function. The instrument will ask the value from which Δ% has to be calculated.

displayed value $\frac{X - C}{C} \times 100 \%$

ZERO Relative reference
From the measured value (X) the contents of the Zero register is subtracted (X - D) and displayed. The instrument asks the value for the Zero register (D).

4.4.2.4 Aquisition/presentation of the measuring data

- DELAY Delay function. A delay can be programmed between a trigger command and the actual start of a measurement.
The instrument will request the delay time in milliseconds
- LIMITS In the limit function, a Lo and Hi limit can be programmed. If a limit is exceeded an indication will be given e.g. via the IEEE-448/IEC-625 interface, or display, and bleeper.
- BURST If the BURST function is selected, N measuring results (N can be selected) are stored in a buffer after a trigger command. A "full" indication is given in the display and a bleeper signal, after completing. If the BURST function is not selected, the last measuring results (max. 999) are stored in the buffer continuously.
- RD.BUF The buffer contents filled in the BURST on or off mode can be read on the display or via the IEC-625/IEEE-488 interface. Outputting of location numbers is also possible.

- MIN/MAX The instrument compares continuously the measured value with the contents of the minimum (MIN) and maximum (MAX) registers. The lowest and highest values are stored. Via MIN/MAX these values can be read out and also cleared if desired.
- DIGITS In this function the display length can be programmed.


4.4.2.5 *Input of figures (blue)*

- + - 0/9 ● In the help functions figures have to be input for parameters. Filling the display goes from left to right.

At selection of a help function the old parameters are shown first. If no change is wanted ENTER can be pressed.

With the CLR key a mistaken entry of figures can be cleared

4.4.3 **Inputs**



When measuring voltages, resistance or currents the corresponding 0-socket function must be used. Although these 0-sockets have the same potential, incorrect use could result in measuring deviations.

4.4.4 **Guard Usage**

The PM2535 is equipped with a GUARD. This is an additional shield between the "0" input and earth. The GUARD increases the leakage impedance.

Increasing the leakage impedance improves the common mode rejection.

The GUARD may be connected to the circuit via a separate lead. Proper use of the GUARD provides a better common mode rejection and a higher accuracy, especially in the most sensitive ranges.


The guard can be connected via the switch to the 0-socket.

For an optimum GUARD connection, the following rules should be taken into account:

- * Connect the signal to be measured to the PM2535 by means of a shielded measuring cable. This cable should not run in parallel to heavy current cables.
- * Connect the GUARD to the same potential as the "0" input terminal.
- * Connect the GUARD in such a way that no current due to common mode voltage flows through any source impedance.


Note: The guard must always be connected.

4-8E



ST4742E

4.5 REAR PANEL CONTROLS



ST4847

SYSTEM 21
CONNECTOR FOR SYSTEM 21
(FOR INFO REFER TO : SECTION 5.13)

IEEE - 488/IEC - 625
CONNECTOR FOR IEEE - 488/IEC - 625 INTERFACE
(FOR INFO REFER TO SECTION 5 AND INSTRUCTION CARD)

4.6 DETAILED MULTIMETER FUNCTIONS EXPLANATION

4.6.1 Function selection


With the function keys the various functions can be selected.
The relevant measuring function is indicated on the display with unit indication and indices.

FUNCTION



4.6.2 Ranging

RANGING



Manual or automatic ranging is available for all functions (except °C). Selection between the modes can be made by pressing the AUT/MAN pushbutton.
Manual ranging is indicated with M RNG on the display.

To range, proceed as follows:

EXAMPLE	OPERATION	DISPLAY
Select range 300V _{DC}	<input type="checkbox"/> V _{DC} <input type="checkbox"/> AUT/MAN	+ 000.000 mV _{DC} MRNG SPEED 2
	<input type="checkbox"/> UP <input type="checkbox"/> UP <input type="checkbox"/> UP	+ 000.000 V _{DC} MRNG SPEED 2
Select range 3V _{DC} (from range 300V _{DC})	<input type="checkbox"/> DOWN <input type="checkbox"/> DOWN	+ 0.00000 V _{DC} MRNG SPEED 2
Autoranging (from manual)	<input type="checkbox"/> AUT/MAN or <input type="checkbox"/> X	+ 000.000 mV _{DC} SPEED 2

- Auto
- UP ranging at > 300000 dig.
 - DOWN ranging at ≤ 27000 dig.

To eliminate the hysteresis in the automatic range selection, a higher or lower range can be selected by means of the Up-Down key.



Remark: Selecting another measuring function will set the instrument to AUTO RANGING.

4-10E

4.6.3 Trigger

The trigger mode is divided into two trigger modes:

- Internal trigger mode
- Single trigger mode



A measurement is started automatically after completing a previous one.

A measurement can be started:

- Manual:
 - Pressing the SINGLE pushbutton performs one measurement. (In the automatic ranging mode first, if necessary, the correct range is selected and the new measurement is performed and displayed)
- External:
 - Via the the TRIGGER BNC connector at the rear of the PM2535
 A measurement is started by making this input low. (short-circuit or logic signal)





 Note: The EXT start input is galvanically separated from the measuring circuit.
 - Via the IEC-625/IEEE-488 bus interface (see section 5.5.7).
 - Via PM9267 Data Hold probe.

EXAMPLE	OPERATION	DISPLAY
Single trigger		+ ---.--- mV STRG SPEED 2
		+ 000.000 mV STRG SPEED 2
		+ ---.--- mV STRG SPEED 2
		+ 000.000 mV STRG SPEED 2
	<p>EXTERNAL</p>	+ ---.--- mV STRG SPEED 2
		+ 000.000 mV STRG SPEED 2
Internal trigger (after single trigger)		+ 000.000 mV SPEED 2

Remark: In Single Trigger mode the display shows ----- as long as no new result is available after a trigger command.

4.6.4 Speed

The speed button selects the measuring speed and measuring resolution. In the display, speeds 1, 2, 3 or 4 are indicated.

EXAMPLE	OPERATION	DISPLAY
Select range 300V _{DC}		+ 000.000 mV _{DC} SPEED 2
	 	+ 0000.0 mV _{DC} SPEED 4
Speed selection		

The possibilities are as follows.

Function	Speed	Ranges	Speed meas/s up to	Display length up to
V _{DC}	1	all	0.3	3000000
	2	all	3	300000
	3	all	30	30000
	4	all	100	3000
V _{AC}	2	all	3	30000
	3	all	30	3000
Ω 2-,4-wire (4-w max 3 MΩ)	1	3 kΩ-3 MΩ	0.3	3000000
		30 MΩ	0.3	300000
		300 MΩ	0.3	30000
	2	3 kΩ-3 MΩ	3	300000
	30 MΩ	3	30000	
	300 MΩ	3	3000	
3	3 kΩ-3 MΩ	30	30000	
	30 MΩ	30	3000	
	300 MΩ	30	300	
4		3 kΩ-300 kΩ	65	3000
A _{DC}	2	all	3	300000
	3	all	30	30000
	4	all	100	3000
A _{AC}	2	all	3	30000
	3	all	30	3000
°C	2	all		3000
	3	all		300

- Remarks:
- Stated measuring speed excludes the time needed by the IEEE/IEC controller to perform the handshake. It is valid for a 50 Hz version.
 - In speed 1, the display value will be updated within 0.5 s after a step change of the input signal.

4-12E

4.6.5 Filter




The front-panel FILTER pushbutton brings a filter into circuit, indicated in the display as FILT. There are two possibilities:

1. Digital filter in the functions $V_{\text{---}}$, $A_{\text{---}}$, Ω -2 wire and Ω -4 wire. If the filter is switched on in these functions, the display result is determined by the following formula:

$$\text{display result} / 0.8 \times \text{previous result} + 0.2 \times \text{actual measurement}$$

If the difference between the actual measurement and the previous result is too large, then the display result is equal to the actual result. When one of the above mentioned functions is selected the filter will always be in the off state.




2. In the function V_{\sim} and A_{\sim} a low pass frequency filter can be switched on. The bottom of the measurable frequency range is shifted from 40 Hz (filter on) to 400 Hz (filter off).
If filter off is selected, the response time of the different ac measuring functions is decreased. When V_{\sim} or A_{\sim} is selected, the filter will always be in the on state. (40 Hz)

EXAMPLE	OPERATION	DISPLAY
Switch on digital filter in $V_{\text{---}}$	 	+ 000.000 mV ₋₋₋ SPEED 2 FILT
Filter-off (after on)		+ 000.000 mV ₋₋₋ SPEED 2

4.6.6 Null




The function can be switched on/off in speed 1, 2, 3 (speed 4 excluded) for zero-point correction to compensate offset and thermal voltages of max. 1000 digits in the 300 mV dc range. To compensate offset and thermal voltages short-circuit the input with the **measuring** leads. (recommended cable: shielded low thermal voltage cable PM9265/01).

Pushing Null will automatically select speed 1 to obtain the NULL value. The function active mode is indicated in the display as NULL and is only active for speeds 1, 2 and 3 in the 300 mV dc range.

EXAMPLE	OPERATION	DISPLAY
Switch on null mode in $V_{\text{---}}$ (short cct input, autoranging)	 	+ NULL mV ₋₋₋ SPEED 1
		+ 000.0000 mV ₋₋₋ SPEED 1 NULL
Null mode off (after on)		+ 000.0000 mV ₋₋₋ SPEED 1

Note: After Power On the function is not activated, unless stored in program 0 (PROG 0). However, once activated the state and value is kept in memory even if the $V_{\text{---}}$, 300 mV range is left. Selecting $V_{\text{---}}$, 300 mV range again will switch on the Null function. To enter a new NULL value, first the previous value has to be switched off.

4.6.7 Selfdiagnostics (CHECK, ENTER keys)

EXAMPLE	OPERATION	DISPLAY
<p>Switch on the Selfdiagnostic mode</p>		<p>test 0</p>
		<p>test 1</p>
		<p>SOFT 0X</p>
		<p>Display test</p>
		<p>test O.k.</p>

In case of an error refer to the service manual

Remark: - Via the CHECK button also the following IEC-625/IEEE-488 bus parameters can be set:

- REMOTE/LOCAL
- TALK ONLY
- IEC/IEEE ADDRESS

Refer to chapter 5 how to proceed.

- The Selfdiagnostics mode cannot be switched on in the Calibration, Burst and Sequence function. The entering of the test parameter will be skipped.

4.6.8 Reset

The RESET switch (pencil-point operation to avoid an unwanted reset) is used to give a reset. The instrument jumps to its initial state. All the functions are selected that are also valid after a power-on.

4.6.9 Calibration

Via the CAL switch (pencil-point operation) the electronic calibration mode is enabled. While pressing the CAL switch the RESET switch must be pressed. Release the RESET switch before releasing the CAL switch (cal on display).

The calibration mode is entered after pushing the SHIFT, CHECK button.

In the calibration mode the separate functions and ranges can be calibrated successively. The new calibration values are stored in a non-volatile RAM. The calibration mode is left with the SHIFT, CLR push button and disabled with the RESET switch.


For detailed calibration information refer to the service manual of the PM2535.

4-14E

4.7 MEASURING FUNCTIONS EXPLANATION

The measuring functions, available on the PM2535 are selected by the appropriate function switch. Having selected the required function, further actions that are necessary are referred to in the following quick-check measuring procedure.

4.7.1 Direct voltage measurements



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*	*	*	*	*		*	*) ¹	*

)¹ 300 mV only

Range	Speed	1	2	3	4
	300 mV		300.0000	300.000	300.00
3 V		3.000000	3.00000	3.0000	3.000
30 V		30.00000	30.0000	30.000	30.00
300 V		300.0000	300.000	300.00	300.0

Remarks:


Maximum input voltage

Range: 300 mV/3 V 400 V for <30 s
 300 V continuously
 600 V peak

30 V/300 V 400 V continuously
 600 V peak

Warning indications Audible: max. input voltage exceeded
 Visual: ↑ Clip indication
 OL Overload

4.7.2 Alternating voltage measurements



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*		*	*		*			*

└ 40 Hz or 400 Hz

Range	Speed	
	2	3
300 mV	300.00	300.0
3 V	3.0000	3.000
30 V	30.000	30.00
300 V	300.00	300.0

Remarks: Maximum input voltage

All ranges


400 V ac or 400 Vdc
continuously
600 V peak

Warning indications

Audible: >300 V in 300 V range
Visual: Crest factor exceeded
OL Overload

4-16E

4.7.3 Resistance two-wire measurements



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*	*	*	*	*		*		*

Range	Speed	1	2	3	4
	3 kΩ		3.000000	3.00000	3.0000
30 kΩ		30.00000	30.0000	30.000	30.00
300 kΩ		300.0000	300.000	300.00	300.0
3 MΩ		3.000000	3.00000	3.0000	--
30 MΩ		30.0000	30.000	30.00	--
300 MΩ		300.00	300.0	300.0	--

Remarks:


Protection

2-wire terminals
250 V ac or dc
350 V peak

Warning indications

Visual: ↑ Clip indication
OL Overload.

4.7.4 Resistance four-wire measurements



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*	*	*	*	*		*		*

Range	Speed			
	1	2	3	4
3 k Ω	3.000000	3.00000	3.0000	3.000
30 k Ω	30.00000	30.0000	30.000	30.00
300 k Ω	300.0000	300.000	300.00	300.0
3 M Ω	3.000000	3.00000	3.0000	--

Remarks:

Protection

4-wire terminals
30 V ac or dc
continuously
42 V peak


Warning indications

Visual: ↑ Clip indication
OL Overload.

4-18E

4.7.5 Direct current measurement

Remark:
Closing the guard switch with external guard connection introduces measuring errors.



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*		*	*	*		*		*

Range	Speed	2	3	4
30 mA		30.0000	30.000	30.00
3 A		3.00000	3.0000	3.000

Remarks:

Protection


With a fuse of
3.15 A (fast blow)

Warning indications

Visual: ↑ Clip indication
OL Overload
Audible: >3 A in 3 A range

4.7.6 Alternating current measurements

Remark:
Closing the guard switch with external guard connection introduces measuring errors.



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
*	*	*	*	*		*	*		*			*

↳ 40 Hz or 400 Hz

Range	Speed	
	2	3
30 mA	30.000	30.00
3 A	3.0000	3.000

Remarks:

Protection

With a fuse of 3.15 A (fast blow)


Warning indications

Visual: ↑ Crest factor exceeded
OL overload

Audible: >3 A in 3 A range

4-20E

4.7.7 Temperature measurements



Valid modes

Ranging			Trigger		Speed				Filter		Null	Check/
Down	Up	Aut/Man	INT	Single	1	2	3	4	Freq	Dig		End
			*	*		*	*					*

Range	Speed 2	Speed 3
- 100 °C up to 850 °C	3000.0	3000

Linearisation according to DIN 43760 is valid up to 850 °C.

Remark: Remove temperature probe when measuring in other function than °C.

4.7.8 Clipping- Crest- factor indication

Measuring dc voltages or currents with spikes can give an incorrect reading. The reading appears to be good but due to spikes the input circuit is overloaded and the reading is incorrect. The PM2535 indicates this with a ↑ on the display.

When the display shows ↑, a higher range must be selected until the ↑ disappears.

Example:




ST4744

If a spike exceeds a level of 1,5x full scale value the clip indication is displayed.

In V~ or A~ the ↑ symbol is used to indicate that the max. allowable crest-factor has been exceeded.

4.8 HELP FUNCTIONS EXPLANATION

4.8.1 Mathematical functions explanations



4.8.1.1 AX + B scaled measurements

The measured value (x) is adapted according to the formula AX + B, A and B can be input via keyboard or interface

- Valid in function : All multimeter functions (cannot be combined with other mathematic functions)
- Selection : SHIFT, AX + B, ENTER, ENTER
- Input parameters : A (no dimension)
: B (in units of measuring function)
- Output : AX + B
- Exit : SHIFT, CLR, AX + B, or function change
- Exit saves : A, B
- Function change saves : A, B
- Power off/reset destroys : A, B, unless stored in program 0—9 (PROG).

- Limits for A : ± (10¹³....10⁻¹³)
Input via keyboard
± (9999999....0000001)

- Limits for B : ± (10¹³....10⁻¹³)
Input via keyboard
Numerical value
± (9999999 .0000001)

- Delivered from factory on : A = +1, B = 0

Brief application AX + B

Calculation from °C → °F

Formula $\frac{9}{5} \text{°C} + 32 = \text{°F}$

Enter $A = \frac{9}{5} = 1.8$

Enter $B = 32$

$100 \text{ °C} = A X + B = 1.8 \times 100 + 32 = 212 \text{ °F}$

$0 \text{ °C} = A X + B = 1.8 \times 0 + 32 = 32 \text{ °F}$

4-22E

EXAMPLE 1	OPERATION	DISPLAY
ENTER	°C	+ 020.0 °C SPEED 2 PROBE
	SHIFT AX+B	- 32.00000 A SPEED 2 ▼ (bl) PROBE
	+ 1 8	+ 1.8 A SPEED 2 ▼ (bl) PROBE
	ENTER	+ 22.23344 B SPEED 2 ▼ (bl)
	+ 3 2	+ 32 B SPEED 2 ▼ (bl) PROBE
ENTER	+ 68.00000 *C SPEED 2 PROBE	

- ① Previous value for A.
- ② Enter A. Remark. Press "CLR" key to clear mistaken entry.
- ③ Previous value for B.
- ④ Enter B. Remark: Press "CLR" key to clear mistaken entry.
- ⑤ After the next measurement AX + B is calculated and displayed.

EXAMPLE 2	OPERATION	DISPLAY
CHECK A AND B	SHIFT AX+B	+ 1.80000 A SPEED 2 ▼ (bl) PROBE
	ENTER	+ 32.00000 B SPEED 2 ▼ (bl) PROBE
	ENTER	+ 68.00000 *C SPEED 2 PROBE

- ① A = +1.8.
- ② B = +32.
- ③ After the next measurement AX + B is calculated and displayed.













4.8.1.2 dBm

The measured input voltage (\sim or \dots) can be converted into a dB value (0 dBm \pm 1 mW in a selectable reference resistor). The reference resistor value can be chosen and stored. It must lie between .0001 and 9999 Ω . At delivery the resistance value is 600 Ω .








At measuring overload, OL will appear on the display. At shortcircuited input "UL" which means "dB-underload" will appear on the display.

The calculated result is presented with two figures behind the decimal point. If the calculated result is small, only 1 or zero figures may be presented behind the decimal point.

Valid	: V_{\dots} , V_{\sim} (can be combined with ZERO)
Selection	: SHIFT, dBm, ENTER
Input parameter	: reference resistance, initial 600 Ω
Output	: dBm
Exit	: SHIFT, CLR, dBm or function change
Exit saves	: Rref.
Function change saves	: Rref.
Power off/reset destroys	: Rref. unless stored in program 0—9 (PROG).
Limits for Rref	: .0001 \rightarrow 9999 Ω

EXAMPLE 1	OPERATION	DISPLAY
ENTER 50 Ω R REF IN FUNCTION V_{\dots}	  	600.0 Ω   ① SPEED 2 ∇ (bl)
	 	50 Ω   ② SPEED 2 ∇ (bl)
		+ 10.00 dB V_{\dots}   ③ SPEED 2

- ① Previous value for Rref.
- ② Enter Rref. Remark: Press "CLR" key to clear a mistaken entry.
- ③ After the next measurement dBm with 50 Ω R ref in V_{\dots} is calculated and displayed.

EXAMPLE 2	OPERATION	DISPLAY
CHECK R REF IN V_{\dots}	 	50.00 Ω   ① SPEED 2 ∇ (bl)
		+ 10.00 dB V_{\dots}   ② SPEED 2

- ① Previous value for Rref.
- ② After the next measurement dBm with 50 Ω R ref in V_{\dots} is calculated and displayed.

4-24E

4.8.1.3 Δ %

The measured value (X) is adapted according to the formula $\frac{X - C}{C} \times 100 \%$

Example: a. input = 10V (reference) Δ = 0V = 0%
 b. input = 11V Δ = +1V = 10%

$$\Delta\% = \frac{X - C}{C} \times 100\% = \frac{X - 10}{10} \times 100 \%$$






a. input 10V = $\frac{10 - 10}{10} \times 100\% = +0\%$

b. input 11V = $\frac{11 - 10}{10} \times 100\% = +10\%$

- Valid in function : All multimeter functions (cannot be combined with other mathematical functions).
- Selection : SHIFT, Δ %, ENTER
- Input parameter : C
- Output : $\frac{X - C}{C} \times 100\%$
- Exit : SHIFT, CLR, Δ % or function change
- Exit destroys : C
- Function changes destroys : C
- Power off/reset destroys : C, unless stored in program 0—9 (PROG).
- Limits for C : ± (10¹³...10⁻¹³) 0 excluded
Numerical value
± (9999999 .0000001)
- Delivered from factory on : C = + 1

EXAMPLE 1	OPERATION	DISPLAY
ENTER C = 10V _{DC}		+ 000.0000 mV _{DC} SPEED 2
		+ 000.0000 mV _{DC} SPEED 2 ▼ (bl)
		10000 mV _{DC} SPEED 2 ▼ (bl)
		+ 10.00000% V _{DC} SPEED 2 ▼ (bl)

- ① Last measured value on display. Press enter to use this value for parameter of C.
- ② Enter C. Remark: Press "CLR" key to clear mistaken entry.
- ③ After the next measurement $\frac{X - C}{C} \times 100\%$ is calculated and displayed. + 11V will generate + 10%.

EXAMPLE 2	OPERATION	DISPLAY
CHECK C WHEN IN FUNCTION Δ%	SHIFT Δ%	+ 10000.00 mV _{DC}   SPEED 2 ▼ (bl) 
	ENTER	+ 10.00000 %V _{DC}  SPEED 2 











- ① Previous value for C.
- ② After the next measurement $\frac{X-C}{C} \times 100\%$ is calculated and displayed. + 11V will generate + 10%.

4.8.1.4 ZERO (Relative reference)

From the measured value (X) the contents of the ZERO register (D) is subtracted (X-D) and displayed.

Example: a. input = +10V ZERO = 0V
 b. input = +11V ZERO = +1V
 ZERO = X-D = X-10V
 a. input = 10V = 10 - 10 = 0V
 b. input = 11V = 11 - 10 = +1V


- Valid : All multimeterfunctions, dBm (cannot be combined with other mathematical functions)
- Selection : SHIFT, ZERO, ENTER
- Input parameter : D
- Output : X - D
- Exit : SHIFT, CLR, ZERO or function change
- Exit destroys : D
- Function change destroys : D, ZERO function.
- Power off/reset destroys : D unless stored in program 0—9 (PROG)
- Limits for D : ± (10¹³...10⁻¹³)
 Input via keyboard
 ±(9999999 .0000001)

EXAMPLE 1	OPERATION	DISPLAY
ENTER D = 10V	V _{DC}	+ 000.000 mV _{DC}  SPEED 2
	SHIFT ZERO	+ 000.000 mV _{DC}   SPEED 2 ▼ (bl)  
	+ 1 0 0 0 0	10000 mV _{DC}   SPEED 2 ▼ (bl)  
	ENTER	+ 01.0000 V _{DC}  SPEED 2

- ① Last measured value on display. Press ENTER to use this value for parameter of D.
- ② Enter D. Remark: Press "CLR" key to clear mistaken entry.
- ③ After the next measurement X - D is calculated and displayed. + 11V will generate + 1 V


4-26E

4.8.2 Aquisition/ Presentation of measuring data



4.8.2.1 DELAY

A delay can be programmed between a trigger and the actual start of a measurement.



- Valid : All multimeter and mathematical functions
- Selection : SHIFT, DELAY
- Input parameter : X ms
- Result : delay of x ms
- Exit : SHIFT, CLR, DELAY
- Exit saves : delay
- Function changes saves : delay
- Power off/reset destroys : delay unless stored in program 0—9 (PROG).
- Limits for delay : 8 000 000 ms
- Delivered from factory on : Delay off, time 0 ms

EXAMPLE 1	OPERATION	DISPLAY
PROGRAM 140ms DELAY	SHIFT DELAY	84320 ms SPEED 2 ▼ (bl) SHIFT DELAY SET
	1 4 0	140 ms SPEED 2 ▼ (bl) SHIFT DELAY SET
	ENTER	10.0000 XX SPEED 2 DELAY

- ① Previous value for delay.
- ② Enter delay 140 ms Remark: Press CLR key to clear a mistaken entry.
- ③ After a trigger a delay of 140 ms will be executed before the measurement is started.

EXAMPLE 2	OPERATION	DISPLAY
READ DELAY	SHIFT DELAY	140 ms SPEED 2 ▼ (bl) SHIFT DELAY SET
	ENTER	10.0000 XX SPEED 2 DELAY

- ① Pre-programmed delay.
- ② After a trigger a delay of 140 ms will be executed before the measurement is started.

4.8.2.2 LIMITS

The measured or calculated results are compared with the contents of the LIM-LO and LIM-Hi registers. If the Limits values are exceeded an indication is given on the display by arrows (\wedge , \vee or $\hat{\vee}$) and by a bleeper signal if switched on, or via the IEC-625/IEEE-488 interface.

Valid in function	: All
Selection	: SHIFT, LIMITS
Input parameter	: LIM-LO (indicated by \vee) LIM-HI (indicated by \wedge)
Result	: indication that Limits are exceeded. (\wedge , \vee , $\hat{\vee}$, bleeper or interface)
Exit	: SHIFT, CLR, LIMITS, or function change
Exit saves	: LIM-LO, LIM-HI
Function change saves	: LIM-LO, LIM-HI
Power off/reset destroys	: LIM-LO, LIM-HI unless stored in program 0—9 (PROG).
Limit indication	: LIM-LO < LIM-HI and input < LIM-LO \wedge LIM-LO < LIM-HI and input > LIM-HI \vee LIM-LO \geq LIM-HI and input < LIM-LO, > LIM-HI $\hat{\vee}$



Limits for LIM-LO | LIM-LO and LIM-HI | \pm (10¹³...10⁻¹³)

Delivered from factory on LIM-LO = 0
LIM-HI = 0

EXAMPLE 1	OPERATION	DISPLAY
ENTER LIM-LO = +126.5645	SHIFT LIMITS	+ 83.26241 mV \vee ①
	+ 1 2 6 . 5 6 4 5 ENTER	+ 126.5645 mV \vee ②
		+ 336.356 mV \wedge ③
	LIM-HI = +320.3651	+ 320.3651 mV \wedge ④
	+ 100.000 mV SPEED 2	

- ① \vee = LIM LO Previous value for LIM-LO
- ② Enter LIM LO Remark: Press CLR key to clear mistaken entry
- ③ \wedge = LIM-HI Previous value for LIM-HI
- ④ Enter LIM-HI Remark: Press CLR to clear mistaken entry

4-28E



ST4905
860324

EXAMPLE 2	OPERATION	DISPLAY
CHECK LIM-LO AND LIM-HI REGISTERS	SHIFT LIMITS	+ 126.5645 mV _{TRMS} ^v SHIFT LIM SET ①
	ENTER	+ 320.3651 mV _{TRMS} [^] SHIFT LIM SET ①
	ENTER	+ 100.000 mV _{TRMS} LIM ②

- ① v = LIM-LO
- ② ^ = LIM-HI

4.8.2.3 BURST

In the BURST function a preprogrammed number (N, max 999) of measurements are stored in a buffer after a trigger command. A buffer full indication is given on the display and via the IEC-625/IEEE-488 interface. The stored measuring results can be read on the display or via the interface in the Read Buffer fuction (RD.BUF).

BURST ON MODE

The burst on mode can be selected via the keyboard or interface. The PM2535 will ask for the number of measurement results (N) to be buffered.

When (N) is entered the PM2535 will wait for a trigger command (single or internal).

- In single trigger mode the measuring process is stopped after (N) measurements. The PM2535 will wait for the next trigger.

After (N) measurements a full indication is given by means of:

Beeper (if switched on)

Display (FULL.)


Interface (DAV 1)

During the BURST process only the display will be refreshed about twice a second with the latest measurement result.

No interface output will be available during the BURST cycles.

The measuring results are buffered and can be read out in the RD.BUF function.

A function change will clear the buffer contents, but the BURST function stays on.



- 0 = Empty
- 1 = First result after trigger
- 82 = Last result entered.
- N = Number of results to be stored (BURST ON function)
- Max. = Maximum locations number = 999
- RD. BUF. pointer = Location to be read

Valid in function	:	All functions except SEQUENCE
Selection	:	SHIFT, BURST (PM2535 set to STRG)
Input parameter	:	N (number of measurements to be buffered).
Result	:	N measurements buffered.
Exit	:	SHIFT, CLR, BURST
Exit destroys	:	Contents of buffer
Exit saves	:	N, Single trigger
Function change destroys	:	Contents of buffer
saves	:	N, Single trigger
Power off/reset destroys	:	Contents of buffer, N
saves	:	N can be stored in program 0 (prog 0)

BURST-OFF MODE (normal measurement)


In the burst-off mode the last measured samples are present in the buffer, with a maximum of 999.

A function change (measuring or mathematical) will clear the buffer contents except in the sequence function (SEQU).

In the SEQU function the program number is also stored.

Reading the buffer can be done at any moment in the RD.BUF. function

The normal measuring process is stopped during reading. There is no buffer full-indication.



- 0 = Actual measurement
- 1 = Last measurement carried out
- 95 = First measurement after function change
- Max. = Maximum locations number = 999
- Function change = Last function change
- RD. BUF. pointer = Location to be read at the moment of RD.BUF mode selection

- Valid in function : ALL
- Selection : Power on
- Result : 999 measuring results stored
in 999 out
window
- Function change destroys : Contents of buffer
- saves : N
- Power of/reset destroys : Contents of buffer
- saves : N can be stored in program 0—9 (PROG).

EXAMPLE 1	OPERATION	DISPLAY
BUFFER 10 MEASUREMENT RESULTS	SHIFT BURST	NO. 500 S TRG SPEED 2 ▾ (bl) SHIFT BURST SET
	1 0	NO. 10 S TRG SPEED 2 SHIFT BURST SET
	ENTER	+ _____ V BURST
	SINGLE	FULL BURST

EXAMPLE 2	OPERATION	DISPLAY
CHECK NUMBER OF MEASURING RESULTS TO BE BUFFERED (N)	SHIFT BURST	NO. 10 S TRG SPEED 2 ▾ (bl) SHIFT BURST SET
	ENTER	+ _____ V BURST

- ① Previous value for number of measurements (N) to be buffered. The single trigger mode is automatically selected.
- ② Enter 10 (N). Remark: Press CLR key to clear mistaken entry.
- ③ After a trigger (N) measuring results are buffered.
- ④ If (N) is reached a buffer full indication is given.
- ⑤ (N) = 10
- ⑥ After a trigger (N) measuring results are buffered.

4.8.2.4 RD. BUF (Read buffer)

In the RD. BUF function, the buffer contents stored in the BURST ON/OFF function can be read.

The measurement results are stored together with a buffer location number. When selecting RD.BUF first the PM2535 asks if the contents of the locations have to be sent to a listen-only IEC-625/IEEE-488 printer. If yes (1). The next step allows reading locations.


By entering a location number, on the display or interface another location can be read. After the next ENTER, the print mode including the handshaking is set, and the contents of the selected location number is displayed and sent to the printer.

With the keys ▲ and ▼ the RD. BUF pointer can be moved to check the contents of the buffer. The stepping is possible in the location number mode and the measuring result display mode. If the keys are held for 1 second the checking is performed automatically. Stop this by pushing the arrows once more. The reading speed is 1 result per second in print off mode. In print on mode the printer determines the speed.

Dependent on the BURST ON/OFF mode the location number are preceded with "-" or blank.

BURST ON, RD.BUF.

- Location numbers are preceded with a "blank".
- After activating SHIFT, RD. BUF. the last measuring result will be displayed.




- 0 = Empty
- 1 = First result after trigger
- 82 = Last result entered.
- N = Number of result to be stored (BURST ON function)
- Max. = Maximum locations number = 999
- RD. BUF. pointer = Location to be read

- Valid in function = BURST
- Selection = SHIFT, RD. BUF., if BURST is on
- Input parameter = Location number 1 - 999
- Print on/off = Print on/off
- ▲ (UP)
- ▼ (DOWN)
- Output = Contents of buffer location number
- Exit = CLR, RD.BUF
- CLR, BURST
- Exit destroys = Contents of buffer
- Power off/reset destroys = Contents of buffer, N
- N can be stored in program 0 (prog 0)
- N is related to the BURST ON function

The stepping is possible in the location number mode and the measuring result display mode.

BURST OFF, RD.BUF.

- Location number is preceded with a "-"
- Start of reading is the last measurement.




























- | | | |
|-----------------|-----------------|--|
| Max | Function change | RD.BUF. pointer |
| -0 | = | Actual measurement |
| -1 | = | Last measurement carried out |
| -95 | = | First measurement after function change |
| max | = | maximum locations number = 999 |
| Function change | = | Last function change |
| RD.BUF. pointer | = | Location to be read at the moment of RD.BUF mode selection |

- | | | |
|--------------------------|---|---------------------------------------|
| Valid in function | : | All multimeter function |
| Selection | : | SHIFT, RD. BUF |
| Input parameter | : | Location number 1 - 999 |
| | | Print on/off |
| | | ▲ (UP) |
| | | ▼ (DOWN) |
| Output | : | Contents of buffer location number |
| Exit | : | CLR, RD. BUF |
| Exit destroys | : | Contents of buffer |
| saves | : | N |
| Power off/reset destroys | : | Contents of buffer |
| saves | : | N can be stored in program 0—9 (PROG) |


EXAMPLE 1	OPERATION	DISPLAY
FIRST CARRY OUT EXAMPLE 1 OF THE BURST MODE (CHAPTER 4.8.2.3) READ BUFFER LOCATION 5 IN THE BURST ON MODE IN FUNCTION V_~ (NO PRINT OUT)	<input type="button" value="SHIFT"/> <input type="button" value="RD. BUF"/>	<div style="display: flex; justify-content: space-between;"> <div> PRINT 0 S TRG SPEED 2 ▼ (bl) </div> <div style="text-align: right;"> SHIFT READ BURST SET </div> </div>
	<input type="button" value="ENTER"/>	<div style="display: flex; justify-content: space-between;"> <div> NO. 10 S TRG SPEED 2 ▼ (bl) </div> <div style="text-align: right;"> SHIFT READ BURST SET </div> </div>
	<input type="button" value="5"/>	<div style="display: flex; justify-content: space-between;"> <div> NO. 5 S TRG SPEED 2 ▼ (bl) </div> <div style="text-align: right;"> SHIFT READ BURST SET </div> </div>
	<input type="button" value="ENTER"/>	<div style="display: flex; justify-content: space-between;"> <div> + 10.0000 V S TRG SPEED 2 ▼ (bl) </div> <div style="text-align: right;"> SHIFT READ BURST </div> </div>

- ① If contents of buffer location has to be print-out on a IEC 625/IEEEE 488 listen only printer enter "1".
- ② Most recent loaded buffer location (N = 10).
- ③ Enter buffer location 5. Remark: Press CLR key to clear mistaken entry.
- ④ Contents of buffer location no. 5.

EXAMPLE 2	OPERATION	DISPLAY
<p>• FIRST CARRY OUT EXAMPLE 1 OF THE BURST MODE (CHAPTER 4.8.2.3)</p> <p>PRINT OUT ALL LOADED BUFFER LOCATIONS IN BURST ON MODE, FUNCTION V_{TR} (IEC-625/IEEE-488) LISTEN ONLY PRINTER)</p> <p>• SET THE PM2535 TO TALK ONLY MODE VIA SHIFT, CHECK, ENTER 1, ENTER CHAPTER 5.4.3.</p>	 	TLK ONLY      PRINT 0 S TRG SPEED 2 ▼ (bl)
	 	TLK ONLY      PRINT 1 S TRG SPEED 2 ▼ (bl)
		TLK ONLY      NO. 10 S TRG SPEED 2 ▼ (bl)
		TLK ONLY     + 120.450 V_{TR} S TRG SPEED 2 ▼ (bl)




















- ① Print mode can be entered 0 = no printing (default) 1 = printing
- ② Print mode on. Remark: Press CLR key to clear mistaken entry.
- ③ Most recent loaded buffer location (N = 10).
- ④ Contents of buffer location no. 10 is displayed and sent to the printer
 With ▼ or ▲ can be stepped through the buffer location contents (no location indication).
 1 x press = 1 step (print-out) 1,5s press = auto step Stop = 1 x press ▲ of ▼
 The printer will determine the stepping speed.
 The end of the block of locations is indicated with "END" on the display.

Buffer contents




- 0 = empty
- 1 = first result after trigger
- 82 = last result entered
- N = number of results to be stored (burst on function).
- Max = maximum number of locations (999).
- Rd. buf pointer = location to be read.

4-34E

EXAMPLE 3	OPERATION	DISPLAY
READ BUFFER LOCATIONS STEP BY STEP IN BURST ON MODE, FUNCTION V_{TRG} (NO PRINT OUT) FIRST CARRY OUT EXAMPLE 1 OF THE BURST MODE (CHAPTER 4.8.2.3)	 	PRINT 0 S TRG SPEED 2 ▼ (bl)      ①
	 	+ 10.0000 V_{TRG} S TRG SPEED 2 ▼ (bl)     ②
	 	+ 120.450 V_{TRG} S TRG SPEED 2 ▼ (bl)     ③

- ① Most recent loaded buffer location.
- ② Contents of buffer location no. 10
- ③ With ▼ or ▲ can be stepped. Through the buffer locations contents (no location indication).
 1 x press = 1 step 1,5s press = auto step with 1s delay Stop = 1 x press ▲ of ▼
 The end of the block of locations is indicated with "END" on the display.

Buffer contents



- 0 = empty
- 1 = first result after trigger
- 82 = last result entered
- N = number of results to be stored (burst on function).
- Max = maximum number of locations (999).
- Rd. buf pointer = location to be read.


4.8.2.5 MIN/MAX

The function minimum/maximum is continuously updating the extreme values of the measuring results. The minimum and maximum measurement result including the processed data are stored in the minimum and maximum registers within one function. Via the MIN/MAX keys the stored values can be read.

During reading the measuring of the minimum and maximum values is continued. If a new extreme is measured it will be immediately displayed.

- Valid in function : All
- Selection : SHIFT, MIN/MAX
- Result : Display minimum
Display maximum
- Exit : ENTER
- Exit saves : Contents of MIN/MAX registers
- Function change destroys : Contents of MIN/MAX registers (when MIN/MAX is not selected)
- Power off/reset destroys : Contents of MIN/MAX registers
- Clearing MIN/MAX registers : - Press CLR when MIN/MAX is switched on
- First exit the MIN/MAX function and press SHIFT, CLR, MIN/MAX

Example: Measurement of minimum and maximum temperatures (MIN/MAX thermometer)



EXAMPLE 1	OPERATION	DISPLAY
READ MINIMUM AND MAXIMUM TEMPERATURE. (FUNCTION °C WITH THE PT100 PROBE PM9249)		+ 025.0 °C SHIFT SPEED 2 PROBE
	<div style="display: flex; justify-content: space-around; border: 1px solid black; padding: 2px;"> SHIFT MIN MAX </div>	+ 015.0 °C SHIFT SPEED 2 ▼ (bl) PROBE MIN
	<div style="display: flex; justify-content: space-around; border: 1px solid black; padding: 2px;"> MIN MAX </div>	+ 030.0 °C MAX SPEED 2 ▼ (bl) PROBE
	<div style="display: flex; justify-content: space-around; border: 1px solid black; padding: 2px;"> ENTER </div>	+ 025.0 °C SPEED 2 PROBE

- ① Present value
- ② Minimum value.
- ③ Maximum value.
- ④ New measuring value. While reading, the PM2535 keeps on measuring. The new results are compared with the "OLD" values and refreshed.

4-36E

4.8.2.6 DIGITS (Display format function)

Independent of other settings the maximum display length can be set.






The number of digits "d" can be programmed ($0 \leq d \leq 7$). The displayed result is never longer than the measuring result of the function selected. If the number of figures in front of the decimal point is larger than "d", small zeros will be displayed up to the decimal point (significant blanks).

In exponent notation DIGITS are only related to the mantisse. The exponent will be displayed independent of the DIGITS function.

The DIGITS function is independent of the DISPLAY function, that can be used via the IEC-625/IEEE-488 interface.


e.g. Programmed 2 digits in $V_{\text{---}}$
 Display e.g. + 12._____ $V_{\text{---}}$
 Display + 200._____ $V_{\text{---}}$ in stead of + 20

- Valid in function : All
- Selection : SHIFT, DIGITS
- Input parameter : Number of digits "d"
- Result : Modified display length "d"
- Exit : ENTER
- Function change saves : "d"
- Power off/reset destroys : "d", unless stored in program 0—9 (PROG).
- Delivered from factory on : "d" = 7

EXAMPLE 1	OPERATION	DISPLAY
PROGRAM MAX. DISPLAY LENGTH 3 DIGITS	SHIFT DIGITS	DIG 7 SPEED 2 ▼ (bl)   ①
	3 ENTER	DIG 3 SPEED 2 ▼ (bl)   ②
	ENTER	+ 12.3 $V_{\text{---}}$ SPEED 2  ③

- ① Previous programmed digits
- ② Enter 3 digits.
Remark: Press CLR key to clear mistaken entry.
- ③ All following measurements a display length of 3 is valid.

4.8.3 FUNCTION PROGRAMMING



PROG **SEQU**

4.8.3.1 PROG function (PROGRAM)








Instrument settings including process functions and constants, can be stored under a program number (except rtl, tonly, address, test, MSR, SPR). The settings can be recalled (manual, via interface or in the sequence function) to set the instrument in predefined modes/functions. The maximum number of programs is 10 (0-9)

The settings stored in P0 will be automatically taken over by the PM2535 at power on or reset

- Valid in function : All
- Selection : SHIFT, PROG
- Input parameters : Program recall number PX (X = 0-9)
Program store number PX
- Result : Instrument settings stored in PX
- Exit : ENTER
- Exit saves : Settings PX
- Function change saves : Settings PX
- Power off/reset saves : Settings P0-P9

EXAMPLE 1	OPERATION	DISPLAY
STORE ACTUAL INSTRUMENT SETTINGS IN P0		 STRG SPEED 2
	SHIFT PROG	 PrcL - STRG SPEED 2 ▼ (bl)
	PROG	 PSTo - STRG SPEED 2 ▼ (bl)
	0	 PSTo 0 STRG SPEED 2 ▼ (bl)
	ENTER	ACTUAL MEASUREMENT

- ① Actual settings to be stored.
- ② Program recall. No = prog. Yes = enter P number.
- ③ Programm store ? Enter P number.
- ④ Enter P number 0.
- ⑤ Instrument settings are stored in P1.

EXAMPLE 2	OPERATION	DISPLAY
CARRY OUT PROGRAM SETTINGS OF P0	SHIFT PROG	PrcL - SPEED 2 ▼ (bl)  
	0	PrcL 0 SPEED 2 ▼ (bl)  
	ENTER	-----*V...  STRG SPEED 2  

- ① Programm to recall ?
- ② Enter P number 0.
- ③ Setting of P0 are carried out.

Remark: At power on or reset the settings programmed in P0 are automatically selected.

4.8.3.2 Sequence

The sequence function enables the PM2535 to carry out a number of sequential steps with different instrument settings as stored in the PROGRAM function.

At the same time control data can be output to System 21 modules in the System 21 scan function. In this case the PM2535 with system 21 modules can be used as stand-alone system (without controller).

The scan function (available only in some units) is used for the sequential select of inputs, switches, channels. A scan-cycle can be executed over channels of several units on the condition that:

- All units are of the same PM-number.
- All units are set for the same operating mode (see the System 21 manual and the operating cards of the slave units).
- No unit is in Execute Unconditional mode.
- The units have successive addresses with settings starting at 0.

The scan is initiated by the PM2535. The execution is automatically done with a number of execute commands or triggers in system 21 equal to the number of channels to be scanned. Under the above conditions a scan cycle will start with the lowest channel number of the unit with address-switch set to zero and continue along all channels and units.

Programming the Sequence function is only possible via the front keys.
(via IEC/IEEE interface is not implemented)

After pressing the SHIFT-SEQU keys the display asks "Run?".
With ENTER the sequence program will start.

The load-program mode is entered with SHIFT, SEQU, SEQU.
Sequentially a number of System 21 related questions have to be answered and entered.
After that, step numbers will be displayed, starting at step 0 (st 00).
The maximum number of steps is 99.

Every step has to be linked with the PROG number (instrument settings) wanted. The programming of the PROG numbers has to be made in the PROG function (refer to 4.8.3.1).

With "n" (" +/—" key) a PROG number can be skipped.
A number of steps can be terminated with "E" (". " key), the sequence will start again on step 00.


It is not possible to carry out BURST measurements.
A stored BURST-ON in a PROG number will be ignored in the PROG function.

Different from the normal measuring modes the buffer is not cleared in the sequence function. In this way it is possible store measurement results with different settings. Checking afterwards is possible because the PROG number has also been stored.

During execution of the sequence program only the keys SHIFT, CLR, SEQU and SINGLE TRIGGER and function rtl (return to local) are active.

The execution can be stopped with SHIFT, CLR, SEQU

4.8.3 FUNCTION PROGRAMMING



PROG **SEQU**

4.8.3.1 PROG function (PROGRAM)







Instrument settings including process functions and constants, can be stored under a program number (except rtl, tonly, address, test, MSR, SPR). The settings can be recalled (manual, via interface or in the sequence function) to set the instrument in predefined modes/functions. The maximum number of programs is 10 (0-9)

The settings stored in P0 will be automatically taken over by the PM2535 at power on or reset

- Valid in function : All
- Selection : SHIFT, PROG
- Input parameters : Program recall number PX (X = 0-9)
Program store number PX
- Result : Instrument settings stored in PX
- Exit : ENTER
- Exit saves : Settings PX
- Function change saves : Settings PX
- Power off/reset saves : Settings P0-P9

EXAMPLE 1	OPERATION	DISPLAY
STORE ACTUAL INSTRUMENT SETTINGS IN P0		 STRG SPEED 2
	SHIFT PROG	 Pr c L - STRG SPEED 2 ▾ (bl)
	PROG	 P S To - * V... STRG SPEED 2 ▾ (bl)
	0	 P S To 0 * V... STRG SPEED 2 ▾ (bl)
	ENTER	 ACTUAL MEASUREMENT

- ① Actual settings to be stored.
- ② Program recall. No = prog. Yes = enter P number.
- ③ Programm store ? Enter P number.
- ④ Enter P number 0.
- ⑤ Instrument settings are stored in P1.

EXAMPLE 2	OPERATION	DISPLAY
CARRY OUT PROGRAM SETTINGS OF P0	SHIFT PROG	PrcL - SPEED 2 ▼ (bl)  SHIFT  ①
	0	PrcL 0 SPEED 2 ▼ (bl)  SHIFT  ②
	ENTER	-----*V...  AX + B STRG SPEED 2  DELAY ③

- ① Programm to recall ?
- ② Enter P number 0.
- ③ Setting of P0 are carried out.

Remark: At power on or reset the settings programmed in P0 are automatically selected.

4.8.3.2 Sequence

The sequence function enables the PM2535 to carry out a number of sequential steps with different instrument settings as stored in the PROGRAM function.

At the same time control data can be output to System 21 modules in the System 21 scan function. In this case the PM2535 with system 21 modules can be used as stand-alone system (without controller).

The scan function (available only in some units) is used for the sequential select of inputs, switches, channels. A scan-cycle can be executed over channels of several units on the condition that:

- All units are of the same PM-number.
- All units are set for the same operating mode (see the System 21 manual and the operating cards of the slave units).
- No unit is in Execute Unconditional mode.
- The units have successive addresses with settings starting at 0.

The scan is initiated by the PM2535. The execution is automatically done with a number of execute commands or triggers in system 21 equal to the number of channels to be scanned. Under the above conditions a scan cycle will start with the lowest channel number of the unit with address-switch set to zero and continue along all channels and units.

Programming the Sequence function is only possible via the front keys.
(via IEC/IEEE interface is not implemented)

After pressing the SHIFT-SEQU keys the display asks "Run?".
With ENTER the sequence program will start.

The load-program mode is entered with SHIFT, SEQU, SEQU.
Sequentially a number of System 21 related questions have to be answered and entered.
After that, step numbers will be displayed, starting at step 0 (st 00).
The maximum number of steps is 99.

Every step has to be linked with the PROG number (instrument settings) wanted. The programming of the PROG numbers has to be made in the PROG function (refer to 4.8.3.1).

With "n" (" + / - " key) a PROG number can be skipped.
A number of steps can be terminated with "E" (". " key), the sequence will start again on step 00.

It is not possible to carry out BURST measurements.
A stored BURST-ON in a PROG number will be ignored in the PROG function.

























Different from the normal measuring modes the buffer is not cleared in the sequence function. In this way it is possible store measurement results with different settings. Checking afterwards is possible because the PROG number has also been stored.

During execution of the sequence program only the keys SHIFT, CLR, SEQU and SINGLE TRIGGER and function rtl (return to local) are active.

The execution can be stopped with SHIFT, CLR, SEQU






Valid in function : All
 Selection of execution : SHIFT, SEQU, ENTER
 Selection of programming : SHIFT, SEQU, SEQU
 Input parameters at programming : Srun
 : Aid (system 21 module type)
 : M (system 21 module mode) dsp (display time)
 : ST00 P. (program number at step xx)
 Result : - Sequential steps of program settings
 : - scan function for System 21
 Stop. Execution : SHIFT, CLR, SEQU
 Exit : ENTER
 Exit saves : P0-P9
 Function change saves : P0-P9
 Power off/reset saves : P0-P9

Enter the next in the prog. function: P0 = V_{\sim} Internal trigger. Speed 2. Auto ranging.
 : P1 = $\Omega 2W$. Internal trigger. Speed 2. Auto ranging.
 : P2 = V_{\sim} . Internal trigger. Speed 2. Auto ranging.



EXAMPLE 1	OPERATION	DISPLAY
<p>Enter the following sequence program</p> <p>STEP0 . Set PM2535 to setting of P2 . Display result for 5s.</p> <p>STEP1 . Skip settings of P1.</p> <p>STEP2 . Set PM2535 to setting of P0 . Display result for 5s.</p> <p>STEP3 . Terminate the program and return.</p> <p>This program can be used for a stand alone PM2535.</p> <p>A shorter program is:</p> <p>STEP0 P2.DSP 5s STEP1 P0.DSP 5s STEP2 TERMINATE</p> <p>To perform a step in the sequence-run mode the PM2535 needs to be Internal of single triggered.</p>		 <p>Srun SPEED 2 ▼ (bl)</p>  ①
		 <p>AidxxMx SPEED 2 ▼ (bl)</p>  ②
		 <p>dSP 1.5s SPEED 2 ▼ (bl)</p>  ③
		 <p>dSP 5.0s SPEED 2 ▼ (bl)</p>  ④
		 <p>ST.00 P6 SPEED 2 ▼ (bl)</p>  ⑤
		 <p>ST.00 P2 SPEED 2 ▼ (bl)</p>  ⑥
		 <p>ST.01 P6 SPEED 2 ▼ (bl)</p>  ⑦
		 <p>ST.01 Pn SPEED 2 ▼ (bl)</p>  ⑧






- ① PM2535 asks to run the sequence program. Enter = yes. SEQU = no = programming mode.
- ② PM2535 asks two parameters for system 21 use (Type.Mode). Press ENTER to continue.
- ③ PM2535 asks you for display time. (1.5s = previous display time).
- ④ Enter 5 seconds.
- ⑤ PM2535 asks P number (P6 = previous P number). PM2535 will start to ask with step 00. Maximum number of steps = 99
- ⑥ Enter 2 on step 3.
- ⑦ PM2535 asks P number (P6 = previous P number). Enter " - " on step 1. " - " = the PM2535 will not measure.
- ⑧ Enter " - " on step 01 to skip (n = displayed)

4-40E

EXAMPLE 1 (cont.)	OPERATION	DISPLAY
	ENTER	ST.02 P6 SPEED 2 ▼ (bl)  SHIFT SEQ SET ⑨
	0	ST.02 P0 SPEED 2 ▼ (bl)  SHIFT SEQ SET ⑩
	ENTER	ST.03 P6 SPEED 2 ▼ (bl)  SHIFT SEQ SET ⑪
	.	ST.03 PE SPEED 2 ▼ (bl)  SHIFT SEQ SET ⑫
	ENTER	+ 12.34567 SPEED 2  V _{DC} ⑬

- ⑨ PM2535 asks P number (P6 = previous P number)
- ⑩ Enter 0 step 02
- ⑪ PM2535 asks P number (P6 = previous number)
- ⑫ Enter. on step 03 to terminate (E = displayed)
- ⑬ Actual-measurement

EXAMPLE 2	OPERATION	DISPLAY
Start (run) a Sequence program (refer to example program). To perform a step in the sequence-run mode, the PM2535 needs to be triggered internal or single	SHIFT SEQU	Srun ▼ (bl)  SHIFT SET SEQ
	ENTER	+ 000.0000 mV SPEED 2  SHIFT

EXAMPLE 3	OPERATION	DISPLAY
<p>Make a program using the scan function of system 21. Suppose one PM2121 that has to be set to mode "M1" is used.</p> <p>Use the program of example 1</p> <p>Total sequence program</p> <p>STEP 0. P2 settings. System 21 scan step (PM2121, M1) Display result for 5s</p> <p>STEP 1. PN System 21 scan step (PM2121.M1)</p> <p>STEP 2. P0 settings System 21 scan step (PM2121.M1) Display result for 5s</p> <p>STEP 3. PE (terminator)</p>  <p>Remarks- A system PM2121, M1 scan consists of 20 scan steps per slave connected. - With a programmed delay (chapter 4.8.2.1) a waiting loop between closing the PM2121 relay contact and the start measuring of the PM2535 can be inserted.</p>	<p>SHIFT SEQU SEQU</p>	<p>Aid 20 M0 (bl) ▼</p> 
	<p>2 1</p>	<p>Aid 21 M— ▼ (bl)</p> 
	<p>1</p>	<p>Aid 21 M1 ▼ (bl)</p> 
	<p>ENTER</p>	<p>dSP 5.0s ▼ (bl)</p> 
	<p>continue with example 1</p>	

- ① PM2535 asks slave type connected to perform the scan function
- ② Press: 21 (PM21 [21])
- ③ Enter: mode "M1"
- ④ PM2535 asks display time.

4-42E

4.9 GENERAL

4.9.1 Bleeper



The built in bleeper can be switched on or off for a number of functions.
 For some alarm functions the bleeper cannot be switched off (not programmable).

The bleeper is programmable for the following alarm conditions.






- At exceed of the LIMIT values
- Buffer full in BURST mode




Not programmable:

- Overload in highest voltage and current ranges.

Valid in function = LIMIT, BURST
 Bleeper on = SHIFT, , ENTER
 Bleeper off = SHIFT, CLR, 

Programmed at delivery: Bleeper on.

EXAMPLE 1	OPERATION	DISPLAY
SWITCH ON BLEEPER FUNCTION	 	+ 123.456 V  SPEED 2
		 + 123.456 V  SPEED 2

EXAMPLE 2	OPERATION	DISPLAY
SWITCH OFF BLEEPER FUNCTION	 	+ 123.456 V  SPEED 2

4.9.2 CLR (clear)

With SHIFT, CLR selected help functions can be switched-off, by specifying the function to be switched-off.

At input of figure a mistaken entry can be cleared. The complete number of input figures will be cleared, after which a new input can be given. Escape from inputting is possible via CLR, ENTER. No equivalent command is available for the interface (IEC/IEEE).

EXAMPLE 1	OPERATION	DISPLAY
SWITCH OFF A HELPFUNCTION E.G. AX + B		- 23.9876 * V ₋₋₋ AX + B DELAY SPEED 2
	SHIFT CLR	CLEAR SHIFT AX + B SPEED 2 ▼ (gn) SET
	AX + B	+ 10.0000 V ₋₋₋ DELAY SPEED 2

EXAMPLE 2	OPERATION	DISPLAY
CLEAR A MISTAKEN ENTRY OF FIGURES E.G. DURING INPUT OF "A" IN FUNCTION AX + B		+ 8.657 A SHIFT AX + B SET
	CLR	+ A SHIFT AX + B RE-ENTER ALL FIGURES SET

EXAMPLE 3	OPERATION	DISPLAY
ESCAPE OUT OF FUNCTION AX + B DURING INPUT OF FIGURES		+ 8.657 A SHIFT AX + B SPEED 2 ▼ (bl) SET
	CLR ENTER	+ 10.0000 V ₋₋₋ SPEED 2

4-44E


4.9.3 CHECK

In the check function a number of checks and tests are carried out sequentially. The checks and tests have been described in the relevant sections in this manual.

To enter the CHECK function press: SHIFT, CHECK. Sequentially a number of steps have to be carried out. Exit is possible with the CLR key.

The following checks and tests are implemented:

Press: SHIFT, CHECK



No equivalent command is available for the interface (IEC/IEEE)

4.9.4 SHIFT and ENTER

SHIFT allows to select the help functions. If shift is activated an indication will appear on the display.

ENTER

With ENTER help functions selection or input of figures are terminated.

No equivalent commands are available for the interface (IEC/IEEE)

4.9.5 Input of figures (blue text)

Dependent on the help function selected, the PM2535 will ask for figures to be entered. Available are: 0...9 + - and . (decimal point).

+/- is an independent toggle function

Remark: Due to conversion from decimal to binary a rounding error of ± 1 digit may occur when recalling the entered 7 digit figures.

5. OPERATING INSTRUCTIONS FOR REMOTE OPERATION VIA IEC-625/IEEE-488 INTERFACE

5.1 GENERAL


The PM2535 is an automatic ranging multimeter equipped as standard with an IEC/IEEE interface. It is designed to comply with the IEC-625/1 publication and has full remote control capabilities.

This section deals with hardware and software aspects of bus operation and describes programming functions in detail. Included are: general bus commands, device-dependent commands, status word and other operating commands. Via the interface, all functions are controllable that are normally selected by the front push-buttons. However, a number of special commands are implemented to meet the requirements of a system multimeter.

5.2 SPECIFICATIONS

5.2.1 Functional specification

Function	Identification	Description
Source-handshake	SH1	Complete capability
Acceptor	AH1	Complete capability
Talker	T5	Basic talker Serial poll possible Talk-only possible Unaddressed if "MY LISTEN ADDRESS"
Listener	L4	Basic listener Unaddressed if "MY TALK ADDRESS"
Service Request	SR1	Complete capability
Remote/Local	RL1	Complete local LOCK-OUT capability
Device Trigger	DT1	Complete capability
Device clear	DC1	Complete capability
Bus Drivers	E1	Open collector Isink 48 mA



5.2.2 Code specification

Code in use: ISO 7-bit (ISO-646).
 Separator for input data : Fully programmable; initial separator after POWER-ON; LF or the END message (EOI).
 Separator for output data : Same as the input separator; always with the END message.


5.2.3 Connector pinning

Type of connector : 24-pin female connector, contact assignment in accordance with IEEE-488.

5-2E

5.2.4 Timing specification


Interface messages (with ATN = 1) received e.g. MLA, MTA, UNL, GTL.



ST 3956

Tac = accept time; time needed to accept the interface message: 70 μ S.
 Trd = ready time; time needed until acceptor can receive new data: <220 μ S.


Data bytes (any input) received (with ATN = 0)



ST 3959

Tac = accept time; time needed to accept the data byte.
 - for the first data byte (after addressing): 90 μ S.
 - for the second and following data bytes: 90 μ S.
 Trd = ready time; time needed until acceptor can receive new data: <350 μ S.


Output data (measuring data and status data)



ST 3960

T1 = settling time (according to IEC625-1, section 3 cl 24): <150 μ S.
 T1st = time needed for the first data byte to become available on the bus:
 <400 μ S (only if valid data is available).
 Tsc = source time needed for next data byte to become available: <250 μ S.

Execution time of the GET command (Group execute trigger).



ST 3961E

Ted = execution delay time for the GET command: <500 μ S.

5.3 PROGRAMMING THE PM2535

5.3.1 General information

Programming the PM2535 is divided into three main parts: viz Interface Programming, Interface Program Data and Device programming.

The commands listed under interface programming do not influence the device functions. It is recommended to program first separators and service request masking.

5.4 INTERFACE PROGRAMMING

5.4.1 Explanation

- Remote state

When the display indication "REM" is on, the PM2535 is in the remote state. In this state, the instrument can be controlled by device-dependent data via its interface. All control of the instrument via the front-panel is disabled, except for the SHIFT, CHECK keys and single trigger (when chosen). With the CHECK key, the return-to-local function can be chosen only if the remote state is not locked.

- Local state

When the front indication "REM" is off, the PM2535 is in the local state. In this state, the instrument can be controlled via its front keyboard. All control data received via the interface will be cancelled and not executed. In the remote state, the local state is chosen via the GTL (go to local) command.

- Device clear

By a device clear command the PM2535 is initialised. This command is comparable with POWER ON or RESET.

The device clear command can be given by:

- DCL Device clear
- SDC Selected device clear } see ASCII table

- Trigger command

To start a measurement in the PM2535 a trigger command can be given by:

- GET (group execute trigger).
- X1

- Serial Polling

The serial polling sequence is used to obtain the status byte of the PM2535. It is used to determine which of several devices has requested service over the SRQ line. However, the serial polling sequence may be used at any time to obtain the status byte, to give information of settings.

5-4E

5.4.2 REMOTE/LOCAL selection

EXAMPLE	OPERATION	DISPLAY
Return to local if PM2535 is remote	SHIFT CHECK	REM rtl 0 SHIFT SET ▼ (bl)
	1	REM rtl 1 SHIFT SET ▼ (bl)
	ENTER	NORMAL MEASUREMENT

Remark: rtl 1 sets the PM2535 to local and not the interface. LSTN or TLK will stay on the display until a UNL or UNT command.

5.4.3 TALK ONLY selection


EXAMPLE	OPERATION	DISPLAY
Switch-on Talk Only mode	SHIFT CHECK ENTER	t. only 0 SHIFT SET SPEED 2 ▼ (bl)
	1	t. only 1 SHIFT SET SPEED 2 ▼ (bl)
	ENTER	TLK only NORMAL MEASUREMENT
Switch-off Talk Only mode	SHIFT CHECK ENTER	TLK only t. only 1 SHIFT SET SPEED 2 ▼ (bl)
	0	TLK only t. only 0 SHIFT SET SPEED 2 ▼ (bl)
	ENTER	NORMAL MEASUREMENT

5.4.4 ADDRESS (At delivery 22) selection.

EXAMPLE	OPERATION	DISPLAY
Check Adress	SHIFT CHECK ENTER ENTER	Addr 22 SHIFT SPEED 2 ▼ (bl) SET
	CLR	NORMAL MEASUREMENT
Modify Address to e.g. 11	SHIFT CHECK ENTER ENTER	Addr 22 SHIFT SPEED 2 ▼ (bl) SET
	1 1	Addr 11 SHIFT SPEED 2 ▼ (bl) SET
	ENTER	NORMAL MEASUREMENT

5.4.5 Interface program data

Interface program data is used to specify the different interface settings or parameters. A message unit consists always of a header-body combination and **must always** preceded by the listner address. The following structure of a program message must be used.



ST4.090E

Note: Before every header-body combination the listen address must be sent.

5.4.6 Sending program data

INTERFACE PROGRAMMING

The following program data can be given.

Function	Message	Description
Service request	MSR_ n [n] [n]	Setting of the service request mask. n [n] [n] is the decimal equivalent bit pattern
Separators	SPR_ nn [, nn]	Setting of the separators. nn is the decimal equivalent of a character of the ISO code table.
Identity	ID_?	On receipt of this command the identity is returned.
Interface test	TSl_ U TSl_ <dec 170>	On receipt of these commands a self test is performed. (U = with service request) (<dec 170> means without service). 170 is the decimal value and can be programmed on most controllers with CHR\$(170).

Notes: [] means optional
_ = space

5-6E

Service request mask

The reasons to ask for service can be masked (see table). If a service request has to be enabled for a certain condition, its mask bit must be set to 1.

Bit	8	7	6	5	4	3	2	1	0
Decimal value	256	128	64	32	16	8	4	2	1

Bit	Reasons for service request	Description
8	Instrument no longer busy	The PM2535 has made a measurement and sent it via the interface. It can now be triggered.
7	System 21 event	A service request can be generated by the System 21 part.
6	Incorrect measurement	The PM2535 has made an incorrect measurement. (e.g. overload, crest-factor exceeded, failure in a calibration measurement or a faulty Null measurement).
5	Internal failure	The PM2535 has an internal failure (e.g. No CAL).
4	Program failure	An illegal body or header is received in a command.
3	Hi limit exceed \wedge	Exceed of programmed Hi limit
2	Lo limit exceed \vee	Exceed of programmed Lo limit
1	Hold mode	The hold mode is selected via the data hold probe. Also when the hold mode is released it can generate a service request.
0	Data available	Valid data is available in the output buffer.

A mask can be set by sending MSR n [n] [n] via the interface. n[n][n] represents the decimal equivalent of the bit pattern. The following sequence must be used.

Command: MSR_n [n] [n] = optional

If more than one reason for service request has to be enabled, the decimal value is the sum of the individual decimal values.

Example: MSR_97

specifies the bit pattern: 01100001

- Data available	1
- Internal failure	32
- Incorrect measurement	64
	<u>97</u>

Note: At POWER ON all reasons for service request are masked. If a reason to ask for service occurs while its service request bit is masked, the reason is still specified in the status byte, but RQS = 0.

5.4.7 Separators


A record separator terminates the output or input sequence. It indicates that there is no additional information available. The PM2535 is capable of handling single and double input and output record separators. The record separator character(s) can be programmed to one or two characters of the ISO code table.

An ESC character is not acceptable as a record separator but no error message is given and the last programmed separator(s) will remain valid.

At POWER ON the separator is: NL (LF)

Note: For input data, the PM2535 allows but does not require the END message (EOI line). However, the PM2535 always sends out the END message concurrently with the last record separator character.

To program the separators the following sequence has to be used.



5.4.8 Identity

If the interface programming code ID_? is decoded, and the PM2535 becomes talker, it responds with PM2535X SYY.

Command ID_? X = hardwareversion (e.g. 0)
 YY = softwareversion (e.g.01)

Any additional data bytes sent in the program string are lost.

5.4.9 Interface test


On receipt of TSI_U an interface self-test is performed. If correct, a response with a byte of decimal equivalent 170 is sent on the bus when the PM2535 becomes talker. A service request is generated. If a byte of decimal equivalence 170 is received instead of the U, the same interface self-test is performed, but no service request is generated and the character U is sent out on the bus.

Commands: TSI_<dec. 170>
 TSI_U

Additional data bytes are lost.

5.5 DEVICE PROGRAMMING

Device-dependent messages are used for device control purposes. The basic units consist of a header, a body and a separator. However, a complete program message may consist of one or more units. The following structure has to be used.



The unit separator (comma) or semi colon must be used between the units. Upper and lower case characters are allowed. The execution of a message is according to the input sequence.

Example: "RNG_AUTO,X1"

5-8E

The device messages relating to the input data for the PM2535 deal with measurement start commands, speed and range selection, trigger modes function selection and display modes. These are listed on the next page.

5.5.1 Function selection

With this command, one of the seven measuring functions is selected. The select function command sets the PM2535 to predetermined states as defined in the following table. All other program data not mentioned in the table will remain if another function has been chosen.

Commands: FNC_xyz
 xyz

Function	Program data x y z	Ranging	Speed	Filter	Internal settling time
V $\overline{\text{---}}$	VDC	AUTO	2	OFF	ON
V \sim	VAC	AUTO	2	ON	ON
Ω -2w	RTW	AUTO	2	OFF	ON
Ω -4w	RFW	AUTO	2	OFF	ON
A $\overline{\text{---}}$	IDC	AUTO	2	OFF	ON
A \sim	IAC	AUTO	2	ON	ON
$^{\circ}\text{C}$	TDC	AUTO	2	OFF	ON

Ask function:

On receipt of the FNC_? command the actual function is output.

Command: FNC_?

Function	Output
V $\overline{\text{---}}$	FNC_VDC
V \sim	FNC_VAC
Ω -2w	FNC_RTW
Ω -4w	FNC_RFW
A $\overline{\text{---}}$	FNC_IDC
A \sim	FNC_IAC
$^{\circ}\text{C}$	FNC_TDC

5.5.2 Range selection

Range selection is achieved by sending the characters RNG as header. The body may consist of a decimal value with or without decimal point.

Also a technical or scientific notation is allowed.

A range is chosen by the instrument when the body is programmed as the expected measuring value. It is also possible to program the end of the range or a value within a range. The instrument will always choose the lowest possible range.

Commands: RNG_A
 RNG_AUTO

RNG_300

Ask range:

Sending the command RNG_? will output the selected range

Examples for output: RNG_300.E + 6 (300 M Ω range MAN ranging)
 RNG_30.E + 00 (30 V range MAN ranging)

Note: Programming functions and ranges can be combined in one command. The headers FNC and RNG are in this case not necessary. The bodies described in Section 5.5.1 are used for this command as a header.

VDC_200	will select	V $\overline{\text{---}}$ range 300 V
VDC_0.001	„	V $\overline{\text{---}}$ range 300 mV
VAC_2.0 E - 3	„	V \sim range 300 mV
RTW_1.5 E + 3	„	Ω -2W range 3 k Ω
IAC_AUTO	„	In auto ranging

5.5.3 Measuring Speed/Resolution

The speed and the resolution are determined by the ADC and depend also on the selected function and range. These functions are displayed with SPEED 1 (2,3,4) as a relative number (1 = lowest speed and 4 = highest speed). The instrument selects the right combination of measuring speed and resolution. Default is speed 2 for all measuring functions. Changing the measuring function will select this speed.

- Measuring Speed

With the following commands the measuring speed is selected.

Commands: MSP_1
 MSP_2
 MSP_3
 MSP_4

Ask measuring speed.

Command MSP_? will output the actual measuring speed.

Example: MSP_3

- Resolution

Commands: RSL_4
 RSL_5
 RSL_6
 RSL_7

With this command a resolution of 4, 5, 6 or 7 digits is chosen.

Note: A non-valid resolution or measuring speed results in a program failure. After programming of resolution and speed the last command is always executed.

- Ask resolution

Command: RSL_?

The actual resolution is output.

Example: RSL_5

5.5.4 Filter

The filter function can be switched ON/OFF by means of:

Commands: FIL_OFF
 FIL_ON

Note: Changing the function will select the default state.

Ask filter state.

Command: FIL_?

After sending this command, the PM2535 gives the state of the filter.

Example: FIL_OFF

5-10E

5.5.5 Trigger mode

The PM2535 has two trigger modes, namely Internal and Single. Selecting internal triggering will give a continuous measuring of the instrument. At single triggering the instrument must be started via a start command. This command can be given via the keyboard, via the IEC/IEEE bus or via the EXT TRIG input at the rear. Changing the function does not alter the selected trigger mode.

Commands: TRG_I
 TRG_B
 TRG_E
 TRG_K

I: Internal triggering

B: Single triggering via IEC/IEEE bus

E: "EXT TRIG" input and via IEC/IEEE bus

K: Single triggering via IEC bus, EXT TRIG input or via the keyboard.

Ask trigger mode:

Command: TRG_?

The trigger mode is output.

Example: TRG_E

5.5.6 Internal settling time

The internal settling time is a waiting time after a start command.

Before the ADC starts converting, the signal conditioning circuit needs time to settle. The settling time depends on the function, range and speed and is determined by the instrument. This settling time can not be changed via the front panel but can be switched OFF via the IEC-625/IEEE-488 interface to obtain faster measurements. With the following command the settling time can be switched ON/OFF.

Commands: IST_OFF
 IST_ON

Ask state internal settling time:

Command: IST_?

This will give IST_ON when the settling time is switched ON and IST_OFF when it is switched OFF.

Note: Changing the function will switch the internal settling time ON.

5.5.7 Start command

X

X_1

Start a measurement in the actual function.

5.5.8 Display mode (instrument display)

Commands: DSP_OFF
 DSP_ON

Note: The display mode is not altered when changing the function.

Ask display mode:

Command: DSP_?

Example: DSP_OFF

The display can be filled with a value. This is done by sending the value as a character string to the instrument.

Command: TXT_nnnn.nnn

nnnn.nnn is the value that is written in the display.
 The following characters can be sent to the PM2535:

1	2	3	4	5	6	7	8	9	0	.	e	"	'	-	=]	_									
1	2	3	4	5	6	7	8	9	0	.	e	"	'	-	=]	_									
A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	?
A	B	C	D	E	F	G	H	I	J	L	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	?		

ST4786

Note: 0,1 or 2 decimal points can be sent.

5.5.9 Output mode

The string (measuring value) which is output to the controller can be made shorter.

Command: OUT_N,x
 OUT_N
 OUT_S

- S = string is complete output
- N = only numerical values are output (only body)
- N,x = only numerical values are output with length specified in x.
 Also dec. point and polarity are included in this number.

Example: OUT_N,6 will give +036.4

Note: The selected mode is not altered after changing the function.

Ask output mode:
 Command: OUT_?

Example: OUT_N,5

5.5.10 Null

If a thermal e.m.f. occurs at the input sockets an offset voltage can arise. This offset voltage in the V₋₋₋, 300 mV range can be compensated by pushing NULL if the input is short-circuited. This can also be done via the IEC-645/IEEE-488 interface. At POWER ON or RESET this function is not active. The state is kept in memory during function changing, and will be used again when V₋₋₋, 300 mV is selected (Null function must be ON).

Commands: NUL_NEW
 NUL_N
 NUL_OFF
 NUL_ON

NEW: The instrument is set in V₋₋₋ 300 mV range.
 Also TRG_K is selected.
 To compensate the offset, short-circuit the V- and 0 socket and give one of the trigger commands (X1, GET). Also single trigger can be pushed or a single trigger via the BNC connector can be given.
 The compensation value is stored in memory.

OFF: The Null function is switched off but the value is still kept in memory.

ON: The Null function is switched on with the stored value.

Ask Null state:
 Command: NUL_?

Example: NUL_OFF

5-12E

5.6 HELP FUNCTIONS

5.6.1 Mathematic functions

5.6.1.1 AX + B

The measured value(X) is adapted according to the formula AX + B.
A and B can be input via keyboard or interface.

Valid in function	:	ALL
Selection command	:	SCL_ON
Input parameter	:	A
	:	B
Output	:	AX + B
Exit command	:	SCL_OFF
Exit saves	:	A, B
Function changes saves	:	A, B
Power off/reset destroys	:	A, B, unless stored in program 0—9 (PROG)
Limits for A	:	$\pm (10^{13} \dots 10^{-13})$ Input via keyboard $\pm (9999999 \text{ to } .0000001)$
Limits for B	:	$\pm (10^{13} \dots 10^{-13})$ Input via keyboard Numeric value $\pm (9999999 \text{ to } .0000001)$ The multiplication factor as shown when entering B is included in the value of B.
Delivered from factory on	:	A = +1, B 0
Commands:		
SCL_ON	:	Switches on function AX + B
SCL_OFF	:	Switches off function AX + B
SCL_ON, + 1234567, - 765.4321	:	Switches on function AX + B and fills A and B A = + 1234567 B = - 765.4321 (+ = optional)
SCL_?	:	Output the actual state of the AX + B function, technical notation Format: SCL_OFF, + 123.4567E + 00, - 765.4321E-03 ↓ ↓ A B

5.6.1.2 dBm

The measured input voltage (\sim or \rightarrow) can be converted into a dB value (dBm = 1mW, with reference resistor). The reference resistor can be chosen and stored. It must lay between .0001 and 9999 Ω . At delivery the resistance value is 600 Ω .

Valid	:	$V_{\rightarrow}, V_{\sim}$ (can be combined with ZERO)
Selection command	:	DBM_ON
Input parameter	:	Reference resistance, at delivery 600 Ω
Output	:	dBm
Exit	:	DBM_OFF
Exit saves	:	Rref
Function change saves	:	Rref
Power off/reset destroys	:	Rref, unless stored in program 0—9 (PROG)
Limits for Rref	:	.0001 \rightarrow 9999 Ω
Delivered from factory on	:	Rref = 600 Ω
Commands:		
DBM_ON	:	Switches on the dBm function with the actual reference resistor.
DBM_OFF	:	Switches off the dBm function
DBM_ON, + 7,5 E + 01	:	Switches on the dBm function and sets Rref. to 75 Ω . + = optional
DBM_OFF, 150	:	Switches off the dBm function and sets Rref. to 150 Ω .
DBM_?	:	Outputs the actual state of the dBm function, technical notation Format: DBM_OFF,_____ + 150.0000E + 00

5.6.1.3 Δ %

The measured value (X) is adapted according to the formula $\frac{X-C}{C} \times 100\%$

Valid in function	:	All (cannot be combined with other mathematical functions)
Selection command	:	PRC_ON
Input parameter	:	C
Output	:	$\frac{X-C}{C} \times 100\%$
Exit	:	PRC_OFF
Exit saves	:	C
Function change saves	:	C
Power off/reset destroys	:	C, unless stored in program 0—9 (PROG)
Limits for C	:	$\pm (10^{13} \dots 10^{-13})$ 0 excluded. Numerical value $\pm (9999999 \rightarrow .0000001)$ The multiplication factor as indicated when entering C is including the value of C.
Delivered from factory on	:	C = + 1
Commands:		
PRC_ON	:	Switches on the Δ % function with the actual reference constant C.
PRC_OFF	:	Switches off the Δ % function.
PRC_M	:	Enter measured value as reference constant C.
PRC_MEAS	:	and switches on function Δ %
PRC_ON,-168.4	:	Switches on function Δ % and enters -168.4 as reference constant C.
PRC_OFF, + 12345.67	:	Switches off function Δ % and enters + 12345.67 as reference constant C. + = optional
PRC_?	:	Outputs the actual state of the Δ % function, technical notation. Format: PRC_OFF, + 12.34567E + 03

5-14E

5.6.1.4 ZERO (Relative reference)

From the measured value (X) the contents of the ZERO register (D) is subtracted (X-D) and displayed.

Valid in function	:	All multimeter functions, dBm (cannot be combined with other mathematic functions)
Selection	:	ZER_ON
Input parameter	:	D
Output	:	X-D
Exit	:	ZER_OFF
Exit saves	:	D
Function change saves	:	D, ZERO function?
Power off/reset destroys	:	D, unless stored in program 0—9 (PROG)
Limits for D	:	$\pm(10^{13}...10^{-13})$ Input via keyboard \pm (9999999→.0000001)

Commands:

ZER_ON	:	Switches on the ZERO function with the present value of the ZERO register.
ZER_OFF	:	Switches off the ZERO function
ZER_M	:	Enters the measured value as ZERO value and switches on the ZERO function
ZER_ON, + 1234,5E + 00 + = optional	:	Switches on the ZERO function and enters + 1234.5 as ZERO value.
ZER_OFF, -34567.3	:	Switches off the ZERO function and enters -34567.3 as ZERO value.
ZER_?	:	Outputs the actual state of the ZERO function, technical notation. Format: ZER_OFF, -34.56730E + 03

5.6.2 Aquisition/Presentation of measuring data

5.6.2.1 DELAY

A delay can be programmed between a trigger and the actual start of a measurement.

Valid in function	:	All
Selection command	:	DLY_ON
Input	:	x ms
Result	:	delay of x ms
Exit command	:	DLY_OFF
Exit saves	:	Delay
Function change saves	:	Delay
Power off/reset destroys	:	Delay, unless stored in program 0 (PROG)
Limits for delay	:	8 000 000 ms
Delivered from factory on	:	Delay off, time 0 ms.

Commands:

DLY_ON	:	Switches on the delay function with the actual delay time.
DLY_OFF	:	Switches off the delay function
DLY_1234	:	Delay time of 1234 ms is entered without modification of the delay on/off state.
DLY_ON,4321	:	Switches on the delay function with a delay time of 4321 ms
DLY_OFF,9878	:	Switches off the delay function and enters a delay time of 9878 ms.
DLY_?	:	Outputs the actual state and delay time. Format: DLY_ON, 0009878

5.6.2.2 LIMITS

The measured or calculated results are compared with the contents of the LIM-LO and LIM-HI registers. If the limit values are exceeded an indication is given on the display by arrows (\vee , \wedge or $\hat{\vee}$) or by a bleeper signal, if switched on. Also a SRQ is given via the interface.

Valid in function	: All
Selection command	: LIM_ON
Input parameters	: LIM-LO (indicated by \vee) : LIM-HI (indicated by \wedge)
Result	: Indication at exceed of limits (\wedge , \vee , $\hat{\vee}$ and/or bleeper and SRQ, status byte)
Exit command	: LIM_OFF
Exit saves	: LIM-LO, LIM-HI
Power off/reset destroys	: LIM-LO, LIM-HI, unless stored in program 0—9 (PROG)
Limit indication	: LIM-LO < LIM-HI and input < LIM-LO = \vee : LIM-LO < LIM-HI and input > LIM-HI = \wedge : LIM-LO \geq LIM-HI and input < LIM-LO, > LIM LIM-HI = $\hat{\vee}$
Limits for LIM-LO LIM-LO and LIM-HI and LIM-HI.	$\pm(10^{-13} \dots 10^{13})$
Delivered from factory on	LIM-LO = 0 LIM-HI = 0

Commands:

LIM_ON	: Switches on the LIMITS function with the actual LIM-LO and LIM-HI.
LIM_OFF	: Switches off the LIMITS function: LIM-LO with LIM-HI are saved.
LIM_ON, + 123,-99.5 + = optional	: Switches on the LIMITS function and enters LIM-LO with + 123 and LIM-HI with -99.5
LIM_OFF,-7880, + 16.189 + = optional	: Switches off the LIMITS function and enters LIM-LO with -7880 and LIM-HI with + 16.189.
LIM_?	: Outputs the actual condition and limit values. Format: LIM_OFF,-788.0000E + 03, + 16.18900E + 00

5.6.2.3 BURST

In the BURST function a preprogrammed number (N, max.999) of measurements are stored in a buffer after a trigger command. A buffer full indication is given on the display switch bleeper or via the IEC-625/IEEE-448 interface. The stored measurement results can be read on the display or via the interface in the Read Buffer (RD BUF) function.

Valid in function	: All functions except SEQU
Selection command	: BUR_ON (PM2535 set to STRG)
Input parameter	: N (number of measurements to be buffered)
Result	: N measurements buffered
Exit	: BUR_OFF
Exit destroys	: Contents of buffer
Exit saves	: N, Single trigger
Function change destroys	: Contents of buffer
Function change saves	: N, Single trigger
Power off/reset destroys	: Contents of buffer, N unless stored in program 0—9 (prog 0)
Commands:	
BUR_ON	: Switches on the BURST mode with the actual number of measurements to be buffered (N).
BUR_OFF	: Stops the running BURST measurement and switches off the BURST mode. The buffer contents is cleared.
BUR_ON,320	: Switches on the BURST mode with 320 (N) measuring results to be buffered.
BUR_OFF, 16	: Stops the running BURST measurement. Switches off the BURST function. Enters 16 as number of measuring results (N) to be buffered.
BUR_?	: Outputs the actual condition and (N). Format: BUR_OFF,_16.


5-16E

5.6.2.4 RD. BUF (Read Buffer)

In the RD. BUF function, the buffer contents stored in the BURST function can be read.

In BURST ON mode

- Location numbers are preceded with "+" entered



- 0 = Empty
- 1 = First result after trigger
- 82 = Last result entered
- N = Number of result to be stored
- Max = Maximum locations number
- RD. BUF. pointer = Location to be read

- Valid in function : BURST
- Selection : BUR_ON
- Input command : Location number 0 ...999
e.g. RBU_125
- Output : Contents of buffer location number 125
- Function selection destroys : Contents of buffer
- Power off/reset destroys : Contents of buffer
- BUR_OFF destroys : Contents of buffer
- NEW BURST trigger destroys : Contents of buffer


Commands:

- RBU_125 : Outputs buffer location and the measuring result stored on buffer location 125
If not measured a "?" is emitted in the output string
Format: RBU_ + 125, MEASURING DATA
- + = optional
- RBU_+20, + 223 : Outputs buffer location and the measuring results + = optional stored on buffer locations 20 to 223.
(Order oldest ... youngest value). If not measured a "?" is emitted in the output string.
Format: RBU_ + 125, MEASURING DATA
- RBU_? : Outputs the buffer location number with the most recent measuring result.
Format: RBU_ + 330 (max. 3 digits, fixed string length).

Remark: A requested location contents, outside the specified number (N) stored in the BURST function will generate a program failure and generate a SRQ (status byte). An incorrect input polarity will also give a program failure.

In BURST OFF mode

- Location numbers are preceded with a "-".



- 0 = Actual measurement
- 1 = Last measurement carried out
- 95 = First measurement after function change
- max = Maximum locations number 999
- Function change = Last function change
- RD. BUF. pointer = Location to be read at the moment of RD. BUF. mode selection.
- Valid in function : All multimeter functions
- Input command : e.g. RBU-125
- Output : Contents of buffer
- Function change destroys : Contents of buffer
- Power off/ reset destroys : Contents of buffer

Commands:

- RBU_-125 : Outputs buffer location and the measurement result stored on buffer location-125. If not measured a "?" is emitted in the output string.
Format: RBU_- 125, MEASURING DATA
- RBU_-178,-37 : Outputs buffer location and the measurement results stored on buffer locations-178 to -37.
(Order oldest youngest value).
If not measured a "?" is emitted in the output string.
Format: RBU_- 125, MEASURING DATA
- RBU_? : Outputs the buffer location number with the oldest value at this moment.
Format: RBU_-128
(max 3 digits, fixed string length)

5.6.2.5 MIN/MAX

The function minimum/maximum is continuously present.
The minimum and maximum measurement result including the processed data are stored in the minimum and maximum registers within one function.

- Valid in function : All
- Selection Command : MIN or MAX
- Result : Display minimum
Display maximum
- Function change destroys : Contents of MIN/MAX registers
- Power off/reset destroys. : Contents of MIN/MAX registers
- Clearing MIN/MAX register : CLM
without entering the MIN/MAX function.

Commands

- MIN : Outputs actual contents of MIN register.
Format: MIN, measuring data
- MAX : Outputs actual contents of MAX register.
Format: MAX, measuring data
- CLM : Clears MIN/MAX registers.

5-18E

5.6.2.6 DIGITS (Display format function)

Independent of other settings the maximum display length can be set. The number of digits "d" can be programmed ($0 \leq d \leq 7$). Dependent on range and/or function the programmed number of digits is enabled. If the number of figures in front of the decimal point is larger than "d", small zeros will be displayed up to the decimal point (significant zeros).

e.g. Programmed 2 digits in V₋₋₋
 Display e.g. + 12. V₋₋₋
 Display + 20o. V₋₋₋, instead of + 20.

If DIGITS is 0, only the polarity sign will be displayed.

Valid in function	:	All
Selection command	:	DIG_d
Input parameter	:	number of digits "d"
Result	:	modified display length "d"
Function change saves	:	"d"
Power off/reset destroys	:	"d", unless stored in program 0—9 (PROG)
Delivered from factory on	:	"d" = 7

Commands:

DIG_d	:	Enters the number of digits to be displayed
($0 \geq d \geq 7$)	:	+ 1234567
DIG_?	:	Outputs number of digits selected "d"
		Format: DIG_6

5.6.3 Function programming

5.6.3.1 PROG function (PROGRAM)

Instrument settings including process functions and constants can be stored under a program number (except rtl, tonly, address, MSR, SPR). The settings can be recalled (manual, via interface) to set the instrument in predefined modes/functions.

The maximum number of programs is 10 (0-9).

The settings stored in P0 will be automatically taken over by the PM2535 at power-on or reset.

Valid in function	:	All
Selection command	:	STO_X
Input parameter	:	(P)X X = 0-9
Result	:	Instrument settings stored in PX
Function change saves	:	Settings PX
Power off/reset saves	:	Settings P0

Commands:

STO_3	:	The actual settings of the PM2535 are stored in P3.
RCL_3	:	The settings stored in P3 will be taken over by the PM2535.

5.6.3.2 SEQUENCE

The sequence function enables the PM2535 to carry out a number of sequential steps, with different instrument settings as stored in the PROGRAM function.

At the same time control data can be output to System 21 modules in the System 21 scan function. In this case the PM2535 with System 21 modules can be used as stand-alone system (without controller).

The scan function (available only in some slave units) is used for the sequential select of inputs, switches, channels. A scan-cycle can be executed over channels of several units on the condition that:

- All units are of the same PM-number.
- All units are set for the same operating mode (see the System 21 manual and the operating cards of the slave units).
- No unit is in Execute Unconditional mode.
- The units have successive addresses with settings starting at 0.

The scan is initiated by the PM2535. The execution is done with a number of execute commands or triggers equal to the number of channels to be scanned. Under the above conditions a scan cycle will start with the lowest channel number of the unit with address-switch set to zero and continues along all channels and units.

Programming the Sequence function is only possible via the front keys. (via IEC/IEEE interface is not implemented).

Valid in function	:	All
Selection	:	SEQ_ON
Result	:	Start of the SEQUENCE function
Exit	:	SEQ_OFF
Exit saves	:	P0-P9
Function change saves	:	P0-P9
Power off/reset saves	:	P0-P9

Remark: Programming of a sequence program is not possible via the interface. Start stop and trigger of the complete program is possible.

Commands that change instrument settings when the sequence program is in progress will be ignored and generate a program failure.

Commands:

SEQ_ON	Starts sequence program Trigger commands are allowed.
SEQ_OFF	Ends the sequence program and exits the sequence function.
SEQ_?	Outputs the actual SEQUENCE condition. Format: SEQ_OFF

5.6.3.3 BLEEPER

The built-in bleeper can be switched on or off for a number of functions. For some alarm functions the bleeper cannot be switched off (not programmable). The bleeper is programmable for the following alarm conditions:

- All exceeds of the LIMIT values.
- Buffer full in BURST mode.

Not programmable:

- Overload in highest voltage and current ranges.

Valid in function	:	LIMITS, BURST
Bleeper on command	:	BLP_ON
Bleeper off command	:	BLP_OFF
Programmed at delivery	:	Bleeper on

Commands:

BLP_ON	:	Switches on the bleeper function
BLP_OFF	:	Switches off the bleeper function (excluding overload alarms)
BLP_?	:	Outputs the actual bleeper condition. Format: BLP_OFF.

5.7 SYSTEM 21 MODE

To enable responses from System 21 part the command: AID_E has to be sent.

To disable responses from the System 21 part the command: AID_D has to be sent.

5-20E

5.8 SURVEY OF COMMANDS


The following table gives a survey of the commands that can be used to program the PM2535.

Commands	Description
Function	
FNC_xyz	xyz can be one of the following functions: VDC = Direct voltage IDC = Direct current VAC = Alternating voltage IAC = Alternating current RTW = Ohm 2-wire TDC = Temperature °C RFW = Ohm 4-wire
Ranging	
RNG_A[uto] RNG ±aaa.aE ±aa	Auto-ranging The expected measuring value or the end-of-range can be programmed as range in scientific or technical notation. (e.g. RNG_3 or RNG_3.000E+03).
Measuring Speed/ Resolution	
MSP_x RSL_x	x = integer between 1 and 4 to program the measuring speed x = integer between 4 and 7 to program the resolution.
Filter	
FIL_ON FIL_OFF	Filter is switched ON/OFF.
Trigger mode	
TRG_I TRG_B TRG_E TRG_K	Internal triggering. Single triggering via IEEEE/IEC bus. "EXT TRIGGER" input or via IEC/IEEE bus. Triggering via the keyboard (Single triggering), via the "EXT TRIGGER" input or via the IEC/IEEE bus.
Internal settling time	
IST_ON IST_OFF	Internal settling time switched ON/OFF.
Delay	
DLY_ON DLY_ON, X DLY_OFF DLY_OFF, X	Delay ON/OFF or x ms.
Start	
X_1	Starts a measurement.
Display	
DSP_ON DSP_OFF TXT_xxxxxxx	The display is switched ON/OFF. Text specified in xxxxxxx is displayed.
TST	Selfdiagnostic mode switched on (Refer to service manual)
Output mode	
OUT_S OUT_N OUT_N,x	The whole measuring data string is output. Only numerical results are output. A numerical result is output with a length specified in x.

Commands	Description
Null mode	
NUL_ON NUL_OFF NUL_[New]	The NULL function is switched ON/OFF. A new NULL value is stored in memory.
Cal mode	
CAL_ON CAL_OFF	The cal mode is switched ON/OFF (Refer to service manual)
System 21	
AID_E AID_D	Output from System 21 part is enabled/disabled
AX + B	
SCL_ON SCL_OFF SCL_ON,A,B SCL_OFF,A,B	Switches-on/off the AX + B function Switches on the AX + B function and fills A and B A = e.g. -765.4321 B = e.g. -.1234567 Switches-off the AX + B function and fills A and B A = e.g. + 1234567 B = e.g. -765.4321
dBm	
DBM_ON DBM_OFF DBM_ON,A DBM_OFF,A	Switches-on/off the dBm function Switches-on the dBm function and sets Rref to the value of A. A = e.g. 150 Switches-off the dBm function and sets Rref to the value of A. A = e.g. 5E + 01 = 50Ω
Δ%	
PRC_ON PRC_OFF PRC_M PRC_MEAS PRC_ON,A PRC_OFF,A	Switches-on/off the Δ % function with the actual reference constant. Enters the measured value or reference constant and switches on the Δ % function. Switches on the Δ % function and enters A as reference constant. A = e.g. -168.4 Switches-off the Δ % function and enters A as reference constant. A = e.g. + 12345.67
ZERO	
ZER_ON ZER_OFF ZER_M ZER_MEAS ZER_ON,A ZER_OFF,A	Switches-on/off the ZERO function with the present value of the ZERO register. Enters the measured value as ZERO value and switched on the ZERO function. Switches-on the ZERO function and enters A as ZERO value. A = e.g. + 1234.5E + 00 Switches-off the ZERO function and enters A as ZERO value. A = e.g. + 1234.5

5-22E

Commands	Description
DELAY	
DLY_ON DLY_OFF DLY_ON,A DLY_OFF,A	Switches-on/off the delay function with the actual delay time Switches-on the delay function with a delay time of a A ms. A = e.g. 1234 Switches-off the delay function and enters a delay time of A ms. A = e.g. 1000
LIMITS	
LIM_ON LIM_OFF LIM_ON,A,B LIM_OFF,A,B	Switches -on/off the LIMITS function with the actual LIM-LO and LIM-HI values Switches-on the LIMITS functions and enters LIM-LO with A and LIM-HI with B. . A = e.g. 123 B= e.g. -99.5 Switches-off the LIMITS function and enters LIM-LO with A and LIM-HI with B. . A = e.g. -7880 B= e.g. +16.189
BURST	
BUR_ON BUR_OFF BUR_ON,N BUR_OFF,N	Switches-on the BURST mode with the actual number of measurements to be buffered (N). Stops the running BURST measurement and switches-off the BURST mode. The BUFFER contents is cleared. Switches-on the BURST mode with N measuring results to be buffered. Stops the running BURST measurement. Switches-off the BURST function. Enters N as number of measuring results to be buffered.
RD. BUF	
<u>BURST ON</u> RBU_A RBU_A,B	Outputs buffer location and the measurement result stored-on buffer location A. If not measured a "?" is emitted in the output string. Outputs buffer location and the measurement result stored on buffer location A to B.
<u>BURST OFF</u> RBU_ - A RBU_ - A, - B	Outputs buffer location and the measurement result stored on buffer location - A. If not measured a "?" is emitted on the output string. Outputs buffer location and the measurement results stored in buffer locations - A to - B.
MIN/MAX	
MIN MAX CLM	Outputs the actual contents of MIN register. Outputs the actual contents of MAX register. Clears MIN/MAX registers.
DIGITS	
DIG_A	Enters the number of digits to be displayed $0 \leq A \leq 7$
PROG	
STO_A RCL_A	The actual settings of the PM2535 are stored in (P)A. The settings stored in (P)A will be taken over by the PM2535.
SEQUENCE	
SEQ_ON SEQ_OFF	Starts sequence program. Ends the sequence program and exits the sequence function.

Commands	Description
BLEEPER 	Switches-on the bleeper function. Switches-off the bleeper function (excluding overload alarms)
BLP_ON BLP_OFF	
DUMP	Outputs all settings of the PM2535
DMP	

5.9 CALIBRATION VIA THE CONTROLLER

The calibration mode can be called via the IEEE-488/IEC-625 bus. To enable the calibration mode push the CAL (pencil operation) and the RESET (Pencil operation) switch. Release the CAL switch after the RESET switch. The calibration mode is indicated on the display with the CAL symbol.

Via the command CAL_ON the calibration mode is started and the first range can be programmed. The normal commands to select a range or function can be used. On receipt of CAL_? the CAL state is output (Example: CAL_OFF).

For detailed calibration information, refer to the service manual of the PM2535.

5.10 SELFDIAGNOSTICS VIA THE CONTROLLER


It is possible to choose the selfdiagnostic mode via the interface. This is done with the command TST. Refer to the service manual of the PM2535 for detailed information.

Remark: The testmode cannot be switched-on the Calibration, Burst and Sequence function. An illegal code will be generated.

5.11 OUTPUT DATA

5.11.1 Measuring data

Measurements is sent out as header body combinations



FUNCTION/ADDITIONAL INFORMATION (1) (2) (3) (4) (5) (6)
 x x x y y y

The first part of the header (xxx) is a three-character indication of the function separated by a space from the second part. The possibilities for xxx are given in the following table.

Function	Characters 1 2 3
V $\overline{\text{---}}$	VDC
V \sim	VAC
Ω -2w	RTW
Ω -4w	RFW
A $\overline{\text{---}}$	IDC
A \sim	IAC
$^{\circ}\text{C}$	TDC

5-24E


The second part (YYY) of the header gives additional information.

- no processing
- S scaling (AX + B) **4th character**
- D decibel (dBm)
- P Δ %

- no processing
- Z Zero set **5th character**
- C Calibration measurement

- L Limits exceeded *
- ? dummy measurement output
- normal measurement
- O ADC overload **6th character**
- C Crestfactor, ($V \sim A \sim$),
Clipping input circuit (other function)
- U dBm underload
- F Fail at calibration measurement
- N Failure at NULL measurement
- M Mathematical overflow
- R Reduced accurate output
- * Software version \geq S04

MEASURING RESULT (body)



RECORD SEPARATOR

SR3 is the record separator with the END message. The record separator is programmable (see section 5.4.7). The initial state after POWER-ON is: NL. Data examples, and their representation in a header body are shown below.

Characters	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
	V	D	C	<u>Sp</u>	<u>Sp</u>	C	+	1	2	3	.	4	5	6	7	E	-	0	3	<u>SR3</u>
	R	T	W	<u>SP</u>	<u>Sp</u>	<u>Sp</u>	+	1	2	.	3	4	5	6	7	E	+	0	3	<u>SR3</u>


5.11.2 Dump

After the dump command, the PM2535 sends all the settings to the controller.

DMP

The output is always in a determined pattern as described in the section, Device Programming.

Remember: This outputted string can also be used to program the PM2535. The identical setting of the instrument is performed.



5-26E

5.11.3 Output of settings

The programmed PM2535 can give its setting by the DMP command (see section 5.11.2). However, the individual settings can also be obtained from the instrument. The instrument outputs a setting as it receives the header which is normally used to program the setting, and a question mark as body.

See the following table for outputs.

Command	Output	(Possibilities)
FNC_?	FUNCTION	FNC_VDC FNC_VAC FNC_RTW FNC_RFW FNC_IDC FNC_IAC FNC_TDC
RNG_?	RANGE	RNG_AUTO RNG_xxx.E ± xx (x = integer between 0-9)
MSP_?	MEASURING SPEED	MSP_1 MSP_2 MSP_3 MSP_4
RSL_?	RESOLUTION	RSL_4 RSL_5 RSL_6 RSL_7
FIL_?	FILTER MODE	FIL_OFF FIL_ON
IST_?	INTERNAL SETTLING TIME	IST_OFF IST_ON
TRG_?	TRIGGER MODE	TRG_I TRG_B TRG_E TRG_K
DLY_?	DELAY	DLY_OFF,xxxxxxx (x = integer between 0 and 9) DLY_ON,xxxxxxx
DSP_?	DISPLAY STATE	DSP_OFF DSP_ON
OUT_?	OUTPUT MODE	OUT_S OUT_N OUT_N,x (x = integer between 1 and 9)
NUL_?	NULL MODE	NUL_OFF NUL_ON
CAL_?	CAL MODE	CAL_OFF CAL_ON
SCL_?	AX + B	SCL_OFF, + 123.4567E + 00, - 765.4321E - 03 SCL_ON, - 123.4567E + 00, - 765.4321E - 03
DBM_?	dBm	DBM_OFF, _____ + 150.0000E + 00 DBM_ON, _____ + 150.0000E + 00
PRC_?	Δ%	PRC_OFF, + 12.34567E + 03 PRC_ON,
DLY_?	DELAY	DLY_ON, 0009878 DLY_OFF,
LIM_?	LIMITS	LIM_OFF, - 12345.67E + 03, + 12345.67E + 03 LIM_ON, - 12345.67E + 03, + 12345.67E + 03

Command	Output	(Possibilities)
BUR_?	BURST	BUR_OFF,_16 BUR_ON,120
RBU_?	RD. BUF.	RBU_-128 (BURST OFF) RBU_+ 128 (BURST ON)
DIG_?	DIGITS	DIG_6
BLP_?	BLEEPER	BLP_OFF BLP_ON
SEQ_?	SEQUENCE	SEQ_OFF SEQ_ON

Note: To avoid occasional incorrect read-out (measuring result) in the internal trigger mode, a delay of some machine cycles is advised.

Example P2000 C: 10 IEC INIT
 20 IEC PRINT # 22,"DMP?"
 Delay → 30 R = B
 40 IEC INPUT # 22,A\$
 50 PRINT A\$

5-28E

5.11.4 Device status data

The device status data of the PM2535 is represented in one status byte (8 bits) and is built-up as follows:

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
EX	RQS	AB	BSY	EF3	EF2	EF1	EF0

- EX Extension (always 0)
- RQS = 0 No request for service
- RQS = 1 The PM2535 has requested for service
- AB = 0 The PM2535 is not in an abnormal condition
- AB = 1 The instrument is in an abnormal condition and is specified in the bits EF3 to EF0
- BSY = 0 PM2535 is not measuring and the data of any previous measurement has been output.
- BSY = 1 The PM2535 is measuring and/or data has not been output.

Description

If AB = 1 then the bits EF3-EF0 indicate the abnormal condition.

AB	BSY	EF3	EF2	EF1	EF0	Description
1	x	x	x	x	1	Program failure (e.g. an illegal body has been received).
1	x	x	x	1	x	Internal failure (e.g. No Cal condition).
1	x	x	1	x	x	Incorrect measurement (OL, CF, failure in a calibration measurement or a faulty NULL measurement).
1	x	1	x	x	x	System 21 event.

Note: One or more conditions can be specified, by the instrument, in the status byte.

After a serial poll, the bits AB and EF3 to EF0 are reset to zero.

If AB = 0 then the bits EF3 to EF0 indicate a normal condition.

AB	BSY	EF3	EF2	EF1	EF0	Description
0	0	x	x	x	0	No measurement is started and there is no data available.
0	1	x	x	x	0	A measurement is started but no data available.
0	1	x	x	x	1	Data is available, not yet sent via the interface.
0	0	x	x	x	1	Data is sent via the interface but remains available. Instrument can be triggered.
0	x	x	x	1	x	The HOLD mode is selected via the data hold probe.
0	x	1	x	x	x	HI Limit exceed
0	x	x	1	x	x	LO Limit exceed

5.11.5 Identity

After the command ID_? the identity is output:

Characters	1	2	3	4	5	6	7	8	9	10	11	12
	P	M	2	5	3	5	0	<u>SP</u>	S	0	1	<u>SR3</u>

↑ depends on hardware version ↗ depends on software version

5.11.6 Interface test

On receipt of TSI_U or TSI+[CHR\$(170)] a self-test is performed.

Programming	Output data (test o.k.)	Remark
TSI_U	dec. 170 [CHR\$(170)]	with service request
TSI+[CHR\$(170)]	U	without service request

5.12 REASONS FOR SERVICE REQUEST

Service is requested, if not masked, in the following way:

Program failure

If the PM2535 has received an illegal body or header the instrument responds with:

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	1	x	x	x	x	1

Internal failure

Service request will be given if an internal failure occurs. An internal failure is e.g. No Cal. The following will be given.

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	1	x	x	x	1	x

Incorrect measurement

Service will be requested when the PM2535 has made an incorrect measurement. This incorrect measurement can be Overload (OL), exceeding the Crest factor (CF), if a failure occurs at a calibration measurement or when the instrument has made a faulty NULL measurement. It responds with:

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	1	x	x	1	x	x

5-30E

System 21 event

In the PM2535 the master function of the System 21 is implemented. At a System 21 event (see also section 5.13) the master function draws the attention of the controller by asking service. The events are described in the System 21 manual which can be ordered with the reply card.

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	1	x	1	x	x	x

Data available

If the PM2535 has made a measurement and has valid data which has not been output, it responds with:

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	0	1	x	x	x	1

Waiting for a trigger command

If the instrument has sent the data to the interface and is waiting for a trigger command, the status byte will be the following: (BSY = 0)

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	0	0	x	x	x	1

The BSY (busy) bit will set after a trigger command has been received.

Hold mode

With the HOLD probe the HOLD mode can be entered. The reading is "frozen" on that moment. The instrument responds with:

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	0	x	x	x	1	x

If the HOLD mode is left by once more pushing the button on the HOLD probe, the instrument asks again for service and responds with the following byte:

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	0	x	x	x	0	x

Limit mode

Exceed of limits

EX	RQS	AB	BSY	EF3	EF2	EF1	EF0
0	1	0	x	x	1	x	x
0	1	0	x	1	x	x	x

Lo
Hi

5.13 SYSTEM 21 MASTER FUNCTION

5.13.1 General

System 21 is a modular system consisting of a master and a number of independent functional units (slaves). It can be used in automatic test or measurement set-ups for auxiliary purposes, such as switch functions, I/O functions etc.

The main task of the master function is to pass data to the functional units. The communication between the external system and functional units is transparent. That means that the data is not affected during the transport from the external system to the functional unit and vice versa.


In the PM2535 a System 21 master function is implemented. This means that a number of slave units (depending on the supply current, fuse protected max. 200 mA) can be connected to the PM2535.

The System 21 with PM2535 set-up can be used in two ways via:

- as Stand-alone system without a controller

The PM2535 can be programmed via the frontkeys in the SEQUENCE function to control the scan function of System 21.

- as Complete system with a controller



S14795ED
850805

The System 21 commands are not handled here, but a full survey of the commands can be found in the Quick-operating guide delivered with the PM2535 and in the operating cards of the individual units (delivered with the units) for specific unit-dependent commands. Remember that interface commands (such as service request masking, identity, etc) are only valid for the interface and will act as described in section 5.12.

5-32E


5.13.2 Contact assignment of System 21 connector

Pin number	Signal line
1	V +
2	data high
3	earth (shield)
4	ready
5	trigger
6	V -
7	data low
8	reset
9	V -


5.13.3 Addressing a message

Any message to the PM2535 preceded by the IEEE/IEC address is set by the CHECK/END button. The routing of a message to the master or to one of the slave units, is indicated by the first element of the message, the unit address.

The unit address for the master is recognized by the characters AID.
(Additional Instrumentation Devices). So a command for the master is as follows:



A command intended for a slave must be preceded by the characters AID and 3 digits.



These 3 digits consist of the last two digits of the PM- number of the unit + 1 digit set on the unit address switch.

Separation between the unit address and the commands is achieved with ";" or ",". If more than one command is sent in one string, the individual commands need to be separated by commas.

5.13.4 Commands

Commands are given in ASCII-coded form. There are two types of commands:

1. Commands for the master function.
2. Commands for individual unit slaves.

A full summary is given overleaf of the System 21 master commands. Some of these commands request for return data.

Command	Description
Reset	
AID,RES	Reset the complete system to the power-on conditions.
enable/disable	
AID__E AID__D	Output from system 21 part is enabled/disabled

Command	Description
Trigger mode and commands to trigger or to execute	
AID,TRG_R AID,TRG_U AID,XCU_T AID,XCU_nn	Trigger in ready mode: enable the trigger-commands <u>GET</u> and "XCU_T" only when ready is true (ready line is high) or delay the received trigger command until ready becomes true. Trigger Unconditional mode: the trigger-commands <u>GET</u> and "XCU_T" will unconditionally generate an impulse on the trigger-line. Execute the units by a pulse on the System 21 trigger-line if enabled. Execute all units with "PM21nn" numbers independent of the execution mode of the units. This command is useful when using I_S commands to perform a scan by more than one unit of the same type number.
Read trigger mode	
AID,TRG_?	Read current trigger mode Responses: AID;TRG_R Trigger in ready mode AID;TRG_U Trigger unconditional
sequential execution	
AID,SEQ_ON AID,SEQ_OFF	Sequential execution. (SEQ_ON) Parallel execution possible.
Read sequential mode	
AID,SEQ_?	Sequential execution ON or OFF ? Responses: AID;SEQ_ON Sequential execution on. AID;SEQ_OFF Sequential execution mode off.
System 21 event masking	
AID,MSK + <digits>	Mask System 21 events (maximum 9 digits). A zero digit disables the corresponding event to generate a Service Request. Digits 1 slave had a power fail or received a power-on reset. A unit received an illegal code or illegal sequence. 2 An addressed module is not present. 3 All units are ready performing the programmed actions. 4 All units are ready with the received data and may receive new data (input buffer is empty). 5 A unit has functional data available. 6 All units have completed the block or scan. 7 A unit has a warning. 8 The ready-line became high (ready true). 9 A trigger-pulse was captured on the trigger-line (not in PM2535).
Read event mask	
AID,MSK_?	Read current System 21 event mask. Response: AID;MSK + <9 digits> Indicates which events set the abnormal bit (AB) together with the EF3 bit in the Serial Poll byte.

5-34E

Command	Description
Request Configuration	
AID_?	Which unit addresses are present on System 21? Responses: AID + <address> List of addresses that are available
System 21 status	
AID,STA_?	Request System 21 Status.
	Response: AID;STA + <9 digits> Digits 1 Master received a power-on reset. 2 The addressed unit was not present. 3 A unit is busy. 4 A unit is not ready with the received data. 5 A unit has functional data available that should be read. 6 One or more units are busy with a block or scan. 7 A unit has a warning. 8 The master detected the ready-line high; ready is true. 9 The master captured a trigger pulse on the trigger-line (not available in PM2535). Digits 1, 2, 8 and 9 are cleared when read. A digit which is 0, indicates that the related message is not true.
Read ready-line	
AID,RDY_?	Logic state of the ready-line ? Responses: AID;RDY_0 If ready-line is low (ready false) AID;RDY_1 If ready-line is high (ready true)
Read trigger-mode	
AID,TRG_?	Read actual trigger mode Responses: AID;TRG_R Trigger if ready mode. AID;TRG_U Trigger unconditional mode.
Read programming of the master	
AID,DMP_?	Ask for the programming data of the master Response: AID; + <event mask> + <trigger mode> + <sequential mode>
End of block or scan	
AID,BBS_?	Which units are busy with a block or a scan? Response: AID;BBS + <addresses> List of addresses of units which are busy with a block or a scan.
Data available	
AID,DAV_?	Which unit addresses have Data available? Response: AID;DAV + <addresses> List of addresses of units which have data available. (Example: AID;DAV 310,311,312,).

6. GLOSSARIES

6.1 GLOSSARY OF TERMS

A	Addr AH1 AID ATN AUTO, AUT AX + B	Address (IEC-625/IEEE-488) Acceptor handshake (IEC-625,IEEE-488) Auxillary instrumentation devices (system 21) Attention (IEC-625, IEEE-488) Automatic (ranging) Scaled measurements function
B	BLP BUR	Beeper Burst
C	CAL CLR CM CSA	Calibration Clear Common mode Canadian Standard Assosiation
D	$\Delta\%$ DBM DAV DCL DIG DIO-DIO8 DLY DSP	Deviation in $\frac{X-C}{C} \times 100\%$ Decibel measurements Data available Device clear Digit Data input lines (IEC-625/IEEE-488) Delay Display
E	EOI	End or identify
F	FIL FNC	Filter Function
G	GET GTL	Group execute trigger Go to local
H	Hi	High-input
I	ID INT IST	Identity Internal Internal settling time
L	L4 LF LIM LO	Listener (basic) Line feed Limit Low-input
M	M MAX MAN MIN MLA MRNG MSR MTA	Mode Maximum Manual Minimum My listen address Manual ranging Mask service request My talk address

6-2E

N	NDAC NL NRFD	Not data accepted New line Not ready for data
O	OL	Overload
P	P0 PROG PRC PX	Program 0 Program Percentage Program X
R	REM RD BUF RH RL1 RNG R. REF RSL	Remote Read buffer Relative humidity Remote local 1 Range Reference resistor Resolution
S	SCL SDA SDC SEQ SEQU SH1 SPR SR1 SRQ STRG ST 00	Serial clock Serial data Selective device clear Sequence Sequence Source handshake 1 Separator Service request 1 Service request Single trigger Step 00
U	UL UNL	Underload Unlisten
X	X1	Start command
Z	ZER	Zero (relative reference)

6.2. SHORT SURVEY OF PROGRAM COMMANDS

<p>BLP_ON BLP_OFF BLP_? → BLP_OFF BLP__ON</p>
<p>BURST</p> <p>BUR_ON BUR_OFF BUR_ON, N BUR_OFF, N BUR_? → BUR_OFF, N BUR__ON, N</p>
<p>CAL</p> <p>CAL_ON CAL_OFF CAL_? → CAL_OFF CAL__ON</p>
<p>MIN/MAX</p>
<p>CLM</p>
<p>DBM</p> <p>DBM_ON DBM_OFF DBM_ON, A DBM_OFF, A DBM_? → DBM_OFF, A DBM__ON, A</p>
<p>DISPLAY</p> <p>DSP_ON DSP_OFF DSP_? → DSP_OFF DSP__ON</p>
<p>DIGITS</p> <p>DIG_A DIG_? → DIG_A</p>
<p>DELAY</p> <p>DLY_ON DLY_OFF DLY_ON, A DLY_OFF, A DLY_? → DLY_OFF, A DLY__ON A</p>
<p>FILTER</p> <p>FIL_ON FIL_OFF FIL_? → FIL__ON FIL_OFF</p>

<p>FUNCTION</p> <p>FNC_VDC VAC IDC RTW IAC RFW TDC FNC_? → FNC_VDC</p>
<p>Δ%</p> <p>PRC_ON PRC_OFF PRC_ON A PRC_OFF, A PRC_M [EAS] PRC_? → PRC_OFF, A PRC__ON, A</p>
<p>RD. BUF</p> <p>RBU_A → RBU_+A, DATA RBU_A, B → RBU_+A, DATA RBU_-A → RBU_-A, DATA RBU_-A, -B → RBU_-A, DATA RBU_? → RBU_-128, DATA RBU_+128, DATA</p>
<p>RANGE</p> <p>RNG_A RNG_3 RNG_? → RNG_____AUTO RNG xxx. E + OX</p>
<p>RESOLUTION</p> <p>RSL_X RSL_? → RSL_X</p>
<p>AX + B</p> <p>SCL_ON SCL_OFF SCL_ON, A, B SCL_OFF, A, B SCL_? → SCL_OFF, A, B SCL__ON, A, B</p>
<p>SEQUENCE</p> <p>SEQ_ON SEQ_OFF SEQ_? SEQ_OFF SEQ__ON</p>
<p>TRIGGER</p> <p>TRG_I TRG_B TRG_E TRG_K TRG_? → TRG_I TRG_B TRG_E TRG_K</p>

6-4E

TEST
TST
TEXT
TXT_XXXXXXXX
SETTLING TIME
IST_ON IST_OFF IST_? → IST_ON IST_OFF
LIMITS
LIM_ON LIM_OFF LIM_ON, A, B LIM_OFF, A, B LIM_? → LIM_OFF, A, B LIM_ON A, B
MIN/MAX
MIN → MIN, A MAX → MAX, A
SPEED
MSP_A MSP_? → MSP_A
NULL
NUL_ON NUL_OFF NUL_N[EW] NUL_? → NUL_OFF NUL_ON

OUTPUT FORMAT
OUT_S OUT_N OUT_N, X OUT_? → OUT_S OUT_N OUT_N, X
START
X [1]
ZERO
ZER_ON ZER_OFF ZER_M[EAS] ZER_ON, A ZER_OFF, A ZER_? → ZER_OFF, A ZER_ON, A
INTERFACE COMMANDS
SRQ MASK
MSR_n, [n] [n]
SEPARATOR
SPR_n n [, nn]
IDENTITY
ID_? → PM2535 X_SYY
INTERFACE TEST
TSI_<dec.170> → U TSI_U → <dec. 170>

Sales and Service all over the world

Algeria

Bureau de Liaison Philips
24 rue Bougainville
El Mouradia, Alger
Tel: 60 14 05
TLX: 62221

Antilles

Philips Antillana N.V.
(For Philips products)
Schottegatweg Oost 146
PO Box 3523
Willemstad, Curacao
Tel: 599-9-615277
Fax: 599-9-612772
TLX: 1047
Tel: 599-9-414071/74*

Argentina

Philips Argentina S.A.
(For Philips products)
Casilla Correo 3479
Vedia 3892
1430 Buenos Aires
Tel: 54-1-5414106/5417141
Fax: 54-1-7869818
Tel: 54-1-5422411/5422451*
TLX: 21359/21243

Coasin S.A.

(For Fluke products)
Virrey del Pino 4071 DEP E-1
1430 CAP FED
Buenos Aires, Argentina
Tel: (54) (1) 552-5248
TLX: (390) 22284 COASN AR

Australia/New Zealand Philips Scientific & Industrial PTY Ltd.

Test & Measurement Dept.
NZ Head Office
2 Wagner Place
PO Box 4021
Auckland 3
New Zealand
Tel: 09-894160
Fax: 09-862728
TLX: NZ 2395

Australia Head Office Philips Scientific & Industrial PTY Ltd.

Test & Measurement Dept.
Centrecourt 25-27 Paul Street
North Ryde
Sydney New South Wales 2113
Tel: 02-888 0416
Tel: 02-888 8222*
Fax: 02-888 0440
TLX: AA 20165 philind ausnrsi

Philips Scientific & Industrial PTY Ltd.

Test & Measurement
23 Lakeside Drive
East Burwood
Melbourne Victoria 3151
Tel: 03-235 3666
Fax: 03-235 3618

Philips Scientific & Industrial PTY Ltd.

Test & Measurement
348 Torrens Road
Croyden
Adelaide South Australia 5008
Tel: 08-3482888
Fax: 08-3482813

Philips Scientific & Industrial PTY Ltd.

Test & Measurement
299 Montagne Road
West End
Brisbane Queensland 4101
Tel: 07-8440191
Fax: 07-8448537

Philips Scientific & Industrial PTY Ltd.

Test & Measurement
1 Frederick Street
Belmont
Perth West Australia 6104
Tel: 09-277-4199
Fax: 09-277-1202

Austria

**Oesterreichische Phillips
Industrie GmbH**
Geschäftsbereich I & E
Marktbereich Test und
Messgeräten
Triesterstrasse 64
1101 Wien
Tel: 0222/60101 ext. 1772
Fax: 0222-6272165
TLX: 131670

Oesterreichische Phillips* Industrie GmbH

Geschäftsbereich I & E
Technischer Kundendienst
Triesterstrasse 64
1101 Wien
Tel: 0222-60101 ext. 818

Bahrain

**Messrs. Mohamed Fakhroo
& Bros**
PO Box 439
Bahrain
Tel: 973-253529
Fax: 973-275996
TLX: 8679 alfaro bn

Bangladesh

Philips Bangladesh Ltd.
(For Philips products)
PO Box 62, Ramna
16/17 Kawaran Bazar C/A
Dhaka
Tel: 325081-5
Tel: 234280*
TLX: 65666

Motherland Corporation

(For Fluke products)
24 Hatkhola Road, Tikatuli
Dacca-3, Bangladesh
Tel: 257249
TLX: (950) 642022 PCO BJ

Belgium

**Philips Professional
Systems S.A.**
**Test & Measurement
Department**
Tweestationstraat 80
1070 Brussel
Tel: 02-525 6692
Tel: 02-525 6694*
Fax: 02-230-2856* yhyg
Fax: 02-525 6483
TLX: 61511 belbrms

Brazil

ATP Hi-Tek Electronica Ltda.
Al. Amazonas 422, Alphaville
06400, Barueri
Sao Paulo, Brazil
Tel: (55) (11) 421-5477
TLX: (391) 1171413 HITK BR

ATP/Hi-Tek Electronica Ltda.

Ave. Henrique Valadares, RJ-4
Andar-Sala 401
20231, Rio de Janeiro, RJ Brazil
Tel: (55) (21) 252-1297

Brunei

Brunei (via Singapore)
(For Philips products)
Philips Project Development
(S) PTY Ltd.
Lorong 1, Toa Payoh
Singapore 1231
PO Box 340 Tao Payoh C.P.O.
Tel: 65-3502000
TLX: philips rs/21375

Rank O'Connor's, 5nd Bhd

(For Fluke products)
No. 8 Block D,
Sufri Shophouse Complex
Mile 1 Jalan Tutong
Bandar Seri Begawan
Negara Brunei Darussalam
Tel: (673) (2) 23109 or 23557
TLX: (799) BU 2265 RANKOC

Canada

Fluke Electronics Canada Inc.
400 Britannia Rd. East Unit #1
Mississauga, Ontario
L4Z 1X9 Canada
Tel: (416) 890-7600
Fax: (416) 890-6866

Fluke Electronics Canada Inc.

1690 Woodward Drive
Suite 216
Ottawa, Ontario
K2C 3R8 Canada
Tel: (613) 723-9453
Fax: (613) 723-9458

Fluke Electronica Canada Inc.

1255 Trans Canada Highway
Suite 120
Dorval, Quebec
H9P 2V4, Canada
Tel: (514) 685-0022
Fax: (514) 685-0039

Fluke Electronics Canada Inc.

101, 1144 - 29th Ave. N.E.
Calgary, Alberta
T2E 7P1 Canada
Tel: (403) 291-5215
Fax: (403) 291-5219

Chile

**Philips Chilena S.A.
de Product Electr.**
(For Philips products)
Avenida Santa Maria 0760
Casilla 2678
Santiago de Chile
Tel: 56-2-770038
Fax: 56-2-776730
TXL: 240239

Itronsa

(For Fluke products)
Casilla 16228
Santiago, Chile
Tel: (56) (2) 232-4308
Fax: (56) 2-2322694
TLX: (332) 346351

China, Peoples Republic (via Hong Kong)

Philips Hong Kong Ltd.
(For Philips products)
29 F Hopewell Centre
17 Kennedy Road
G.P.O. Box 2108
Hong Kong
Tel: 852-5-8215888
Fax: 852-5-8655408
TLX: 73660 philh hx

China, People's Republic of Fluke International Corp.

PO Box 9085
Beijing
People's Republic of China
Tel: (86) (1) 512-3435
Fax: (86) 1-512-3437
TLX: (716) 222529 FLUKE CN

Instrimpex - Fluke Service Center

(For Fluke products)
Scite Tower Room 2101
22 Jiam Guo Man Wal Dajie
PO Box 9085
Beijing
People's Republic of China
Tel: 86 01 512-3436

Colombia

**Industrias Philips de
Columbia S.A.**
(For Philips products)
Apartado Aereo 4282
Calle 13 No. 51-39
Bogota
Tel: 57 1-2600600
Fax: 57-1-2610139
TLX: philcolon 44776

Sistemas E Instrumentation, Ltda.

(For Fluke products)
Carrera 21, No. 39A - 21, Of. 101
Ap. Aereo 29583
Bogota, Colombia
Tel: (57) 232-4532
Fax: (57) 1-287-2248

Costa Rica

Electrocom
Apartado 7742
San Jose
Costa Rica
Tel: 53-0083 n.
TLX: 3050 elecrom cr

Cyprus

**D. Ouzounian M. Soultanlan
& Co. Ltd.**
PO Box 1775
45, Evagoras Avenue
Nicosia
Tel: 357-2-442220
Fax: 357-2-459885
TLX: 2315 cy automobil

Denmark

**Philips A/S Test &
Measurement**
Prags Boulevard 80
DK 2300 Kobenhavn S
Tel: (31) 572222
Fax: (31) 570044
TLX: 31201

Egypt

**Philips Egypt Branch of Philips
Middle East B.V.**
10, Abdel Rahman el Rafie st.
PO Box 242
Dokki, Cairo
Tel: 20-2-3490922
Fax: 20-2-3492142
TLX: 22816 pheyg un

Ethiopia

Ras Abebe Areguay Avenue
PO Box 2565
Addis Ababa
Tel: 010-231-1-518300
Fax: 251-1-52845
TLX: 021319 phaddis

Finland

OY Philips AB
Sinikallontie 3
PO Box 75
02631 Espoo
Tel: 0-5026371
Fax: 0-529558
TLX: 1248 1150 Phil
Tel: 0-50261*
Fax: 0-529570*
TLX: 1248 1152 phil*

OY Philips AB*

Kaivokatu 8
PO Box 255
00101 Helsinki 10
Tel: 0-52571

Instrumentarium Elektronika*

PO Box 64 Vitikka 1
02631 Espoo 63
Tel: 0-5281

Sales and Service all over the world

France

S.A. Philips Industrielle et Commerciale
Division Science et Industrie
 105 Rue de Paris, BP 62
 93002 Bobigny Cedex
 Tel: (1) 49428080
 Tel: (1) 49428073*
 Fax: (1) 49428100
 TLX: 235546

Germany

Philips GmbH - EWI
Head Office
 Miramstrasse 87
 D-3500 Kassel
 Tel: 0561-501466
 Fax: 0561-501590
 TLX: 997070

Philips GmbH - EWI

Martin Luther Strasse 3-7
 D 1000 Berlin 30
 Tel: 030-21006364
 TLX: 185532

Philips GmbH - EWI

Wieselweg 5
 D 4300 Essen 11
 Tel: 0201-3610-245
 Fax: 0201-3610265
 TLX: 857-226

Philips GmbH - EWI

Th. Heuss Allee 106
 D 6000 Frankfurt 90
 Tel: 069-794093-31
 Fax: 069-794093-91
 TLX: 413611

Philips GmbH - EWI

Meiendorferstrasse 205
 D 2000 Hamburg 73
 Tel: 040-6797-278
 Tel: 040-6797471*
 TLX: 2116625

Philips GmbH - EWI

Ikarusallee 1A
 D 3000 Hannover 1
 Tel: 0511-6786-120
 TLX: 923950

Philips GmbH - EWI

Oskar Messterstrasse 18
 (For Fluke products)
 D 8045 Ismaning
 Tel: 089-9605-121
 TLX: 21701380 phd. memo = de73txm

Philips GmbH - EWI

Kilianstrasse 142
 D 8500 Nuernberg 12
 Tel: 0911-3603293
 TLX: 21701 380 phd, memo = de73txn

Philips GmbH - EWI

Hoehenstrasse 21
 D 7012 Fellbach
 Tel: 0711-5204-121
 Tel: 0711-5204150*
 Fax: 0711-5204136
 TLX: 7254669

Great Britain

Philips Scientific Test & Measurement
 Colonial Way
 Watford Herts WD2 4TT
 Tel: 0923-240511
 Fax: 0923-225067
 TLX: 934583 phitmd

Philips Scientific Test & Measurement

Yorkstreet
 Cambridge CB1 2PX
 Tel: 0223-358866
 Fax: 0223-321764
 TLX: 817331 phsc cam g

Greece

Philips S.A. Hellénique
 PO Box 3153
 15, 25th March Street
 15 GR 17778 Tavros/Athens
 Tel: 30-1-4894911
 Fax: 30-1-4815180
 TLX: 241566 PHAT GR

Hong Kong

Philips Hong Kong Ltd.
 (For Philips products)
 29/F Hopewell Centre
 17 Kennedy Road
 G.P.O. Box 2108
 Hong Kong
 Tel: 852-5-8215888
 Fax: 852-5-8655408
 TLX: 73660 phihl hx

Schmidt & Co (H.K.), Ltd.

(For Fluke products)
 18th Floor, Great Eagle Centre
 23 Harbour Road
 Wanchai, Hong Kong
 Tel: (852) (5) 8330-222
 Fax: (852) 5-836-2652
 TLX: (780) 74766 or 76762 SCHMC HX

Iceland*

Heimelistaeki S.F.
 (For Philips products)
 Saetun 8
 125 Reykjavik
 Tel: 1-691500
 Fax: 1-691555

Semeind

(for Fluke products)
 Brautarholt 8
 125 Reykjavik
 Tel: 1-25833
 Fax: 1-621531
 TLX: 3136 samein is

India

Peico Electronics & Electricals Ltd.
I&E Division
 (For Philips products)
 Band Box House
 254 Dr. Annie Besant Road
 Bombay 400 025
 Tel: 022 4930311/4930590
 Fax: 022-4941698
 TLX: 76049

Peico Electronics & Electricals Ltd.

I&E Division
 (For Philips products)
 7 Justice Chandra
 Madhab Road
 Calcutta 700 020
 Tel: 473621

Peico Electronics & Electricals Ltd.

I&E Division
 (For Philips products)
 68, Shivaji Marg
 New Delhi 110 015
 Tel: 530153
 Tel: 533956/57*
 TLX: 031 3142

Peico Electronics & Electricals Ltd.

I&E Division
 (For Philips products)
 No 3 Haddows Road
 Madras 600 006
 Tel: 472341
 TLX: 041 499

Peico Electronics & Electricals Ltd.

I&E Division
 (For Philips products)
 7311 St Mark's Road
 Bangalore 560 001
 Tel: 579119/579164
 TLX: 0845-8185

Hinditron Services Pvt., Ltd.

(For Fluke products)
 Industry House
 23-B Mahal industrial Estate
 Mahakali Caves Road
 Andherl (E) Bombay
 400 093, India
 Tel: (91) (22) 636-4560
 (91) (22) 634-8268
 Fax: (91) 22-822-0197
 TLX: (953) 11-79286 HIPL IN

Indonesia

P.T Daeng Brothers
 (For Philips products)
 Centre Point Building, 3rd Fl.
 Jalan Gatot Subroto Kav. 35/36
 PO Box 41 Tebet
 Jakarta
 Tel: 62-21-5207335
 Fax: 62-21-5207550
 TLX: 62798 phdc ia

P.T. Lamda Triguna

(For Fluke products)
 PO Box 6/JATJG, Jakarta 13001
 Indonesia
 Tel: (62) (21) 819-5365
 Fax: (62) 21-819-9631
 TLX: (796) 63938 KA IA

Iran

Philips Iran Ltd.
 Private Joint Stock Comp.
 PO Box 11365-3691
 TEHRAN
 Tel: 98-21-674138/675158
 TLX: 212545 phps ir

Ireland

Circuit Specialists Ltd.
 Unit 5, Enterprise Centre,
 Plassey Technology Park
 Castleroy, Limerick
 Tel: 061 330333

Italy

Philips S.p.A.
Sezione S & I, T & M Dept.
 Viale Elvezia 2
 20052 Monza
 Tel: (039) 3635240/8/9
 Fax: 039-3635309
 TLX: 333343

Japan

NF Circuit Design
Block Co., Ltd.
 (For Philips products)
 3-20 Tsunashima Higashi, 6
 Chome,
 Kokokuku, Yokohama 223
 Tel: (045) 452-0411
 TLX: 3823-297

Japan

Nihon Philips Corporation*
 Shuwa Shinagawa Building
 26/38 Tahanawa 3-Chrome
 Minatu-ku Tohyo 108
 Tel: 4485511

John Fluke Mfg. Co., Inc.

Japan Branch
 (For Fluke products)
 Sumitomo Higashi ShinbashBldg.
 1-1-11 Hamamatsucho
 Minato-ku, Tokyo 105, Japan
 Tel: (81) (3) 434-0181
 Fax: (81) 3-434-0170
 TLX: (781) 2424331 FLUKJJPJ

Jordan

Jordan Medical Supplies & Services
 PO Box 140415
 Al Biader
 Amman Jordan
 Tel: 962-6-819929
 Fax: 962-2-823556
 TLX: 22161 jms jo

Kenya

Philips Kenya Ltd.
 Ol Kalou Road, Industrial Area
 PO Box 30554
 Nairobi
 Tel: 254-2-557999
 Fax: 254-2-543135
 TLX: 24033

Korea, Republic of

Myoung Corporation
 (For Fluke products)
 Yeo Eui Do
 PO Box 14
 Seoul Korea
 Tel: (82) (2) 784-9942
 Fax: (82) 2-784-2387
 TLX: MYOUNG K24283

South Korea

Philips Industries (Korea) Ltd.
 (For Philips products)
 CPO Box 3680, Philips House
 260-199, Itaewon-Dong
 Youngsan-Ku
 Seoul
 Tel: 82-2-7970378
 Fax: 82-2-7978048
 TLX: philkor k 27291

Lebanon

Electronic Supplies S.A.R.L.
 Autostrade Dora, Hayek Bldg.
 PO Box 90 1388
 Beyrouth
 Tel: 01-894243
 TLX: 42950 DICI

Luxemburg

Philips Luxembourg
Professional Systems S.A.
 Rue des Joncs 4
 L-1818 Howald
 Tel: 496111
 Fax: 400577
 TLX: 60572

Malaysia

Electronic Systems (Malaysia) Sdn. Bhd.
 (For Philips products)
 Lot 51 Section 13
 Jalan University
 Petaling Jaya - Selangor 46200
 Tel: 60-3-7560112
 Fax: 60-3-7560761

Mecomb Malaysia Sdn. Bhd.

(For Fluke products)
 PO Box 24
 46700 Petaling Jaya
 Selangor, Malaysia
 Tel: (60) (3) 774-3422
 Fax: (60) 3-774 3414
 TLX: (784) MA37764 MECOMB

Malta

Charles A. Micallef & Co. Ltd.
 PO Box 527
 217 St. Paul str.
 Valletta
 Tel: 356-234313/233506
 TLX: 1651 mica mw

Mexico

Mexicana de Electronica Industrial S.A. (Mexel)
 Diagonal No. 27
 Entre Calle de Eugenia Y Ave.
 Colonia del Valle
 C.P. 03100, Mexico
 Tel: (90) (5) 680-4323
 Fax: (525) 687 8695
 TLX: (383) 177 1823 MDEIME

Mexel Servicios en Computacion*

Instrumentation Y Perifericos
 Blvd. Adolfo Lopez Mateos No. 163
 Col. Mixcoac
 Mexico D.F.
 Tel: 90-5-563-5411

*Service Center

Sales and Service all over the world

Morocco

Samtel*
2 Rue de Bapaume
Casablanca
Tel: 243050

Somacel

304 Boulevard Mohammed V
Casablanca 05
Tel: 308051/52
TLX: 27021

Nepal

Bahajurana Engineering & Sales (P) Ltd.
(For Philips products)
Jyoti Bhawan
PO Box 133 Kantipath
Kathmandu
Tel: 2-25134
TLX: jyoti np

Associated Enterprises

(For Fluke products)
GPO Box 790, Pyaphal Tole
Kathmandu, Nepal
Tel: 13868
TLX: (947) 2588 ASCENT NP

Netherlands

Philips Nederland B.V.
Test en Meetapparaten
Hoevenseweg 55A
Postbus 115
5000 AC Tilburg
Tel: 013-390112
Fax: 013-427528
TLX: 52683

Philips Nederland

Technische Service Prof. Akt.*
Hurksestraat 2C
Gebouw HBR
5652 AJ Eindhoven

New Zealand

Philips Scientific & Industrial PTY Ltd.
Test & Measurement Dept.
2 Wagner Place
PO Box 4021
Auckland 3
Tel: 09-084-160
Fax: 09-862728
TLX: N2 2395

Nigeria

Associated Electronic Products (Nigeria) Ltd.
KM 16, Ikorodu Road
Ojota
PO Box 1921
Lagos
Tel: 234-1-900160/69
Tel: 234-1-932825*
Fax: 234-1-615601
TLX: 21961 NG

Norway

Norsk Philips AS
Dept. I & E Test & Measurement
Sandstuveien 70
PO Box 1 Manglerud
0612 Oslo 6
Tel: 47-2-356110
Tel: 47-2-680200*
Fax: 47-2-381457
TLX: 856-71719

Oman

Messrs. Mustafa Jawad Trading Co.
PO Box 4918
Ruwi, Sultanate of Oman
Tel: 968-709955
Fax: 968-7972 77
TLX: 3731 mujatra on

Pakistan

Philips Electrical Co. of Pakistan (Private) Ltd.
(For Philips products)
Philips Markaz, M.A. Jinnah Road
PO Box 7101
Karachi 3
Tel: 92-21-725772/9
Fax: 92-21-726694
TLX: 2874 phpak pk

International Operations (PAK Private), Ltd.

(For Fluke products)
505 Muhammadi House
I.I. Chundrigar Road
PO Box 5323
Karachi 2, Pakistan
Tel: (92) (21) 221127
Fax: (92) 21-2411241
TLX: (952) 24494 PIO PK

Paraguay

Philips del Paraguay S.A.
(For Philips products)
Avenida Artigas 1519
Casilla de Correo 605
Asuncion
Tel: 595-21-291924
Fax: 595-21-211662
TLX: py 215

Peru

Philips Peruana S.A.
Carretera Central KM 6.5
Apartado 1841
Lima 1000
Tel: 51-14-350059
Fax: 51-14-423107

Importaciones y Representaciones Electronicas S.A.

(For Fluke products)
Avda. Franklin D. Roosevelt 105
Lima 1, Peru
Tel: (51) (14) 28-8650
TLX: (394) 25663 PE IREING

Philippines, Republic of

Philips Industrial Development Inc.
(For Philips products)
2246, Pasong Tamo
PO Box 911
MCCPO Makati Riazal D
Metro Manila
Tel: 63-2-8100161/69
Fax: 817-3474

Spark Radio & Electronics, Corp.

(For Fluke products)
PO Box 610, Greenhills
Metro Manila 1502
Philippines
Tel: (63) (2) 775192
Fax: (63) (2) 7220313
TLX: (712) 4005 RLA PH PU

Portugal

Philips Portuguesa, S.A.R.L.
Division of I & E
Test & Measurement
Av. Eng. Duarte Pacheco 6
1009 Lisboa Codex
Tel: 1-657181
Fax: 1-658013

Philips Portuguesa* Division I & E

Rua Eng Erequil de Campos 182
4100 Porto
Tel: (2) 678278
TLX: 28790

Qatar

Darwish Trading Company
PO Box 92
Doha, Qatar
Tel: 974-422781 ext. 228
Fax: 974-426378
TLX: 4298 tradar dh

Saudi Arabia

Messrs. A. Rajab & A. Silsilah
Head Office
PO Box 203
Jeddah 21411
Tel: 966-2-6610006
Fax: 966-2-6610164-6610558
TLX: 601180 arndas sj

Messrs. A. Rajab & A. Silsilah

PO Box 260
Riyadh 11411
Tel: 966-1-4122425
Fax: 966-1-4122366
TLX: 404787 arndas sj

Messrs. A. Rajab & A. Silsilah

PO Box 587
Damman
Tel: 966-3-8322596/8331870
Fax: 966-3-8271962
TLX: 601044 arndas sj

Singapore

Philips Project Development (S) PTY Ltd.
(For Philips products)
Lorong 1, Toa Payoh
Singapore 1231, PO Box 340
Toa Payoh Central Post Office
Singapore 9131
Tel: 65-3502000
Fax: 65-2535873
TLX: philips rs/21375

Rank O'Connor's Pte Ltd.

(For Fluke products)
O'Connor House
98 Pasir Panjang Road
Singapore 0511
Republic of Singapore
Tel: (65) 473-7944
Fax: (65) 472-4508
TLX: (766) RS 21023 OCONSIN

South Africa

South African Philips PTY Ltd.
I & E Division Test & Measurement
10 Bondstreet, Randburg
Johannesburg 2000
Tel: 27-11-889-3911
Fax: 27-11-889-3098/889 3191
TLX: 4-26152-sa

South African Philips PTY Ltd.*

I & E Customer Support Centre
195 Mai Road, PO Box 58088
Martindale, New Ville 2092
Tel: 27-11-470-5937
Fax: 27-11-470-5166
TLX: 4-26152 SA

Spain

Philips Iberica SAE
Depto Instrumentacion de Medida
Poligono Industrial Zona Franca
Sector C-calle F
08004 Barcelona
Tel: 34-3-3361061
Fax: 34-3-3355838
TLX: 51293/59292

Philips Iberica*

Depto Instrumentacion de Medida
Martinez Villergas 2
28027 Madrid
Tel: 34-1-4042200
Fax: 34-1-4048603
TLX: 27710

Philips Iberica SAE*

Jose Olabarria 6
48012 Bilbao
Tel: 34-4-4313800
Fax: 34-4-432 0961
TLX: 31230

Sri Lanka

Hayleys Electronics & Engineering Ltd.
(For Philips products)
PO Box 70
400 Deans Road
Colombo 10
Tel: 599087
Fax: 598786
TLX: 21146/21384

Computerlink Data Systems, Ltd.

(For Fluke products)
68 Havelock Rd.
Colombo, 5, Sri Lanka
Tel: (94) (1) 502202/3
Fax: (94) 1-502203
TLX: (954) 22455 COLINK CE

Sweden

Philips Kistaindustrier AB
PO Box 33
16493 Kista
Tel: 08-7031000
Fax: 08-752 0831
TLX: 17173 philkis

Svenska A.B. Philips*

Div. Industrielektronik
Avd. Matinstroment
11584 Stockholm
Tel: 782-1800

Switzerland

Philips AG Test und Messtechnik
Postfach 670
8027 Zurich
Tel: 01 4882390
Fax: 01 4828595
TLX: 815780-0

Philips SA

Test et Mesure
Avenue du Mont Blanc
1196 Gland
Tel: 022/647171

Syria

Philips Moyen-Orient S.A.R.L.
Rue Fardous 79
PO Box 2442
Damascus
Tel: 218605/221650
TLX: phisyr 411203 sy

Taiwan

Philips Taiwan Ltd.
(For Philips products)
150, Tun Hua North Road
PO Box 22978
Taipei
Tel: 886-2-7120500
Fax: 886-2-7125442
TLX: 21570 philipei

Schmidt Electronics Corp.

(For Fluke products)
5th Floor, Cathay Min Sheng
Commercial Building,
344 Min Sheng East Road
Taipei, Taiwan R.O.C.
Tel: (886) (2) 501-3468
Fax: (886) 2-502-9692
TLX: (785) 11111 SCHMIDT

Tanzania

Philips (Tanzania) Ltd.
T.D.F.L. Building - 1st Floor
PO Box 20104
Ohio/Upanga Rd.
Dar es Salaam
Tel: 29571/4
TLX: 41016

Sales and Service all over the world

Thailand
Philips Electrical Co. of Thailand Ltd.
 (For Philips products)
 283, Silom Road
 PO Box 961
 Bangkok 10500
 Tel: 66-2-233-6330/9
 TLX: 87327 philttha th

Measuretronix Ltd.
 (For Fluke products)
 210231 Ramkamhaeng Road
 Bangkok 10240
 Thailand
 Tel: (66) (2) 375-2733
 Fax: (66) 2-374-9965
 TLX: (788) 82796 HUAMARK TH

Tunisia
S.T.I.E.T.
 32 bis rue Ben Ghedahem
 Tunis
 Tel: 348666
 TLX: 14512

Turkey
Türk Philips Ticaret A.S.
 Talatpasa Caddesi no. 5
 PO Box 161
 80640 Levent-Istanbul
 Tel: 90-1-1792770
 Fax: 90-1-1693094
 TLX: 24192 phtr tr

United Arab Emirates
Al Sanani Trading Est.
 PO Box 7187
 Abu Dhabi, U.A.E.
 Tel: 971-2-771370
 Fax: 971-2-728963
 TLX: 23966 Sanani em

Haris Al-Afaq Ltd.
 PO Box 8141
 Dubai, U.A.E.
 Tel: 971-4-283625
 TLX: 48168 Afaq em

Uruguay
Cossin Uruguay S.A.
 (For Fluke products)
 PO Box 1400
 Libertad 2529
 Montevideo, Uruguay
 Tel: (598) (2) 789015
 TLX: (398) 23010 COAUR UY

Venezuela
Inds. Venezolanas Phillips S.A.
 (For Philips products)
 Av. Francisco de Miranda
 Urb. La Carlota,
 Edf. Centro Empresarial Parque
 del Este
 Apartado 1167
 Caracas 1010-A
 Tel: 58-2-203, 71111
 Fax: 58-2-2391090
 TLX: 25267 ivpsa vc

Cossin C.A.
 (For Fluke products)
 Calle 9 Con Calle 4, Edifi Edinurbi
 Apartado de Correos NR-70.136
 Los Ruices
 Caracas 1070-A, Venezuela
 Tel: (58) (2) 241-03-09
 TLX: (395) 21027EMVEN VC

Yemen Arab Republic
Rashed Trading & Travel Agency
 Ali Abdulmugni st.
 PO Box 1221
 Sana'a, Yemen Arab Republic
 Tel: 967-2-273231
 TLX: 2230 abgbar ye

Zaire
Philips Electronics S.A.R.L.
 137 Boulevard du 30 Juin
 BP 16636
 Kinshasa
 Tel: 31693
 TLX: 21078 kinshasa

Zambia
Philips Electrical Zambia Ltd.
 Mwenbeshi Road
 PO Box 31878
 Lusaka
 Tel: 218511/218701
 TLX: za 41220

Zimbabwe
Philips Electrical (Pvt.) Ltd.
 62 Mutare Road
 PO Box 994
 Harare
 Tel: 47211/48031
 Fax: 263-4-47966
 TLX: 2236

For Countries not listed above:
Philips Export B.V.
I & E Export
Test & Measurement
 building HVW-3
 PO Box 218
 5600 MD Eindhoven
 The Netherlands
 Tel: +31 40 711546
 Fax: +31 40 711508
 TLX 35000 phtc nl

Fluke Int'l Corp.
 PO Box 9090
 Mail Stop 206A
 Everett, WA 98206-9090
 Tel: 206-356-5500
 Fax: (206) 356-5116
 TLX: 185103 FLUKE UT

U.S.A.

Alabama
Huntsville
 4920 Corporate Drive Suite J
 Huntsville, AL 35805-6202
 (205) 837-0581

Arizona
Phoenix
 2211 S. 48th Street Suite B
 Tempe, AZ 85282
 (602) 438-8314

California
Irvine*
 PO Box 19676
 Irvine, CA 92713-9676
 16969 Von Karman Ave.
 Suite 100
 Irvine, CA 92714
 (714) 863-9031

Northern*
 46610 Landing Parkway
 Fremont, CA 94538
 (415) 651-5112

Colorado
Denver*
 14180 E. Evans Ave.
 Aurora, CO 80014
 (303) 695-1000

Connecticut
Hartford
 Glen Lochen East
 41-C New London Turnpike
 Glastonbury, CT 06033
 (203) 659-3541

Florida
Altamonte Springs*
 550 South Northlake Blvd.
 Altamonte Springs,
 FL 32803
 (407) 331-4881

Georgia
Atlanta
 2700 Delk Road Suite 150
 Marietta, GA 30067
 (404) 953-4747

Illinois
Chicago*
 1150 W. Euclid Avenue
 Palatine, IL 60067
 (708) 705-0500

Indiana
Indianapolis
 8777 Purdue Road Suite 101
 Indianapolis, IN 46268
 (317) 875-7870

Massachusetts
Boston
 Middlesex Technology Center
 900 Middlesex Turnpike
 Building 8
 Billerica, MA 01821
 (508) 663-2400

Maryland
Rockville*
 5640 Fishers Lane
 Rockville, MD 20852
 (301) 770-1570

Michigan
Detroit
 45550 Helm Street
 Plymouth, MI 48170
 (313) 522-9140

Minnesota
Minneapolis
 1380 Corporate Center Curve
 Suite 113
 Eagan, MN 55121
 (612) 854-5526

Missouri
St. Louis
 11756 Borman Drive Suite 160
 St. Louis, MO 63146
 (314) 993-3805

New Jersey
Paramus*
 PO Box 930
 Paramus, NJ 07653-0930
 West 75 Century Road
 Paramus, NJ 07652
 (201) 262-9550

New York
Rochester
 4515 Culver Road
 Rochester, NY 14622
 (716) 323-1400

North Carolina
Greensboro
 1310 Beaman Place
 Greensboro, NC 27408
 (919) 273-1918

Ohio
Cleveland
 Plaza South Three Suite 402
 7271 Engle Road
 Middleburg Heights, OH 44130
 (216) 234-4540

Pennsylvania
Philadelphia
 200 Lindenwood Drive
 Malvern, PA 19355
 (215) 647-9550

Texas
Dallas*
 1801 Royal Lane Suite 307
 Dallas, TX 75229
 (214) 869-0311

San Antonio
 10417 Gulfdale
 San Antonio, TX 78216
 (512) 340-0498

Washington
Seattle*
 2375 130th Ave. N.E.
 Suite 100
 Bellevue, WA 98005
 (206) 881-6966