


S	G.H.										34	E. A. F.			C.D.	B.												
C	79.74.64.69.62.76.66.68.72.83.73.71.84.78.77.87.	70.	60.	85.	59.	65.	52.	34.	61.	67.	38.	37.	33.	50.	36.	25.	41.	48.	40.	42.	43.	28.	31.	30.	27.	35.	32.	26.
R	62.27.34.68.32.31.	33.67.26.28.	29.24.60.65.35.17.21.18.19.16.66.	B.							14.	11.	12.	6.	9.	7.	10.	8.										



JR 006 77 (/00)	Cabinet Kast Ebnisterie	JR 362 56 (1,9) JR 362 55 (2,10) JR 657 01 (11,18)	Knob Knop Bouton Knopf Botón	JR 322 63	Roller balance control, lower Rol balansregelaar , onder Rouleau inférieur contr. de balance Rolle Balanceregler, unten Rollo inferior contr. de balance
JR 012 05 (/01)	Gehäuse Mueble	JR 255 29	Rear panel Achterwand Panneau arrière Rückwand Panel posterior	JR 322 64	Roller balance control, upper Rol balansregeling, boven Rouleau supérieur contr. de balance Rolle Balanceregelung, oben Rollo superior contr. de balance
JR 670 40	Loudspeaker grill Luidsprekerrooster Grille haut-parleur Lautsprechergitter Rejilla de altavoz	JR 399 29	Connecting plate, rear Aansluitplaat, achterzijde Plaque de connexion, côté arrière Anschlussplatte, Rückseite Placa de conexión, lado posterior	JR 997 71	Balance indicator strip Balansindicatiestrip Barrette d'indication de balance Balanceindikatorstreifen Pletina del indicador de balance
JR 664 41 JR 664 38 JR 664 37 JR 664 39	Dial Schaal Cadran Skala Cuadrante	JR 467 12	Voltage adapter Spanningsomschakelaar Carrousel de tension Spannungswähler Selector de tensión	JR 576 90	Tone indicator disc Toonindicoatieschijf Disque d'indication de son Tonindikatorscheibe Dino del indicador de tonalidad
JR 670 39	Window, EM 84-balance Venster, EM 84-balans Fenêtre, EM 84-balance Fenster, EM 84-Balance Ventanilla, EM 84-balance	JR 677 35	Plate behind dial Plaat achter schaal Plaque derrière cadran Platte hinter Skala Placa detrás cuadrante	JR 652 82	Spring, wave range switch Veer, golflengteschakelaar Ressort, comm. de gammes Feder, Wellenbereichschalter Resorte, comm. de márgenes
JR 674 16	Foot Voet Pied Fuss Pie	JR 213 22 (9 x) 965/2,05x14 (2 x)	Pulley, on front Rol, op front Rouleau, sur front Seilrolle, auf Front Rollo, sobre frente	JR 186 33	Ferroceptor switch Ferroceptorschakelaar Comm. de ferrocepteur Ferroceptorschalter Comm. de ferrocaptor
JR 327 11 (3-6) JR 327 61 (11-17)	Push button Druktoets Touche poussoir Drucktaste Tecla	JR 212 00	Fulley, on switch and duplex Rol, op schak. en duplex Rouleau sur comm. et duplex Seilrolle, auf Schalter und Duplex Rollo, sobre comm. y duplex	JR 093 03	FM unit FM -eenheid Unité FM UKW-Einheit Unidad FM

Take original Service parts, then you are safe

Utilisez les pièces détachées d'origine - c'est plus sûr

Nimm doch original Service Teile, dann geht mann sicher

Gebruik originele Service-onderdelen

Para mayor seguridad - úsense las piezas de recambio primi

S12 } C39 }	JR 122 54	JF link circuit, FM MF-koppeling, FM Circuit de couplage FI, FM ZF-Kopplungskreis, UKW Circuito de acoplo, FM	S26 } S27 } C46 } C47 }	A3 129 30	IF band-pass filter, AM MF-bandfilter, AM Filtre passe bande FI, AM ZF-Bandfilter, AM Filtro de pasabanda, FI, AM	S40 } S41 } S42 }	JR 142 25	Mains transformer Nettransformator Transformateur de réseau Netztransformator Transformador de red
S13 } S14 }	JR 122 32	Wave trap coil and choke Sperring- en smoorspoel Circuit bouchon et self Sperrkreisspule und Drossel Bobina de trampa de onda y choke	S28 } S29 } S30 } C53 }	JR 122 27	Radio detector Radiodetektor Décteur de rapport Radiodetektor Detector de razón	C22) C23)	49 002 38	Variable capacitor Variabele condensator Condensateur variable Drehkondensator Condensador variable
S15 } S16 }	JR 133 41	Input coil, SW Ingangspoel, KG Bobine d'entrée, OC Eingangsspule, KW Bobina de entrada, OC	S31 } S32 } C54 } C55 }	A3 129 30	IF band pass filter, AM MF-bandfilter, AM Filtre passe bande FI, AM ZF-Bandfilter, AM Filtro de pasabanda FI, AM	R50-51) R52-53)	JR 377 68	
S17 } S17 } S18 } S18 }	JR 132 86	Ferroceptor, MW-LW Ferroceptor, MG-LG Ferrocepteur, PO-GO Ferroceptor, MW-LW Ferrocaptor, OM-OL	S33 } R14 } S34 } S35 }	JR 132 85 JR 133 35 VK 200 10	Choke Smoorspoel Self Drossel Choque	R54) R55) R56) R57)	JR 377 69	
S19 } S20 } S21 } S22 } S23 }	JR 122 24	Oscillator coil, LW-MW-SW Oscillatorspoel, LG-MG-KG Bobine d'oscillateur, GO-PO-OC Oszillatorspule, LW-MW-KW Bobina de oscilador, OM-OL-OC	S36 } S37 }	56 390 28/ 22B 56 390 28/ 22B	Ferroxcube bead Ferroxcubekraai Perle de ferroxcube Ferroxcubeperle Perla de ferroxcube	C29) C30) C32) C78) C79,79a)	C 285 AB/D500E C 285 AB/D395E C 285 AB/D150E 909/26,4 909/W100+909/Y9,4	
S24 } S25 } C44 } C45 }	JR 122 53	IF band pass filter, FM MF-bandfilter, FM Filtre passe bande FI, FM ZF-Bandfilter, UKW Filtro de pasabanda FI, FM	S43 } J44 } S45 } S46 } S47 } S48 }	JR 152 38	LS transformer LS-transformator Transformateur de h-p LS-Transformator Transformador de altavoz	C80) C81) C82)	913/M50+50+50	
R10	R8 305 08E/12K		R11, 16	E 001 AD/A2K2		R30) C63)	E 551 AA/70+32	
R40, 40a	E 001 AK/A680E		R41	E 001 AK/A56E		R22) C56) C57)	E 553 AA/49+40	

JGB/UV

